

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [TenCloud](#) /

> [TenCloud Silicone Band Holders Instruction Manual for Bushnell Golf Watches](#)

TenCloud Bushnell GPS golf watch Neo iON Force

TenCloud Silicone Band Holders Instruction Manual

For Bushnell Golf Watch Neo iON Force, iON Edge, and iON Elite

Brand: TenCloud

1. INTRODUCTION

This manual provides instructions for the TenCloud Silicone Band Holders, designed as replacement accessories for compatible Bushnell Golf Watches. These band keepers are essential for securing the excess strap of your smartwatch, preventing it from flapping during use and ensuring a comfortable fit.

2. PACKAGE CONTENTS

Each package contains:

- 10 x Silicone Band Keepers

Note: The Bushnell Golf Watch and its wristband are not included.



Image 2.1: A view of the ten silicone band keepers included in the package, shown from various angles.

3. COMPATIBILITY

These silicone band holders are compatible with the following Bushnell Golf Watch models:

- Bushnell Golf Watch Neo iON Force
- Bushnell Golf Watch Neo iON Edge
- Bushnell Golf Watch Neo iON Elite

For Bushnell Neo iON Force



Image 3.1: A Bushnell Neo iON Force golf watch displayed alongside two silicone band keepers, illustrating compatibility.

4. INSTALLATION INSTRUCTIONS

1. **Prepare the Watch Band:** Ensure your Bushnell Golf Watch band is clean and free of debris.
2. **Position the Keeper:** Take one silicone band keeper. Locate the end of your watch strap that passes through the buckle.
3. **Slide On:** Gently slide the band keeper over the end of the watch strap, past the buckle, until it rests securely against the buckle. The keeper is designed with an integrated gear/skipproof clip to help it stay in place.
4. **Secure the Strap:** Once the watch is on your wrist and buckled, thread the excess strap through the newly installed band keeper. This will hold the strap tail firmly against your wrist.



Image 4.1: A watch band with a silicone keeper correctly positioned to secure the strap.

Integrated skipproof clip

to ensure your fastener more stable




Image 4.2: A diagram highlighting the integrated skipproof clip feature within the band keeper, designed for enhanced stability.

5. USAGE

The TenCloud Silicone Band Holders are designed for daily use to keep your Bushnell Golf Watch strap neat and secure. After fastening your watch, simply slide the excess strap through the keeper. The integrated gear ensures a snug fit, preventing the strap from moving freely or flapping, which enhances comfort and reduces the risk of snagging.

6. MAINTENANCE

To maintain the longevity and appearance of your silicone band keepers:

- **Cleaning:** Wipe the keepers with a soft, damp cloth to remove dirt or sweat. Avoid harsh chemicals or abrasive materials.
- **Storage:** Store unused keepers in a cool, dry place away from direct sunlight.
- **Inspection:** Periodically check the keepers for any signs of wear or damage. Replace if necessary.



Image 6.1: A detailed close-up of a single silicone band keeper, highlighting its texture and design.

7. TROUBLESHOOTING

If you encounter any issues with your band keepers:

- **Keeper feels loose:** Ensure the keeper is correctly positioned against the buckle and the excess strap is fully threaded through it. The integrated gear should provide a secure fit.
- **Keeper is damaged:** If a keeper tears or breaks, replace it with a new one from the 10-pack.

8. SPECIFICATIONS

Product Name	Silicone Band Holders
Brand	TenCloud
Material	Premium Soft Silicone
Quantity	10 Count

Color	Black
Special Features	Integrated skipproof clip for secure fastening
Item Weight	0.81 ounces (total package)

9. WARRANTY AND SUPPORT

Specific warranty information for this product is not provided. For any product-related inquiries, support, or assistance, please contact TenCloud customer service directly through their official channels or the retailer where the product was purchased.