



Manuals.plus /

› **burgkidz** /

› Burgkidz 5-in-1 Flip Top Activity Table and Chair Set Instruction Manual (Model LX.A921B)

burgkidz LX.A921B

Burgkidz 5-in-1 Flip Top Activity Table and Chair Set Instruction Manual

Model: LX.A921B

IMPORTANT SAFETY INFORMATION

- Adult supervision is required at all times when children are using the activity table and chair.
- Regularly inspect all components for damage or wear. Discontinue use if any part is broken or compromised.
- Do not allow children to climb on the table or chair, as this may cause tipping and injury.
- Keep the product away from open flames or direct heat sources.
- Ensure the table is placed on a flat, stable surface during use.

PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 1 x Activity Table Base
- 1 x Double-Sided Playboard (Building Block Surface / Flat Surface)
- 1 x Chair
- 4 x Removable Side Storage Boxes
- 128 x Large Building Blocks (compatible with major brands)

Suitable for Variety of Scenarios



Image: All components included in the Burgkidz 5-in-1 Activity Table and Chair Set package.

ASSEMBLY INSTRUCTIONS

The Burgkidz 5-in-1 Activity Table and Chair Set is designed for easy snap-together assembly. No tools are required.

1. Attach the four table legs to the table base. Ensure each leg clicks securely into place.
2. Attach the four chair legs to the chair base. Ensure each leg clicks securely into place.
3. Insert the four removable side storage boxes into the designated slots on the sides of the table.
4. Place the double-sided playboard onto the table, choosing either the building block surface or the flat surface facing upwards.



Image: Visual guide for the snap-together assembly of the table and chair legs.

Video: Demonstrating the unboxing and initial assembly of the Burgkidz activity table, highlighting the ease of putting components together.

OPERATING MODES

1. Building Block Table

Utilize the green studded side of the double-sided playboard as a base for building with the included 128 large building blocks or other major brand compatible blocks. The side storage boxes are ideal for organizing and holding blocks for easy access during play.

Play & Build Multi Activity Table



Image: Overhead view of the table in building block mode, showing blocks on the green studded surface and in side storage bins.

Video: Official product video showcasing the table's use as a building block play surface, demonstrating block compatibility and creative play.

2. Flat Surface Table (Learning/Dining Table)

Flip the playboard to the smooth white side to transform the activity table into a versatile flat surface. This mode is perfect for drawing, coloring, reading, or serving as a child-friendly dining table.



Image: Children drawing and engaging in learning activities on the smooth, flat surface of the table.



Image: A child eating a meal at the table, demonstrating its use as a dining surface.

3. Water Table

Remove the playboard to reveal a recessed basin. This basin can be filled with water for various water play activities. Ensure the drain plug at the bottom of the basin is securely in place before filling with water.

DIMENSIONS




Image: The table's recessed basin filled with water and toys, illustrating its function as a water play area.

4. Sand Table

The recessed basin can also be used as a sand table. Fill it with play sand for sensory exploration and creative sand play. Remember to secure the drain plug.

5. Storage Table

When the playboard is removed, the spacious basin underneath serves as a convenient storage area. This is perfect for tidying up blocks, art supplies, or other toys, keeping your play area organized.



Image: The table with the playboard removed, revealing the internal storage compartment filled with blocks.

MAINTENANCE AND CARE

- To clean the table and chair, wipe all surfaces with a damp cloth and mild soap.
- Avoid using abrasive cleaners, harsh chemicals, or solvents, as these may damage the plastic.
- Ensure the table and chair are completely dry before storing or allowing children to use them again.
- The plastic construction is durable and designed for easy maintenance.

TROUBLESHOOTING

- **Problem:** Table or chair legs are wobbly. **Solution:** Ensure all legs are fully inserted and clicked into place. Check for any debris preventing a secure connection.
- **Problem:** Side storage boxes fall off easily. **Solution:** Ensure the boxes are correctly hooked onto the table's edge. While designed for easy removal, a firm attachment is needed for stability.
- **Problem:** Blocks do not fit securely on the playboard. **Solution:** Verify that the blocks are compatible with major brands. Ensure the playboard is clean and free of obstructions.

SPECIFICATIONS

Feature	Detail
Model Number	LX.A921B
Assembled Table Dimensions	17.7"L x 17.7"W x 17"H
Assembled Chair Dimensions	10.35"W x 10.12"D x 17.01"H
Item Weight	8.7 pounds
Recommended Age	2 years and up
Material	Sturdy, lightweight plastic



Image: A detailed graphic illustrating the dimensions of the assembled activity table and accompanying chair.

WARRANTY AND SUPPORT

For warranty information or product support, please contact Burgkidz customer service through the retailer's platform where the product was purchased or visit the official Burgkidz website. Please retain your purchase receipt as proof of purchase.

