Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XIHADA ML999-06

XIHADA Universal Garage Door Opener Remote Cloner ML999-06 Instruction Manual

Model: ML999-06

Introduction

This manual provides comprehensive instructions for the setup, programming, operation, and maintenance of your XIHADA Universal Garage Door Opener Remote Cloner. This device is designed to clone existing remote controls for garage doors and gates operating across multiple frequencies (280MHz-868MHz).
Important Note: Your original working remote is required for cloning. This universal remote cannot be programmed without an existing functional remote.

Product Overview





Figure 1: XIHADA Universal Remote with included visor clip. The compact design allows for easy attachment to a keychain or vehicle visor.



Figure 2: The remote features four programmable buttons, labeled Key 1, Key 2, Key 3, and Key 4, for controlling up to four different devices.

Setup and Programming

The XIHADA Universal Remote can clone up to four different original remotes, even if they operate on different frequencies (280MHz - 868MHz).

Programming Steps (General)

1. **Clear Existing Codes:** Hold down Button 1 and then press Button 2 four times. Release both buttons. The LED on the universal remote will emit a quick flash every 2 seconds, indicating it is ready for learning.
2. **Position Remotes:** Place your original remote very close to the universal remote, ideally back-to-back or face-to-face, about 2-3 cm apart.
3. **Initiate Cloning:** Hold down the button on your original remote that you wish to clone. Simultaneously, press any button on the universal remote where you want to store the code. Continue holding both buttons until the LED on the universal remote starts to flash quickly. This indicates successful cloning.
4. **Verify:** Once the LED on the universal remote turns off, the code has been copied. Test the newly programmed button.

Programming for Garage Door Openers (Rolling Code)

For garage door openers, an additional step is required after cloning the code to the universal remote:

5. **Activate Learn Mode on Opener:** Press the 'LEARN' button on your garage door opener's receiver (the mechanical unit that opens the door). The LED on your garage door opener should turn ON.
6. **Transmit Code:** Within 30 seconds of activating the learn mode, press the same button you programmed on the universal remote. The lights on your garage door opener should either flash or go on/off, depending on the brand of the opener, indicating successful pairing.

Your browser does not support the video tag.

Video 1: Detailed Programming and Duplication Video for XIHADA Universal Remote. This video demonstrates the step-by-step process for cloning and programming the remote with various systems.



Figure 3: Visual guide for programming rolling code remotes, including the step to activate the 'LEARN' button on the garage door opener.

Compatibility Information

Before purchasing or programming, please review the compatibility lists. This remote is designed to work with major brands and models, but some are explicitly not compatible.

The duplicator for copy rolling code remote

Brand	model	Brand	model
ACM	TX2, TX2 COLOR, TX4	LABEL	SPYCO
ADYX	TE4433H BLUE, 433-HG BRAVO	LIFE	FIDO
AERF	COMPACT, HY-DOM, MERCURI B, MERCURI C, ABUTON, MARS, SATURN, ST3/N, TERRA, TMP-1, TMP-2, UNITECH	LINEAR	MCT-11, ACT-21, ACT-22, STING RAY ACT-31, STING RAY ACT-34B
ALLMATIC	BROWN, BROWN RED, BRO.OVER, PASS, MINIPASS, TECH3	MERLIN	2.0 E945M, E943M, E940M MERLIN/PROLIFT C945, C940, C943, M842, M844
APERIO	GO, GO PRO, GO MINI APERTO (Sommer) 4020-TX03-434, TX02-434-2, TX02-868-2	MHOUSE	TX3, TX4, GTX4
APRIMATIC	TR, TM4, TXM	MOOVO	MT4G
ATA	PTX4 BLU, PTX4 PINK	NICE	SMILO, FLOR-S, VERY-VR, FLOR-S ERA . ONE (ON), ON ERA, INTI, ERGO, PLANO, ONE (ON FM)
AVIDSEN	104251, 104250, 104250 OLD, 104250 RED, 104257, 104350, 654250 BALLAN FM400, FM400E	NORTON	NEO, TXCD GO NORTON, GO MINI NORTON
BENINCA	TO. GO. WV, TWV, ROLLKEY, APPLE, LOT WCV, CUPIDO, TO.GO. QV,IO	NOVOFERM	MCHS, MICRO-NOVOTRON 502, MINI-NOVOTRON 504, MICRO-NOVOTRON 502, MICRO-NOVOTRON 504, MICRO-NOVOTRON 31, MICRO-NOVOTRON 51, MINI-NOVOTRON 30, MINI-NOVOTRON 50, MNHS
BFT	MITTO, MITTO M, MITTO RCB, MITTO A, TRC, GHIBLI, MURALE, KLEIO	O&O	TX, T.COM R4-2, T.COM R8-2, TWIN, TX (NEO)
CARDIN	TRQ S449, TRQ S449 GREEN (PRECODE), TXQ S449, TXQ S449 GREEN, TRQ S486, TXQ S486, S437 TX, XRADO	PECCININ	TX MENBRANA
CASALI	JA33 AMIGO GENIUS/CASALI A252RC	PRASTEL	MTE, MPSTLE, MPSTP2E, TCE, BFOR, TRQ-P, SLIM-E
CHAMBERLAIN/ LIFT MASTER/ MOTOR LIFT	953ESTD, 371 LM, 971LM, 84330E, 94334CE, 94333E/94334E/94335E, 9747E, 1A5639-7, 1A5477, 1A6487, 132B2372, 94330EML/9333EML/94335EML, 84330EML/84333EML/84335EML, 8747EML	PUJOL	TWIN, VARIO, VARIO MARS, VARIO OCEAN, NEO
CLEMSA	MUTANCODE, T, T-8, E-CODE N MASTERCODE MV	RIB	LITHIO
DASPI	ZERO RC	ROPER	NEO ,GO ROPER, GO MINI ROPER\ SABUTOM BROOVER, BROSTAR
DEA	SYSTEM PUNTO 278, GOLDR, GENIE R 273	SEA	HEAD, SMART DUAL ROLL, SMART-3 ROLLING CODE, COCCINELLA ROLL
DITEC	BIXLP, GOL4, BIXLG	SEAV	BE HAPPY RS
DOORHAN	TRANSMITTER 4	SECULUX	NEO
DOORMATIC	MILENY, MILENY-EVO	SILVELOX	Mhz 2007, QUARZ SAW
ECOSTAR	RSC, RSE, RSZ	SIMINOR	CVXNL, MITTO ,SIM433
ERREKA	IRIS, ROLLER 2, ROLLER 433, ROLLER 868, SOL433, SOL868, VEGA 433, VEGA 868	SOMFY	K-EASY, K-EASY NEW, K-EASY OLD, MITTO, KEY GO RTS, TELIS RTS, KEYTIS RTS, KEYTIS RTS NS, ALARMA
FAAC	TML 433SLH, DL 868 SLH, XT 868 SLH, XT 433 SLH, T 868 SLH, T 433 SLH, XT 868 SLH BLACK, XT 433 SLH BLACK,XT 433 RC, TE433HG, XT4 433 RCBE	SOMMER	4010, 4011, 4014 TX03-434-2, 4013 TX03-434-4, 4020 TX03-868-4, 4026 TX03-868-2, 4022 TX02-434-2, 4025 TX02-868-2, 4031 TX08-868-4 .
FADINI	JUBI-SMALL, JUBI 433	STAGNOLI	KALLISTO, VENUS AV223
GENIE	GITR-3, GIT, GICT390, GIFT390-1, G3T-BX, G1T-BX, GM3T, GICTD, GIFTD	TAU	250K-SLIMRP, 250K-SLIMR, 250T-4RP
GENIUS	AMIGOLD, AMIGO, KILO BRAVO, ECHO	TELCOMA	FM400E, FM400
GIBIDI	AU1600, AU1600 WOOD, AU1680, AU1680 WOOD, DOMINO	TOR LIFT	TORMIT4
JCM	NEO, TWIN ,GO, GO PORTIS, GO NORTON, KBLUE ETH-TEL01	V2	TSC, TXC, TRC, HANDY, PHOENIX, PHOX 433
KEY	900TXB-42R, TXB 44R, SUB 44R .KING GATES CLIPPER, STYLO KLING KUA, KUA E, KUA S	VDS	ECO-R, TRQ P

Figure 4: List of compatible remote brands and models for cloning. Please verify your original remote is listed here.




Figure 5: List of brands and models not compatible with the XIHADA Universal Remote. Ensure your system is not on this list.

Operating Instructions

Once programmed, the universal remote operates identically to your original remote. Simply press the corresponding button to activate your garage door or gate opener.

Brands & Models Not Compatible with XIHADA

1	Chamberlain / Liftmaster Security 2.0 Garage Door Opener	2	Chamberlain / Liftmaster 2.0+ Garage Door Opener
3	Chamberlain Garage door Opener with MYQ System	4	Liftmaster Garage Door Opener with MYQ System
5	LiftMaster 8500W Garage Door Opener	6	Liftmaster 892 LT
7	LiftMaster 811 LMX	8	LiftMaster 893 LM
9	Chamberlain B 6713T Garage Door Opener	10	Chamberlain B 6753T Smart Garage Door Opener
11	Genie Pro Screw Drive	12	AccessMaster garage with MyQ
13	Door king System / DKS Gate Opener	14	Stanley
15	Condo's garage door opener	16	Ryobi
17	Softens Doors	18	Blue Sea
19	Allister	20	Amarr
21	Atoms	22	Merik
23	Lynx	24	Skylink
25	Wayne Dalton	26	Martin
27	Saco Gate Opener		

Figure 6: The remote in use, demonstrating its function in opening a garage door.



Figure 7: The universal remote can be used for various applications, including garage doors, entry gates, and other compatible systems.

Maintenance

Battery Replacement

The remote requires 1 CR2 battery (included). To replace the battery:

1. Locate the small slot on the back of the remote.
2. Carefully insert a thin object (like a credit card tip or small screwdriver) into the slot and gently pry open the remote casing.
3. Remove the old CR2 battery and insert a new one, ensuring correct polarity.
4. Snap the remote casing back together firmly.



Figure 8: Illustration of the battery compartment and the CR2 battery used in the remote.

Troubleshooting

- **Remote not programming:** Ensure your original remote is working correctly. Verify that your original remote's brand and model are not on the non-compatible list (Figure 5). Make sure the remotes are positioned correctly and close enough during the cloning process.
- **Garage door opener not responding after programming:** For rolling code systems, ensure you have completed the 'LEARN' button step on your garage door opener's receiver. Refer to your garage door opener's manual for specific 'LEARN' button procedures.
- **Short range:** Check the battery level of the universal remote. Ensure there are no obstructions between the remote and the receiver.

Specifications

- **Product Dimensions:** 2.36 x 1.38 x 0.39 inches
- **Item Weight:** 1.34 ounces
- **Model Number:** ML999-06
- **Battery:** 1 CR2 battery (included)
- **Frequency Range:** Multi-frequency 280MHz-868MHz
- **Max Number of Supported Devices:** 1 (per button, up to 4 buttons)
- **Compatible Devices:** Garage Doors, Gates (check compatibility lists)

Warranty and Support

For warranty information or technical support, please contact the manufacturer, Xiamen Xihada Information Technology Co., Ltd, or refer to the product's official Amazon listing page for current support details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07S77H69C

More documents and user manuals: **https://manuals.plus/**