MMOBIEL Huawei P30 Lite 6.15 inch 2019

MMOBIEL Dual SIM Card Slot Tray Holder Replacement User Manual

Model: Huawei P30 Lite New Edition 2020

Brand: MMOBIEL

1. Introduction

This user manual provides detailed instructions for the installation and use of the MMOBIEL Dual SIM Card Slot Tray Holder, designed as a replacement part for the Huawei P30 Lite New Edition 2020. This kit includes the necessary components to replace a damaged or lost SIM card tray, ensuring proper functionality of your device's SIM card and memory card slots.
The comprehensive repair kit is intended for easy installation, allowing users to perform the replacement without requiring professional technical assistance.

2. Compatibility

This replacement SIM card tray is specifically compatible with the **Huawei P30 Lite New Edition MARIE-L21BX 2020**. It is crucial to verify your device's model number before attempting installation to ensure proper fit and function. The model type can typically be found in your device's settings or on the device itself.



Image: This diagram illustrates the compatibility of the SIM tray. It is compatible with the Huawei P30 Lite, but not with the Huawei P30 or P30 Pro models.

3. Package Contents

The MMOBIEL Dual SIM Card Slot Tray Holder Replacement kit includes the following items:

- 1 x Dual SIM Card Slot Tray Holder (Midnight Black)
- 1 x SIM Ejector Pin Tool




Image: The complete kit, showing the dual SIM card tray and the included SIM ejector pin.

4. Installation Guide

Follow these steps to safely replace the SIM card tray in your Huawei P30 Lite New Edition 2020:

1. **Power Off Device:** Before beginning, ensure your Huawei P30 Lite is completely powered off to prevent any damage during the process.
2. **Locate SIM Tray Slot:** Identify the SIM card tray slot on the side of your phone.
3. **Eject Old Tray:** Insert the tip of the provided SIM ejector pin into the small hole next to the SIM card tray slot. Apply gentle, steady pressure until the tray pops out slightly.



Image: The SIM ejector pin, used to open the SIM card tray.

4. **Remove Old Tray:** Carefully pull out the old SIM card tray from the slot.
5. **Transfer SIM/SD Cards:** If your old tray contained SIM cards or a microSD card, carefully remove them and place them into the corresponding slots on the new MMOBIEL Dual SIM Card Tray. Ensure they are seated correctly and securely.




Image: The replacement dual SIM card tray, ready for SIM and SD card insertion.

6. **Insert New Tray:** Align the new tray with the slot and gently push it back into the phone until it sits flush with the device's frame. Do not force it.
7. **Power On Device:** Once the new tray is securely in place, power on your Huawei P30 Lite.
8. **Verify Functionality:** Check if your SIM cards are recognized and if cellular service is available. Test calls, messages, and data connectivity.

5. Operating Instructions

The MMOBIEL Dual SIM Card Tray allows for the simultaneous use of two Nano-SIM cards or one Nano-SIM card and one microSD card (depending on your phone's configuration and the tray design). Ensure that your SIM cards are correctly oriented within the tray before insertion into the phone.

- **SIM Card Orientation:** Most SIM trays have an angled corner to guide correct insertion. Match the angled corner of your SIM card to the tray.
- **Secure Fit:** Ensure SIM cards and microSD cards lie flat and securely within their designated slots in the tray before re-inserting into the phone. This prevents damage to the cards or the phone's internal components.

6. Maintenance

To ensure the longevity and proper function of your SIM card tray:

- **Handle with Care:** Always use the provided SIM ejector pin or a similar thin, non-sharp tool to open the tray. Avoid using excessive force or sharp objects that could damage the tray or the phone's slot.
- **Keep Clean:** Periodically inspect the tray for dust or debris. Clean gently with a soft, dry cloth if necessary. Avoid liquids.
- **Store Safely:** If the tray is removed for an extended period, store it in a clean, dry, and safe place to prevent loss or

damage.

7. Troubleshooting

If you encounter issues after replacing the SIM card tray, consider the following:

Problem	Possible Cause	Solution
SIM card not recognized	SIM card not seated correctly; tray not fully inserted; incompatible SIM card.	Remove and re-insert SIM card, ensuring correct orientation and secure fit. Push tray fully into slot. Verify SIM card is active and compatible.
Tray does not fit or is difficult to insert	Incorrect model tray; obstruction in slot; tray misaligned.	Double-check your phone's model number against the product compatibility. Inspect the slot for debris. Ensure the tray is aligned correctly before pushing. Do not force.
No cellular service after replacement	SIM card not recognized; network settings issue.	Refer to "SIM card not recognized" solution. Restart phone. Check phone's network settings. Contact your mobile carrier if issues persist.

8. Specifications

- **Product Type:** Dual SIM Card Slot Tray Holder Replacement
- **Compatibility:** Huawei P30 Lite New Edition MARIE-L21BX 2020 (also referred to as Huawei P30 Lite 6.15 inch 2019)
- **Color:** Midnight Black
- **Material:** Durable plastic/metal composite
- **Package Dimensions:** 3.23 x 1.97 x 0.31 inches
- **Item Weight:** 0.634 ounces
- **Included:** SIM Ejector Pin

9. Support

MMOBIEL is committed to providing high-quality products and customer satisfaction. If you encounter any issues or have questions regarding the installation or functionality of your MMOBIEL Dual SIM Card Slot Tray Holder, please refer to the product listing or contact MMOBIEL customer support for assistance.
For more information about MMOBIEL products and services, you can visit the official MMOBIEL store on Amazon:MMOBIEL Store.

© 2025 MMOBIEL. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question