

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [INTEMPO](#) /

› [INTEMPO Black Bluetooth Sphere Speaker User Manual](#)

INTEMPO Sphere

INTEMPO Black Bluetooth Sphere Speaker

USER MANUAL

Introduction

This manual provides essential information for the safe and efficient operation of your INTEMPO Black Bluetooth Sphere Speaker. Please read this manual thoroughly before using the product and retain it for future reference. The Intempo Sphere Speaker is a compact and portable audio device designed to connect wirelessly via Bluetooth to your smartphone, tablet, or MP3 player, allowing you to enjoy your music anywhere.

Package Contents

- INTEMPO Black Bluetooth Sphere Speaker
- USB Charging Cable
- AUX Cable



Image: The INTEMPO Black Bluetooth Sphere Speaker, along with its included USB charging cable and AUX cable, as typically found in the product packaging.

Setup

1. Charging the Speaker

Before first use, fully charge the speaker.

1. Connect the small end of the supplied USB charging cable to the charging port on the speaker.
2. Connect the large end of the USB charging cable to a suitable USB power adapter (not supplied) or a computer's USB port.

3. The charging indicator light will illuminate. Once fully charged, the light may change color or turn off, depending on the model.
4. A full charge provides approximately 2 hours of playtime.

2. Powering On/Off

- To power on, press and hold the power button until an indicator light illuminates or an audible prompt is heard.
- To power off, press and hold the power button again until the indicator light turns off or an audible prompt is heard.

Operating Instructions

1. Bluetooth Pairing

The speaker will automatically enter Bluetooth pairing mode when powered on for the first time or if no device is connected.

1. Ensure the speaker is powered on and within 10 meters (33 feet) of your Bluetooth-enabled device.
2. Enable Bluetooth on your device (smartphone, tablet, MP3 player).
3. Search for available Bluetooth devices. The speaker will appear as "INTEMPO SPHERE" or similar.
4. Select the speaker from the list to initiate pairing.
5. Once successfully paired, the speaker will indicate connection with a sound or a steady indicator light.
6. The speaker will automatically attempt to reconnect to the last paired device when powered on.

2. AUX Mode

Use the supplied AUX cable to connect non-Bluetooth devices.

1. Connect one end of the 3.5mm AUX cable to the AUX input port on the speaker.
2. Connect the other end of the AUX cable to the headphone jack or audio output of your device.
3. The speaker should automatically switch to AUX mode. If not, check the speaker's mode button (if available).
4. Control playback and volume directly from your connected device.

3. Audio Playback

Once connected via Bluetooth or AUX, play audio from your source device.

- Adjust volume using the controls on your connected device.
- The speaker's output is 3W, providing clear sound for its size.

Maintenance

- **Cleaning:** Wipe the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use for extended periods.
- **Water Exposure:** This speaker is not waterproof. Avoid exposure to water or excessive moisture.

Troubleshooting

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Speaker does not power on.	Battery is depleted.	Charge the speaker fully using the supplied USB cable.
Cannot pair via Bluetooth.	Bluetooth is off on device; speaker is out of range; speaker is already paired to another device.	Ensure Bluetooth is enabled on your device. Move device closer to speaker (within 10m). Disconnect speaker from any other paired devices.
No sound from speaker.	Volume too low; incorrect mode selected; device not playing audio.	Increase volume on your connected device. Ensure speaker is in the correct mode (Bluetooth/AUX). Verify audio is playing on your source device.
Poor audio quality.	Device too far from speaker (Bluetooth); interference; low battery.	Move device closer to speaker. Avoid obstacles between speaker and device. Charge the speaker.

Specifications

Brand	INTEMPO
Model Name	Sphere
Connectivity Technology	Bluetooth
Bluetooth Version	2.1 + EDR
Wireless Range	10 meters (33 feet)
Speaker Output	3 Watts
Audio Output Mode	Stereo
Power Source	Built-in Rechargeable Battery
Playtime	Approx. 2 hours
Color	Black
Dimensions (approx.)	8cm (diameter)
Mounting Type	Tabletop
Compatible Devices	MP3 Player, Tablet, Smartphone

Warranty and Support

Specific warranty information is typically provided with your purchase documentation or on the manufacturer's official website. Please refer to the packaging or the retailer's website for details regarding warranty coverage and how to claim it. For technical support or further assistance, please contact the manufacturer, Intempo, or your point of purchase. Contact details can usually be found on the product packaging or their official website.



