

OMOTON OM-Keyboard-KB066-Grey

OMOTON Bluetooth Keyboard User Manual

Model: OM-Keyboard-KB066-Grey

Brand: OMOTON

1. INTRODUCTION

This manual provides comprehensive instructions for the OMOTON Ultra-Slim Bluetooth Keyboard (Model: OM-Keyboard-KB066-Grey). Designed for seamless connectivity with various Bluetooth-enabled devices, particularly iPads, this keyboard offers a comfortable and efficient typing experience. Please read this manual thoroughly before using the product to ensure proper operation and longevity.

What's in the Box:

- OMOTON Bluetooth Keyboard
- User Manual

2. FEATURES

- **Cable-Free Bluetooth Connection:** Connects wirelessly to mobile devices such as tablets and mobile phones, offering convenience with an operating distance of up to 10 meters.
- **Super Compatibility:** Compatible with iPads (10th, 9th, 8th, 7th Generation, Pro 13/12.9/11 inch, Air/Mini), Phones, and other Bluetooth-enabled tablets, laptops, and mobile phones.
- **Reasonable Layout:** Features a QWERTY layout with hotkeys customized for iPads, including volume control, music control, and brightness adjustment.
- **Long Battery Life:** Provides up to 30 days of continuous use and features an automatic sleep mode, allowing for up to half a year between battery changes. (Requires 2 X AAA Batteries, Not Included).
- **Perfect Size:** Designed to be large enough for comfortable typing yet compact enough for portability in a suitcase or handbag.



Figure 2.1: Top-down view of the OMOTON Ultra-Slim Bluetooth Keyboard.



Figure 2.2: The OMOTON Bluetooth Keyboard positioned next to an iPad on a stand, demonstrating a typical setup.



Figure 2.3: Top and bottom views of the keyboard, showing the sleek design and battery compartment.

3. SETUP AND PAIRING

Follow these steps to set up your OMOTON Bluetooth Keyboard and pair it with your device.

3.1 Battery Installation

The keyboard requires 2 AAA batteries (not included) for operation.

1. Locate the battery compartment on the underside of the keyboard.
2. Open the battery compartment cover.
3. Insert 2 AAA batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.



Figure 3.1: Keyboard dimensions: 11.2 inches (284.5mm) length, 4.7 inches (119.4mm) width, and 0.2 inches (5.1mm) thickness.

3.2 Bluetooth Pairing Process

To pair the keyboard with your device, follow these steps:

1. Slide the power switch on the keyboard from **OFF** to **ON**.
2. Double-click the **"Connect"** button or press and hold it for 2-3 seconds to activate pairing mode. The Bluetooth indicator light on the keyboard will blink.
3. On your iPad or Bluetooth-enabled device, go to **Settings > Bluetooth**.
4. Ensure Bluetooth is turned **ON**. Your device will search for nearby Bluetooth devices.
5. From the list of available devices, select **"Bluetooth Keyboard"** to connect.
6. If prompted, enter the PIN code displayed on your device's screen using the OMOTON keyboard, then press the **"Enter"** key.
7. Once connected, the Bluetooth indicator light on the keyboard will stop blinking, and your device will show "Connected" next to "Bluetooth Keyboard".

Your browser does not support the video tag.

Video 3.1: Official OMOTON video demonstrating the setup and pairing process for the Ultra-Slim Bluetooth Keyboard.

4. OPERATING INSTRUCTIONS

The OMOTON Bluetooth Keyboard features a standard QWERTY layout with additional function keys for enhanced productivity, especially with iPadOS/iOS devices.

4.1 Function Keys (Hotkeys)

The top row of keys (F1-F12) serves as hotkeys for quick access to various functions. These are optimized for iPadOS/iOS:

- **F1 (Home):** Returns to the home screen.
- **F2 (Brightness Down):** Decreases screen brightness.
- **F3 (Brightness Up):** Increases screen brightness.
- **F4 (Search):** Activates the search function.
- **F5 (Keyboard Hide/Show):** Toggles the on-screen keyboard.
- **F7 (Previous Track):** Skips to the previous music track.
- **F8 (Play/Pause):** Plays or pauses music/video.
- **F9 (Next Track):** Skips to the next music track.
- **F10 (Mute):** Mutes audio output.
- **F11 (Volume Down):** Decreases volume.
- **F12 (Volume Up):** Increases volume.
- **Del (Delete):** Deletes characters.

Optimized Multimedia Keys

All there Function Keys Designed
for iPad OS/ iOS



Figure 4.1: The keyboard features optimized multimedia keys designed for iPad OS/iOS.



Compatible with iPad OS

Provide you smooth and precise typing experience

-  Compatible with iPads
-  Optimized Keys
-  Scissor Mechanism
-  Long Battery Life

Figure 4.2: The keyboard is fully compatible with iPad OS, providing a smooth and precise typing experience.

Komfort-Taste



Figure 4.3: Close-up view highlighting the stable scissor structure beneath the keys, designed for comfortable and responsive typing.



Figure 4.4: The keyboard's broad compatibility with different Bluetooth-enabled devices, including various iPad and iPhone models.

5. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your OMOTON Bluetooth Keyboard.

- **Cleaning:** Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution to wipe the surface of the keyboard. Avoid excessive moisture.
- **Dust Removal:** Use compressed air to remove dust and debris from between the keys.
- **Storage:** When not in use, store the keyboard in a dry, cool place away from direct sunlight and extreme temperatures. Consider using a protective sleeve or case for travel.
- **Battery Care:** If the keyboard will not be used for an extended period, remove the AAA batteries to prevent leakage and potential damage.



Multiple Colors To Choose From

Different tablet colors? No worry there is always a color matches your device

Figure 5.1: The keyboard is available in multiple colors, allowing users to choose one that matches their device or preference.

6. TROUBLESHOOTING

If you encounter issues with your OMOTON Bluetooth Keyboard, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Keyboard does not turn on.	Low or dead batteries; Power switch is OFF.	Replace batteries with new ones. Ensure the power switch is in the ON position.
Cannot pair the keyboard.	Bluetooth not enabled on device; Keyboard not in pairing mode; Device too far.	Ensure Bluetooth is ON in your device's settings. Press the "Connect" button on the keyboard to enter pairing mode. Move the keyboard closer to your device (within 10 meters).
Keyboard disconnects frequently.	Low battery; Interference; Device going to sleep.	Replace batteries. Minimize interference from other wireless devices. Some devices may disconnect Bluetooth accessories when idle; adjust device power settings if possible.
Keys are not responding or typing incorrectly.	Low battery; Software glitch; Physical damage.	Replace batteries. Restart both the keyboard and your device. Ensure no debris is lodged under the keys.

7. SPECIFICATIONS

Attribute	Detail
Product Dimensions	11.22 x 4.72 x 0.24 inches (284.5 x 119.4 x 5.1 mm)
Item Weight	12.7 ounces (360 grams)
Manufacturer	OMOTON
ASIN	B07S7VPQG6
Country of Origin	China
Item Model Number	OM-Keyboard-KB066-Grey
Batteries Required	2 x AAA batteries (Not Included)
Connectivity Technology	Bluetooth
Keyboard Description	Wireless
Color	Grey
Number of Keys	78
Special Feature	Portable, Hotkeys and Media Keys
First Available Date	March 26, 2018

8. WARRANTY AND SUPPORT

Specific warranty details for the OMOTON Bluetooth Keyboard are not provided in this manual. For warranty information, technical support, or any product-related inquiries, please contact OMOTON customer service directly through their official website or the retailer where the product was purchased.

You can typically find contact information on the OMOTON brand's official website or by searching for "OMOTON customer support" online.

© 2025 OMOTON. All rights reserved.

This manual is for informational purposes only. Product specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question