

[Manuals.plus](#) /

› [sleek socket](#) /

› Sleek Socket Ultra-Thin Outlet Concealer User Manual

sleek socket 3-M-OVSZ-W

Sleek Socket Ultra-Thin Outlet Concealer User Manual

Model: 3-M-OVSZ-W

1. PRODUCT OVERVIEW

The Sleek Socket is an innovative, ultra-thin outlet concealer designed to discreetly hide unsightly plugs and cords, transforming your living space by reducing clutter and enhancing safety. This device allows furniture to sit flush against walls, optimizing room usage. It functions as a flat extension cord with multiple outlets, providing a practical and aesthetic solution for managing electrical connections.





Image 1.1: The Sleek Socket, demonstrating its ultra-thin design and integrated 3-outlet power strip.

2. SAFETY INFORMATION

Your safety is paramount. Please read and understand all safety instructions before using the Sleek Socket.

- This Sleek Socket product is certified as specifically complying with UL Standard 817 (Safety Cord Sets and Power-Supply Cords).
- It is also certified as complying with its Canada counterpart standard, CSA C22.2 #21.
- Do not exceed the maximum electrical ratings: 13 Amps, 125 Volts, 1625 Watts.
- Ensure the product is used only with standard duplex outlets where the round ground pin is located below the flat pins.
- Do not use in wet conditions or near water.
- Do not attempt to modify or disassemble the device.

3. PACKAGE CONTENTS

The Sleek Socket package includes the following components:

- 1 x Sleek Socket Ultra-Thin Outlet Concealer (3ft cord, 3-outlet power strip)
- Double-sided, removable adhesive strips
- Adhesive cord clips for cable management

4. COMPATIBILITY

The Sleek Socket is universally compatible with all standard duplex outlet sizes, including "standard," "mid-size," and "oversize" outlet covers. It is designed for use with outlets featuring a round ground pin below the flat pins.



Image 4.1: Visual guide for compatible outlet types. Ensure your outlet matches the compatible configurations shown.

5. SETUP AND INSTALLATION

Installation of the Sleek Socket is quick and requires no tools.

1. **Prepare the Outlet:** Ensure the outlet you intend to use is a standard duplex outlet with the ground pin facing downwards. Make sure the outlet is clean and dry.
2. **Attach the Sleek Socket:** Simply plug the Sleek Socket's ultra-thin plug into the top receptacle of your duplex outlet. It is designed to fit snugly and flush against the wall.
3. **Secure the Cord:** Use the provided double-sided, removable adhesive strips to secure the Sleek Socket's main unit to the wall, directly over your existing outlet.
4. **Manage the Cable:** Utilize the adhesive cord clips to neatly secure the flat extension cord along the wall or baseboard, guiding it to your desired location. This helps maintain a clean, organized appearance and prevents tripping hazards.



Image 5.1: Before and after installation in a kitchen, showing how the Sleek Socket conceals cords and allows appliances to sit closer to the wall.



Image 5.2: Before and after installation behind a nightstand, illustrating improved aesthetics and furniture placement.




Image 5.3: Before and after installation in a desk area, showing how the Sleek Socket helps organize cables and allows furniture to be flush with the wall.



Image 5.4: Before and after installation behind a cabinet, demonstrating effective cord concealment.

6. OPERATION

Once installed, the Sleek Socket operates like a standard power strip, providing three additional outlets for your devices.

- Plug your electronic devices into the three available outlets on the power strip.
- Ensure that the total power consumption of all connected devices does not exceed the maximum ratings (13 Amps, 125 Volts, 1625 Watts).

7. CORD MANAGEMENT

The Sleek Socket includes a cord management kit to help keep your space tidy and safe.

- Use the provided adhesive cord clips to route the flat extension cord along baseboards, behind furniture, or around corners.
- The flat design of the cord allows it to be easily hidden and minimizes its visual impact.



Image 7.1: Detailed view of the flat cord and how it can be managed along surfaces.

8. TECHNICAL SPECIFICATIONS

Feature	Specification
Model Number	3-M-OVSZ-W
Cord Length	3 feet
Total Power Outlets	3
Maximum Amps	13A
Maximum Volts	125V
Maximum Watts	1625W
Product Dimensions	4.76 x 1.02 x 0.04 inches
Item Weight	5.8 ounces
Color	White
Safety Certifications	UL Standard 817, CSA C22.2 #21

9. CARE AND MAINTENANCE

The Sleek Socket is designed for minimal maintenance. To ensure optimal performance and longevity:

- Keep the device clean and free from dust. Wipe with a dry cloth if necessary.
- Avoid exposing the device to moisture or extreme temperatures.
- Do not place heavy objects on the cord or the main unit.
- Regularly inspect the cord and plug for any signs of damage. If damage is found, discontinue use immediately.

10. TROUBLESHOOTING

If you encounter any issues with your Sleek Socket, please refer to the following common solutions:

- **No Power to Devices:**
 - Ensure the Sleek Socket is fully plugged into a functioning wall outlet.
 - Check if the wall outlet itself is receiving power by testing it with another device.
 - Verify that the total wattage of connected devices does not exceed 1625W.
- **Cord Not Lying Flat:**
 - The cord may retain some memory from packaging. Gently straighten the cord and use the provided adhesive clips to secure it firmly against the wall. Applying light pressure for a period can help it flatten.
- **Product Appears Scuffed or Damaged:**
 - Minor scuffs may occur during shipping. If the product is significantly damaged or appears to have a factory defect, please refer to the Warranty and Support section for replacement information.

11. WARRANTY AND SUPPORT

Sleek Socket stands behind the quality of its products.

- We only sell products in 100% new condition.
- Any appearance of scuffed or damaged product may occur from the shipping process.
- We will replace product damaged during the shipment process.

For further assistance or to report a damaged product, please contact Sleek Socket customer support. Refer to the official Sleek Socket website or your purchase documentation for contact details.

© 2025 Sleek Socket. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question