Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

esonstyle S8

Esonstyle Sleep Headphones User Manual

Model: S8

1. Introduction

Thank you for choosing Esonstyle Sleep Headphones. These headphones are designed to provide a comfortable audio experience, especially for side sleepers, while offering passive noise reduction to help create a tranquil environment. Featuring Bluetooth 5.3 connectivity and a compact design, they are ideal for relaxation, travel, and improving sleep quality.

2. Safety Information

- Do not expose the device to extreme temperatures or humidity.
- Avoid dropping or subjecting the headphones to strong impacts.
- Do not disassemble or attempt to repair the device yourself. This will void the warranty.
- Keep out of reach of children and pets.
- Use only the provided charging cable or a certified equivalent.
- Prolonged listening at high volumes may cause hearing damage. Adjust volume to a safe level.

3. Package Contents

Please check the package for the following items:

- Esonstyle Sleep Headphones (Earbuds)
- Charging Case
- USB-C Charging Cable
- User Manual

4. Product Overview



Image Description: This image displays two main components of the Esonstyle product. On the left, there is a pair of purple over-ear headphones with cat ears that light up, featuring black earcups and white accents. On the right, there is a compact, light purple charging case for sleep earbuds, shown open with two small, light purple earbuds inside. A single, detached sleep earbud is also visible next to the open case. This manual focuses on the sleep earbuds.

The Esonstyle Sleep Headphones system consists of ultra-compact earbuds designed for comfort, especially during sleep, and a portable charging case. The earbuds feature a low-profile design to minimize pressure when lying on your side.

5. Setup

5.1 Charging the Headphones and Case

Before first use, fully charge the charging case and earbuds.

1. Connect the USB-C charging cable to the charging port on the case.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The indicator lights on the case will show charging status. A full charge typically takes approximately 1.5 hours for

the case.

4. Place the earbuds into the charging case. They will automatically begin charging. The earbuds provide up to 4 hours of music playback on a single charge, and the case extends this to approximately 24 hours.

5.2 Bluetooth Pairing

To connect your Esonstyle Sleep Headphones to your device:

1. Ensure the earbuds are charged and placed in the charging case.
2. Open the charging case. The earbuds will automatically enter pairing mode.
3. On your device (smartphone, tablet, etc.), enable Bluetooth.
4. Search for "Esonstyle S8" or a similar name in the list of available Bluetooth devices.
5. Select the device name to connect. Once connected, you will hear a confirmation tone, and the earbuds' indicator lights will change.
6. The headphones will automatically reconnect to the last paired device when taken out of the case, if Bluetooth is enabled on the device.

6. Operating Instructions

6.1 Wearing the Headphones

The Esonstyle Sleep Headphones are designed for a secure and comfortable fit, especially for side sleepers.

- Gently insert each earbud into your ear canal.
- Adjust the earbud until it sits snugly and comfortably, ensuring the low-profile design is flush with your ear. This minimizes pressure when lying down.
- The passive noise reduction feature works best when the earbuds form a good seal in your ear.

6.2 Basic Controls

The earbuds feature touch controls for easy operation:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud during an incoming call.
- **Reject Call:** Press and hold either earbud for 2 seconds during an incoming call.
- **Activate Voice Assistant:** Triple tap on either earbud.
- **Volume Control:** (If supported by model) Long press on right earbud for volume up, long press on left earbud for volume down.

7. Maintenance

7.1 Cleaning

- Wipe the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use harsh chemicals, cleaning solvents, or strong detergents.
- Regularly clean the ear tips and mesh to prevent wax buildup, which can affect sound quality.

7.2 Storage

When not in use, store the headphones in their charging case to protect them from dust and damage.

7.3 Water Resistance (IPX6)

The earbuds are rated IPX6 water-resistant, meaning they can withstand high-pressure water jets from any direction. This makes them suitable for use during exercise or in light rain. However, they are not designed for submersion in water. Do not use them while swimming or showering.

8. Troubleshooting

Problem	Possible Cause	Solution
Headphones do not turn on.	Low battery.	Place earbuds in the charging case and ensure the case is charged.
Cannot pair with device.	Bluetooth is off on device; earbuds not in pairing mode; too far from device.	Ensure Bluetooth is enabled on your device. Open the charging case to enter pairing mode. Move closer to your device. Try forgetting the device on your phone and re-pairing.
No sound or low volume.	Volume too low; earbuds not properly seated; earwax buildup.	Increase volume on your device. Adjust earbuds for a proper seal. Clean ear tips and mesh.
Intermittent connection.	Interference; too far from device; low battery.	Move closer to your device. Avoid areas with strong Wi-Fi or other Bluetooth signals. Ensure earbuds and case are charged.

9. Specifications

Feature	Detail
Model Name	S8
Connectivity Technology	Wireless (Bluetooth 5.3)
Ear Placement	In-Ear (Intraurales)
Battery Life (Earbuds)	Up to 4 hours
Battery Life (with Charging Case)	Approximately 24 hours
Charging Time	Approx. 1.5 hours (case)
Water Resistance Rating	IPX6
Material	Acrylonitrile Butadiene Styrene (ABS)
Impedance	32 Ohm

10. Warranty and Support

Esonstyle products are designed for durability and performance. While specific warranty details may vary by region, Esonstyle typically offers a quality guarantee for its products. For any issues, questions, or support needs, please contact Esonstyle customer service through the platform where you purchased the product or visit the official Esonstyle website for contact information.
Please retain your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question