

**KUPPET 1022002900#kuus**

# KUPPET Compact Refrigerator User Manual

Model: 1022002900#kuus

Brand: KUPPET

## 1. PRODUCT OVERVIEW

The KUPPET Compact Refrigerator is a versatile 3.2 Cu.Ft appliance designed for various settings such as dorms, garages, campers, basements, or offices. It features a convenient double-door design, separating the refrigerator and freezer compartments for optimal food preservation.



Front view of the KUPPET Compact Refrigerator, showcasing its sleek black finish and double-door design.

- **Sleek Design:** Compact and space-saving, suitable for various environments. Dimensions: 19.1 W x 33.5 H x 20.1 D inches.

- **2-Door Design:** Separate compartments for refrigeration and freezing, allowing for stratified storage of fruits, vegetables, drinks, eggs, ice cream, and other items.
- **Low Noise Operation:** Engineered to operate at less than 40 dB, ensuring a quiet environment.
- **Precise Temperature Control:** Features accurate temperature control with compensation function to maintain food freshness consistently.
- **Reversible Door:** The door can be configured to open from either the left or right side, offering flexible placement options. It includes storage for canned drinks and a compartment for larger bottles.

## 2. SAFETY INFORMATION

---

Please read all safety instructions carefully before operating the appliance to prevent injury or damage.

- **Electrical Safety:** Ensure the refrigerator is connected to a grounded power outlet with the correct voltage (115 Volts). Do not use extension cords or ungrounded adapters.
- **Ventilation:** Allow adequate space around the refrigerator for proper air circulation (refer to setup section for specific dimensions). Blocking vents can lead to overheating and reduced efficiency.
- **Flammable Materials:** Do not store explosive substances or flammable materials inside or near the refrigerator.
- **Child Safety:** This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Supervise children to ensure they do not play with the appliance.
- **Disposal:** When disposing of the refrigerator, remove the doors and leave shelves in place to prevent children from becoming trapped. Dispose of the appliance according to local regulations for refrigerants and insulation materials.

## 3. SETUP AND INSTALLATION

---

### 3.1 Unpacking

Carefully remove all packaging materials, including tape and protective films. Keep packaging materials out of reach of children. Inspect the refrigerator for any shipping damage.

### 3.2 Placement

- Place the refrigerator on a firm, level surface away from direct sunlight or heat sources (e.g., stove, heater).
- Ensure there is adequate clearance around the unit for proper ventilation: at least 4 inches (10 cm) at the back and sides, and 12 inches (30 cm) at the top.
- The appliance is designed for tabletop installation.




Diagram showing the dimensions of the KUPPET Compact Refrigerator: 19.1" W x 33.5" H x 21.9" D. The freezer compartment is 0.93 Cu.Ft and the fridge compartment is 2.24 Cu.Ft.

### 3.3 Leveling

The refrigerator has adjustable feet. Use a wrench to adjust the feet to ensure the unit is level. A level appliance operates more efficiently and prevents door alignment issues.

### 3.4 Initial Power-On

After placing the refrigerator, wait at least 2-4 hours before plugging it into a power outlet. This allows the refrigerant to settle. Once plugged in, allow the unit to cool for several hours before loading food.

### 3.5 Reversible Door Installation

The refrigerator's door hinges are reversible, allowing you to change the door swing direction to suit your space. Refer to the detailed instructions in the full user manual (link provided in Section 7) for the step-by-step process of reversing the door.

## 4. OPERATING INSTRUCTIONS

### 4.1 Temperature Control

The refrigerator features a 5-level temperature control dial located inside the fresh food compartment. Turn the

dial to adjust the cooling intensity. Higher numbers indicate colder temperatures. Start with a medium setting (e.g., 3) and adjust as needed based on ambient temperature and food load.

## LOCK FOOD IN NUTRITION



5 Level Temp Control



Removable Basket & Shelf



Fully Sealed Door

Close-up view of the interior, highlighting the 5-level temperature control dial, removable basket, and shelves, and the fully sealed door.

### 4.2 Internal Storage

- **Refrigerator Compartment:** Ideal for fresh foods, beverages, and dairy products. It includes glass shelves and a fruit and vegetable box for organized storage.
- **Freezer Compartment:** Designed for frozen items like ice cream and pre-packaged frozen meals.
- **Door Storage:** The reversible door provides convenient storage for canned drinks and larger bottles.



Interior view of the KUPPET Compact Refrigerator, demonstrating its storage capacity with various food items and beverages.

## 5. MAINTENANCE

### 5.1 Cleaning

- Always unplug the refrigerator before cleaning.
- Clean the interior and exterior surfaces with a soft cloth and a mild detergent solution. Avoid abrasive cleaners or solvents.
- Wipe down door gaskets regularly to ensure a tight seal.
- The shelves are removable for easy cleaning.

### 5.2 Defrosting

This refrigerator features an automatic defrost system for the fresh food compartment. The freezer compartment may require manual defrosting if ice buildup becomes excessive. To defrost the freezer, unplug the unit, remove all food, and allow the ice to melt naturally. Place towels to absorb water. Do not use sharp objects to remove ice.

## 6. TROUBLESHOOTING

Before contacting customer support, please refer to the following common issues and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Refrigerator does not operate.	Not plugged in; circuit breaker tripped; temperature control set to "OFF".	Check power cord connection; reset circuit breaker; adjust temperature control.
Temperature is not cold enough.	Door opened too frequently; warm food added; poor ventilation; temperature control set too high.	Minimize door openings; allow warm food to cool before placing inside; ensure proper clearance; adjust temperature control to a colder setting.
Excessive noise.	Refrigerator is not level; parts are loose; normal operating sounds.	Adjust leveling feet; check for loose components; gurgling or humming sounds are normal. The unit operates at less than 40 dB.
Door does not close properly.	Refrigerator is not level; gasket is dirty or damaged; food packages blocking door.	Adjust leveling feet; clean or replace gasket; rearrange food items.

## 7. SPECIFICATIONS

Feature	Detail
Brand Name	KUPPET
Model Number	1022002900#kuus
Item Weight	52.9 pounds
Product Dimensions	19.1 x 20.1 x 33.5 inches
Capacity	3.2 Cubic Feet
Installation Type	Tabletop
Form Factor	Compact
Special Features	Adjustable feet, Adjustable thermostat, LED lighting, Fruit and vegetable box, Magnetic sealing door, Reversible door
Color	Black
Voltage	115 Volts
Defrost Type	Automatic (for fresh food compartment)
Door Hinges	Reversible
Shelf Type	Glass
Number of Shelves	3
First Available Date	May 28, 2019

