

[Manuals.plus](#) /

› [WONNIE](#) /

› WONNIE 10.5" Dual Screen Car DVD Players Instruction Manual

WONNIE SMJ1011

WONNIE 10.5" Dual Screen Car DVD Players Instruction Manual

Model: SMJ1011

Brand: WONNIE

INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your WONNIE 10.5" Dual Screen Car DVD Players. Designed for in-car entertainment, these portable DVD players offer versatile playback options for a comfortable viewing experience on the go.

WHAT'S IN THE BOX

- 2 x DVD Player for Car
- 2 x Mounting Brackets
- 2 x Headrest Straps
- 2 x AC Adapter
- 1 x 2-in-1 Car Charger
- 1 x AV Signal Cable
- 1 x RCA Cable



This image displays all the components included in the WONNIE dual DVD player package, ensuring you have everything needed for installation and operation.


SETUP

Mounting the Players

The WONNIE dual DVD players can be easily mounted to car headrests using the provided brackets or straps.

LAST MEMORY FUNCTION

Start from where you left off



This visual guide illustrates the process of attaching the DVD player to the car headrest. First, secure the bracket to the headrest posts, then slide the player onto the bracket, ensuring a firm fit.

OPERATING INSTRUCTIONS

Powering On/Off

To power on the device, press the power button located on the top edge of the player. To power off, press and hold the power button.

Disc Playback

Open the disc cover by sliding the release button on the top. Insert your DVD or CD disc with the label side facing up. Close the cover firmly. The player will automatically begin loading the disc.

MULTIPLE FORMATS SUPPORTED

**Region Free: Play Various DVD/CD Discs and
Media Files from Any Region**



DVD Formats: DVD, DVD+R, DVD-R, DVD+RW, DVD-RW, CD, CD+R, CD-R, CD+RW, CD-RW, VCD, SVCD (Blu-Ray not Support)



Video Formats: VOB, AVI, MPEG1, MPEG2, XVID



Audio Formats: MP3, WMA



Image Formats: JPG, JPEG




This image shows both DVD players actively playing content, highlighting their ability to play various DVD and CD formats, as well as media from USB/SD cards.

Dual Screen Functionality

The dual screen system allows for two modes of operation:

- **Independent Playback:** Each player can play a different movie simultaneously.
- **Synchronized Playback:** Connect the two players using the supplied AV cable to play the same movie on both screens. Connect

the AV OUT of the main player to the AV IN of the secondary player.



Sync to Second Player
via AV cable(Included)

This image demonstrates the independent playback feature, where each screen can display unique content, perfect for multiple viewers with different preferences.



Sync to a Larger TV Screen
via RCA cable(Included)

This image illustrates how to connect the two players using the AV cable to synchronize playback, allowing both screens to display the same movie.

External Connectivity

The players support USB drives and SD/MMC cards up to 32GB for playing music and movies (max resolution 720*576 pixels). Each player also features a headphone jack for private listening or connecting external speakers.

Built-in Dual Stereo Speakers

Hearing Every Moment Loud and Clear



This image highlights the various input/output ports on the side of the DVD player, including USB, SD/MMC card slots, AV In/Out, and headphone jacks for versatile media playback and connectivity.


Last Memory Function

The players are equipped with a last memory function, which automatically resumes playback from where you left off, even after the device is powered off.

FEATURES OVERVIEW

- **High-Definition Display:** 10.5-inch HD 1280*800 pixel screens for clear visuals.

- **Region-Free Playback:** Supports DVD, DVD+R, DVD-R, DVD+RW, DVD-RW, CD, CD+R, CD-R, CD+RW, CD-RW, VCD, SVCD formats (Blu-Ray not supported).
- **Multi-Format Support:** Plays video formats (VOB, AVI, MPEG1, MPEG2), audio formats (MP3, WMA), and image formats (JPG, JPEG) from USB/SD/MMC cards.
- **Built-in Stereo Speakers:** Each unit includes two stereo speakers with individual volume control (0-20).
- **Multiple Power Modes:** Operates via 2 AC adapters, a 2-in-1 car charger (12V), and built-in rechargeable batteries providing up to 5 hours of playback.
- **Sync Screen to TV/Projector:** AV Out ports allow connection to larger displays for home viewing.
- **Upgraded Chip Technology:** Features enhanced chips for fast reading, noise cancellation, heat dissipation, and anti-shock performance.



This diagram details the wide range of formats supported by the DVD players, from traditional DVDs and CDs to digital files via USB and SD cards, ensuring broad compatibility.



This image highlights the integrated dual stereo speakers in each unit, designed to provide clear and immersive sound for an enhanced viewing experience.



Multiple Formats Supported

Play Various DVD/CD/VCD Discs and Support up to 32GB USB/SD/MMC Card

**Discs Formats:**
Free Regions Discs from: DVD, DVD+R, DVD-R, DVD+RW, DVD-RW, CD, CD+R, CD-R, CD+RW, CD-RW, VCD, SVCD (Blu-Ray not Support)

**Video Formats:**
VOB, AVI, MPEG1, MPEG2, XVID (Make sure it is supported formats and maximum resolution cannot exceed 720*576 pixels)

**Audio Formats:**
MP3, WMA

**Image Formats:**
JPG, JPEG

This graphic explains the flexible power options available, including a 5-hour rechargeable battery, a car charger for on-the-go power, and AC adapters for home use.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the screen and exterior. Do not use liquid cleaners or abrasive materials.
- **Disc Handling:** Always handle discs by their edges. Avoid touching the playing surface. Store discs in their cases when not in use.
- **Lens Care:** Do not touch the player's lens. Touching the lens may lead to the player being unable to read discs.
- **Storage:** When not in use, store the DVD players in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Problem	Solution
Player does not power on.	Ensure the power adapter or car charger is securely connected and providing power. Check battery level if operating on battery.
"No Disc" error or disc not reading.	Ensure the disc is clean and free of scratches. Reinsert the disc correctly. Do not touch the lens.
No sound or low volume.	Adjust the volume using the controls on the player or remote. Check headphone connection if applicable. Ensure external speakers are properly connected and powered.
Screens not syncing.	Verify the AV cable is correctly connected between the AV OUT of the main player and AV IN of the secondary player. Ensure both players are powered on.

SPECIFICATIONS

Feature	Detail
Product Dimensions	11.2 x 10.7 x 5.2 inches
Item Weight	5 pounds
Item Model Number	SMJ1011
Batteries	1 Lithium Metal batteries required (included)
Screen Size	10.5 Inches
Display Type	LCD

Feature	Detail
Media Type	DVD-R, DVD+R, DVD-RW, DVD+RW
Color	Black

WARRANTY AND SUPPORT

WONNIE provides a 1-year warranty time for quality-related issues from date of purchase.

For any technical support or product-related inquiries, please feel free to con-tact us via the "Get Product Support" on the Amazon website or after-sales email, we will reply as soon as possible within 24h.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07S9Z7997>

More documents and user manuals: <https://manuals.plus/>