

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [FABER](#) /

› [Faber 152 SRM LG A90 Built-in Hood User Manual](#)

FABER 152 SRM LG A90

Faber 152 SRM LG A90 Built-in Hood User Manual

Brand: FABER | **Model:** 152 SRM LG A90

1. INTRODUCTION

Thank you for choosing the Faber 152 SRM LG A90 Built-in Hood. This manual provides essential information for the safe installation, operation, and maintenance of your new kitchen appliance. Please read these instructions carefully before use and keep them for future reference.

1.1 Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury. Ensure the appliance is correctly installed and grounded by a qualified technician. Do not allow children to operate the hood. Clean the grease filters regularly to prevent fire hazards.

2. PACKAGE CONTENTS

Verify that all components are present in the packaging:

- Faber 152 SRM LG A90 Built-in Hood unit
- Synthetic Grease Filter (pre-installed or separate)
- Mounting hardware (screws, brackets)
- Instruction Manual (this document)

3. SETUP AND INSTALLATION

Installation should be performed by a qualified technician in accordance with local regulations and safety standards. Ensure the power supply is disconnected before beginning installation.

3.1 Mounting the Hood

The Faber 152 SRM LG A90 is a built-in hood designed for integration into kitchen cabinetry. Ensure adequate clearance above the cooking surface as specified by local regulations and the hood's technical specifications.




Image 1: Installation diagram showing dimensions and mounting points for the Faber 152 SRM LG A90 built-in hood. The diagram illustrates the hood's placement within a cabinet, indicating measurements for width, depth, and height, as well as the air outlet diameter.

3.2 Electrical Connection

Connect the hood to a grounded 220 Volt (AC) power supply. The electrical connection must comply with all local electrical codes. Do not use extension cords or adapters.

3.3 Ducting Connection

The hood is designed for exhaust ventilation. Connect the 120 mm diameter air outlet to an appropriate ducting system that vents outdoors. Ensure the ducting is free from obstructions and has minimal bends for optimal performance.

4. OPERATING INSTRUCTIONS

The Faber 152 SRM LG A90 hood features electromechanical controls for easy operation of its functions.



Image 2: The Faber 152 SRM LG A90 built-in hood shown installed under a kitchen cabinet. The image highlights its discreet design.

and the integrated LED lighting illuminating the cooking area.

4.1 Power On/Off

Press the power button to turn the hood on or off.

4.2 Fan Speed Selection

The hood offers three fan speeds to suit different cooking needs:

- **Speed 1:** For light cooking and simmering.
- **Speed 2:** For normal cooking.
- **Speed 3:** For heavy frying or strong odors.

Use the dedicated speed buttons to select the desired fan speed.

4.3 Lighting Control

Press the light button to turn the LED lighting on or off. The LED lights provide illumination for your cooking area.

5. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your hood.

5.1 Cleaning the Grease Filters

The hood is equipped with synthetic grease filters. These filters should be cleaned regularly, typically every 2-4 weeks depending on usage, to prevent grease buildup and maintain extraction efficiency. To clean:

1. Turn off and unplug the hood from the power supply.
2. Remove the grease filters by releasing their locking mechanisms.
3. Wash the filters by hand in hot soapy water or in a dishwasher on a low-temperature cycle.
4. Allow the filters to dry completely before reinstalling them.

Replace synthetic filters if they show signs of damage or excessive wear.

5.2 Cleaning the Hood Surface

Clean the exterior surfaces of the hood with a soft cloth and a mild, non-abrasive detergent. Do not use abrasive cleaners, steel wool, or harsh chemicals, as these can damage the finish.

5.3 LED Light Replacement

LED lights are long-lasting. If replacement is necessary, contact a qualified service technician. Do not attempt to replace LED lights yourself.

6. TROUBLESHOOTING

Before contacting customer service, refer to the following table for common issues and their solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Hood does not turn on	No power supply; Power cord unplugged; Circuit breaker tripped	Check power connection; Check circuit breaker; Ensure power outlet is functional
Low suction power	Grease filters are dirty; Ducting is obstructed or too long/bent; Fan motor issue	Clean or replace grease filters; Check ducting for obstructions; Contact service technician
Lights not working	LED lights faulty; Electrical connection issue	Contact service technician for LED replacement; Check power supply
Excessive noise	Loose components; Fan obstruction; Motor issue	Check for loose parts; Clear any obstructions; Contact service technician

7. TECHNICAL SPECIFICATIONS

Feature	Specification
Brand	FABER
Model Number	152 SRM LG A90
Mounting Type	Built-in
Control Type	Electromechanical Buttons
Lighting Type	LED
Grease Filter Type	Synthetic
Air Outlet Diameter	120 mm
Width	900 mm
Energy Efficiency Class	D
Motor Quantity	1
Fan Speeds	3
IEC Suction Capacity (Speed 1/2/3)	115 / 160 / 225 m ³ /h (converted from Litri al minuto)
Pressure (Speed 1/2/3)	190 / 310 / 370 Pa
Power Consumption (Speed 1/2/3)	80 / 95 / 115 W
Noise Level (Speed 1/2/3)	52 / 59 / 68 dB
Voltage	220 V (AC)
Color	Light Grey

Feature	Specification
Material	Synthetic
Ventilation Type	Exhaust

8. WARRANTY AND SUPPORT

8.1 Warranty Information

For information regarding product warranty and returns, please refer to the terms and conditions provided at the point of purchase or consult the official Faber website. Typically, if you wish to return a product within 30 days of receipt because you have changed your mind, please consult the relevant help page. If you have received a defective or damaged product, please consult the help page on returns and refunds. For specific information on purchases made through marketplaces, consult the marketplace's help page.

8.2 Customer Support

Should you encounter any issues not covered in this manual or require professional assistance, please contact Faber customer support or your authorized dealer. Have your product model number (152 SRM LG A90) and purchase details ready when contacting support.