

Wonder Creature Pet Fountain

Wonder Creature 81oz/2.4L Stainless Steel Cat Water Fountain Instruction Manual

Model: Pet Fountain

1. INTRODUCTION

The Wonder Creature 81oz/2.4L Stainless Steel Cat Water Fountain is designed to provide a continuous supply of fresh, filtered water for your pets. This fountain encourages increased water intake, which is vital for pet health. Its circulating filtration system ensures clean water, while the stainless steel top offers durability and hygiene. The integrated LED light and water level window provide convenience for monitoring and refilling.

2. INCLUDED COMPONENTS

Please ensure all the following components are present in your package:

- Pet fountain base x 1
- Stainless steel lid x 1
- Pump x 1
- Replacement carbon filters x 3
- Sponge foam filter x 1
- Silicone mat x 1
- DC adapter x 1
- Nozzle options (various designs)
- Cleaning brushes (for pump and nozzle)

Translucent Design & Bright LED Lights

Easy to observe the water level




Image: All components of the Wonder Creature Cat Water Fountain, including the main unit, stainless steel lid, pump, filters, silicone mat, and cleaning tools.

3. SETUP INSTRUCTIONS

1. **Unpack and Rinse:** Carefully unpack all components. Rinse the fountain base, stainless steel lid, pump, and all accessories thoroughly with water before first use.
2. **Assemble Pump:** Attach the sponge foam filter to the pump. Ensure the pump's LED light is oriented towards the clear water level window on the fountain base.
3. **Place Pump:** Place the assembled pump firmly at the bottom of the fountain base. The suction cups on the pump will help secure it in place. Route the power cord through the designated channel in the base.
4. **Fill with Water:** Fill the fountain base with fresh, clean water. Ensure the water level is between the 'MIN' and 'MAX' indicators visible through the water level window. Do not operate the fountain without sufficient water.
5. **Install Filter:** Place one carbon filter into the filter holder. Position the filter holder onto the designated area above the pump.
6. **Attach Lid:** Place the stainless steel lid onto the fountain base, ensuring it sits securely.
7. **Select Nozzle:** Choose your preferred water flow nozzle (e.g., flower waterfall, flower bubble, or gentle fountain) and attach it to the central spout on the stainless steel lid.
8. **Power On:** Connect the USB cable to the DC adapter, then plug the adapter into a power outlet. The fountain will begin operating, and the LED light will illuminate.

Keep Water Fresh & Cooler Than Normal Pet Bowl



Image: An exploded diagram illustrating the assembly of the water fountain, from the base to the lid and nozzle, highlighting the placement of the pump and filters.

4. OPERATING INSTRUCTIONS

4.1 Water Flow Designs

The fountain offers three distinct water flow designs to cater to your pet's preferences:

- **Flower Waterfall:** Provides multiple streams of water, aerating it for freshness.
- **Flower Bubble:** Creates a gentle bubbling effect.
- **Gentle Fountain:** A calm, steady flow of water.

You can easily switch between these modes by changing the nozzle attachment.

3 Different Flow Designs

Clear & Fresh High Quality Stainless Steel



- **Flower waterfall**



- **Flower bubble**



- **Gentle fountain**

Image: Visual representation of the three distinct water flow options available with the fountain.

4.2 Water Level Indicator & LED Light

The clear water level window on the front of the fountain, illuminated by an internal LED light, allows for easy monitoring of the water volume. The LED light also serves as a visual alert; if the water level drops below the minimum, the light may change color or flash (refer to specific product behavior for details), indicating a need for refilling.

4.3 Quiet Operation

The fountain is designed with a low-noise pump, operating below 40 dB, ensuring a quiet environment for both you and your pets.

Extremely quiet



20dB
Rustling leaves



30dB
Wonder Creature



40dB
Whisper



Operation $\leq 30\text{dB}$




Image: A graphic demonstrating the low noise level of the fountain, indicating it operates at approximately 30dB, comparable to a quiet room.

5. MAINTENANCE

Regular cleaning and filter replacement are crucial for maintaining water quality and extending the life of your fountain.

5.1 Cleaning the Fountain

- **Disassembly:** Unplug the fountain. Disassemble all parts: remove the nozzle, stainless steel lid, filter holder, and pump.
- **Wash Components:** Wash the fountain base, stainless steel lid, and nozzle with mild soap and water. The stainless steel top is dishwasher-safe.
- **Clean Pump:** Use the provided cleaning brushes to clean the pump thoroughly, especially the impeller and its housing, to prevent mineral buildup and ensure optimal performance.
- **Rinse:** Rinse all components thoroughly to remove any soap residue.
- **Reassemble:** Reassemble the fountain following the setup instructions.

5.2 Filter Replacement

- **Carbon Filter:** Replace the carbon filter every 2-4 weeks, or more frequently if you have multiple pets or

notice reduced water flow/quality.

- **Sponge Foam Filter:** Rinse the sponge foam filter attached to the pump weekly. Replace it every 2-4 months, or when it shows signs of wear or excessive debris.
- **Pre-soak New Filters:** Always pre-soak new carbon filters in water for 5-10 minutes before placing them in the fountain to remove any loose carbon dust.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
No water flow or weak flow	Low water level; Clogged pump/filter; Kinked tubing.	Refill water to MAX level; Clean pump and replace filter; Check and straighten tubing.
Fountain is noisy	Low water level; Dirty pump; Improper assembly.	Refill water; Clean pump thoroughly; Ensure all parts are correctly assembled.
LED light not working	Power issue; Pump not correctly oriented.	Check power connection; Ensure pump's LED is facing the water level window.

7. SPECIFICATIONS

- **Capacity:** 2.4 Liters (81 oz)
- **Dimensions (LxWxH):** 7.09 x 7.09 x 6.1 inches
- **Item Weight:** 1.67 pounds
- **Material:** Stainless Steel (top), Plastic (base)
- **Pump:** Low-voltage, ultra-quiet (below 40 dB)
- **Filtration:** 3-stage (charcoal filter, pre-filter sponge)
- **Features:** Water level window, LED light, 3 flow designs
- **Power:** DC adapter (included)

8. WARRANTY AND SUPPORT

This Wonder Creature Cat Water Fountain comes with a **1 Year Limited Warranty**. For any product inquiries, technical support, or warranty claims, please refer to the contact information provided in your product packaging or visit the official Wonder Creature website.