#### Manuals+

Q & A | Deep Search | Upload

#### manuals.plus /

- NOOA /
- > NOOA Ear Nose Hair Trimmer User Manual

#### **NOOA ES509U**

# **NOOA Ear Nose Hair Trimmer User Manual**

Model: ES509U

#### **PRODUCT OVERVIEW**

The NOOA Ear Nose Hair Trimmer is a versatile 3-in-1 electric grooming tool designed for complete trimming and styling of facial hair. It features dual-edge stainless steel blades, a built-in LED light, and is fully waterproof for convenient wet and dry use. This device is suitable for trimming nose, ear, eyebrow, and beard hair.



Image: The NOOA Ear Nose Hair Trimmer shown with its main body and three interchangeable heads: nose & ear trimmer, eyebrow trimmer, and beard trimmer. A USB charging cable is also visible.

# **SAFETY INFORMATION**

- Keep out of reach of children.
- · Avoid contact with skin and eyes.
- The cutter heads of this nose trimmer can be only used for designated parts; body trimming is not recommended.
- Please keep this nose ear hair trimmer away from children in case of any accident.

# PACKAGE CONTENTS

Please ensure all items are present in the package:

- 1 x NOOA Trimmer Body
- 1 x Nose & Ear Trimmer Head
- 1 x Eyebrow Trimmer Head
- 1 x Beard Trimmer Head
- 1 x USB Charging Cable
- 1 x Cleaning Brush

#### SETUP AND CHARGING

# **Charging the Device**

The NOOA Trimmer comes with a built-in rechargeable battery. Before first use, or when the device's performance decreases, charge the trimmer using the provided USB cable.

- 1. Connect the small end of the USB charging cable to the charging port on the trimmer.
- 2. Connect the larger end of the USB cable to a compatible USB power source (e.g., computer, wall adapter, power bank).
- 3. Allow the device to charge fully. A full charge ensures optimal performance.

# **USB RECHARGEABLE & PORTABLE**

Take it with you and charge anywhere



Image: The NOOA Trimmer being charged via a USB cable connected to a laptop, demonstrating its portable charging capability.

#### **Attaching and Changing Trimmer Heads**

The trimmer features interchangeable heads for different grooming needs.

- 1. To remove a head, gently twist it counter-clockwise and pull upwards.
- 2. To attach a head, align the head with the trimmer body and twist clockwise until it clicks securely into place.

#### **OPERATING INSTRUCTIONS**

# **General Operation**

- To turn the trimmer ON, slide the power switch upwards.
- To turn the trimmer OFF, slide the power switch downwards.
- The built-in LED light will illuminate when the trimmer is on, aiding visibility in dimly lit areas.

### **Using the Nose & Ear Trimmer Head**

This head is designed for safe and efficient removal of unwanted nose and ear hair.

- 1. Insert the trimmer head gently into the nostril or ear canal. Do not insert too deeply.
- 2. Move the trimmer in a circular motion to trim hair. The 360° rotating design and R-type rounded blades ensure comfortable and precise trimming without pulling.
- 3. Breathe normally during nose hair trimming.

# **SAFETY & EFFICIENCY CLEANING**

Don't hurt your nose



Image: A detailed view of the nose trimmer head, highlighting its 360-degree trimming capability and the R-type rounded blade design for safety and efficiency.

### **Using the Eyebrow and Beard Trimmer Heads**

These heads are suitable for shaping eyebrows and maintaining beard lines.

- For eyebrows, carefully guide the trimmer along the desired shape. Use short, controlled strokes.
- For beard trimming, use the head to define edges and remove stray hairs.

#### Wet and Dry Use

The NOOA Trimmer is IPX7 waterproof, allowing for both wet and dry use.

- You can use the trimmer in the shower or with shaving cream/gel for a more comfortable experience.
- Ensure the device is fully charged before wet use.



Image: The NOOA Trimmer being splashed with water, illustrating its IPX7 waterproof capability for use in wet and dry conditions.

#### MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and hygiene.

- 1. After each use, turn off the trimmer.
- 2. Remove the trimmer head by twisting it counter-clockwise.
- 3. Rinse the trimmer head directly under running tap water to remove hair clippings and debris. The waterproof design allows for easy rinsing.
- 4. For thorough cleaning, you may use the provided cleaning brush to remove stubborn hairs from the blades.
- 5. Allow the head to air dry completely before reattaching or storing.
- 6. The entire device can be rinsed under running water or submerged briefly for deeper cleaning.



Image: Step-by-step guide for cleaning the trimmer head: 1. Open the protective cover. 2. Rinse the head thoroughly with water. 3. Replace the cover after drying.

# **T**ROUBLESHOOTING

If you encounter issues with your NOOA Trimmer, please refer to the following common solutions:

Problem	Possible Cause / Solution
Trimmer does not turn on.	Battery may be depleted. Charge the device fully. Ensure the power switch is in the "ON" position.
Trimmer is not cutting effectively.	Blades may be clogged with hair. Clean the trimmer head thoroughly. Ensure the head is securely attached. Battery may be low, try charging.
Device feels hot during use.	This can be normal during extended use. If it becomes excessively hot, turn off the device and allow it to cool down before resuming use.

# **S**PECIFICATIONS

Feature	Detail
Model Number	ES509U
Power Source	USB Rechargeable, Built-in Battery
Blade Material	Stainless Steel
Waterproof Rating	IPX7 (Fully Washable)
Motor Speed	6500 RPM (High Speed)
Dimensions	5.91 x 3.94 x 1.97 inches
Weight	4.97 ounces (141 Grams)
Color	Blue



Image: A visual representation of the trimmer's dimensions, indicating its compact and portable size.

# WARRANTY AND SUPPORT

NOOA offers comprehensive support for its products.

- Warranty: 30 days money back warranty.
- Technical Support: 365 days technical support.
- Customer Service: 24 hours professional service.

For any questions or dissatisfaction, please feel free to reach out to NOOA customer service.


#### Related Documents - ES509U



#### NOOA Vantage Multitrimmer User Manual

Comprehensive user manual for the NOOA Vantage Multitrimmer, detailing features, safety instructions, charging, attachment usage, and maintenance for optimal performance.

VANTAGE User Manual



#### NOOA NOBR018 Ionic Hair Brush User Manual - Features, Safety, and Operation

Comprehensive user manual for the NOOA NOBR018 Ionic Hair Brush. Learn about product features, safety warnings, battery handling, operation, maintenance, and specifications.



#### NOOA Body Analyzer Scale NO602 Instruction Manual

Instruction manual for the NOOA Body Analyzer Scale Model NO602, detailing features, usage, maintenance, and troubleshooting for body composition analysis.



# NOOA Body Analyzer Scale Instruction Manual

Comprehensive guide to the NOOA Body Analyzer Scale (Model NO601H), detailing its features for measuring body fat, water, muscle, bone, and estimating calorie needs, along with usage instructions and maintenance tips.



#### NOOA Bodysync Smart Body Composition Scale User Manual

User manual for the NOOA Bodysync Smart Body Composition Scale, providing detailed instructions on setup, operation, safety precautions, features, specifications, and troubleshooting.



Makeup Mirror

#### NOOA GLOW Hollywood Makeup Mirror User Manual

Operating instructions and specifications for the NOOA GLOW Hollywood Makeup Mirror, including safety precautions, product overview, operation, and care.

GLOW UserManual