

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [IKEA](#) /

> [IKEA Vidja Standing Floor Lamp Instruction Manual](#)

## IKEA VIDJA

# IKEA Vidja Standing Floor Lamp Instruction Manual

Model: VIDJA

## INTRODUCTION

This manual provides essential information for the safe and efficient use of your IKEA Vidja Standing Floor Lamp. Please read these instructions carefully before assembly and operation, and retain them for future reference.


## SAFETY INFORMATION

- Ensure the lamp is placed on a stable, level surface to prevent tipping.
- Do not use bulbs with wattage exceeding the recommended maximum. Refer to the specifications section for details.
- Keep the lamp away from water and moisture. This product is for indoor use only.
- Always unplug the lamp from the power outlet before cleaning or changing bulbs.
- Do not attempt to modify the lamp's electrical components. Contact qualified personnel for repairs.
- Keep packaging materials away from children to prevent suffocation hazards.

## PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- IKEA Vidja Standing Floor Lamp components
- Bulbs (typically 6, as specified in product description)
- Assembly instructions (this manual)





## SETUP AND ASSEMBLY

---

The IKEA Vidja Standing Floor Lamp is designed for straightforward assembly. Follow these steps:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Assemble Base:** Attach the lamp base to the lowest pole section. Ensure it is securely tightened.
3. **Connect Pole Sections:** Screw the remaining pole sections together, ensuring the electrical cord passes freely through them.
4. **Attach Shade Frame:** Secure the shade frame components to the top of the assembled pole.
5. **Install Fabric Shade:** Drape the fabric shade over the frame, ensuring it is evenly positioned and secured.
6. **Insert Bulbs:** Screw the recommended bulbs into the lamp sockets. Ensure the lamp is unplugged before inserting bulbs.
7. **Position Lamp:** Place the assembled lamp in its desired location, ensuring the power cord is not pinched or a tripping hazard.



Image: The IKEA Vidja Standing Floor Lamp, fully assembled and illuminated, positioned next to a sofa in a living room, demonstrating its ambient light output.

## OPERATING INSTRUCTIONS

---

The IKEA Vidja Standing Floor Lamp features a simple touch control for operation.

1. **Power Connection:** Plug the lamp's power cord into a suitable electrical outlet (220 Volts AC, as per specifications).
2. **Turning On/Off:** The lamp is equipped with a touch switch. Gently touch the designated area on the lamp (typically near the base or a metal band) to turn the light on or off.

The fabric shade provides a diffused and decorative light, suitable for creating a warm ambiance.

## MAINTENANCE

---

- **Cleaning:** Disconnect the lamp from the power supply. Wipe the metal parts with a soft, dry cloth. For the fabric shade, use a lint roller or a soft brush to remove dust. Do not use abrasive cleaners or solvents.

• **Bulb Replacement:**

- a. Ensure the lamp is unplugged and the bulbs have cooled down completely.
- b. Carefully unscrew the old bulb(s) from the socket(s).
- c. Screw in new bulbs of the correct type and wattage (refer to Specifications).
- d. Reconnect the lamp to power.



Image: A close-up view of the top section of the IKEA Vidja Standing Floor Lamp, highlighting the texture of the white fabric shade and the silver-colored metal ring.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Lamp does not light up.	<ul style="list-style-type: none"> <li>• Power cord not plugged in.</li> <li>• Bulb(s) loose or burnt out.</li> <li>• Power outlet not functioning.</li> </ul>	<ul style="list-style-type: none"> <li>• Ensure the power cord is securely plugged into a working outlet.</li> <li>• Tighten or replace bulb(s).</li> <li>• Test the outlet with another appliance.</li> </ul>
Light flickers.	<ul style="list-style-type: none"> <li>• Loose bulb connection.</li> <li>• Incompatible bulb type.</li> </ul>	<ul style="list-style-type: none"> <li>• Tighten bulb(s).</li> <li>• Ensure bulbs meet specifications.</li> </ul>
Lamp is unstable.	<ul style="list-style-type: none"> <li>• Base or pole sections not fully tightened.</li> <li>• Uneven surface.</li> </ul>	<ul style="list-style-type: none"> <li>• Re-tighten all connections.</li> <li>• Move the lamp to a flat, stable surface.</li> </ul>

## SPECIFICATIONS

<b>Model Number</b>	VIDJA
<b>Product Dimensions</b>	11"D x 18.5"W x 4.12"H (approx. 28cm D x 47cm W x 10.5cm H)
<b>Item Weight</b>	2.51 Pounds (approx. 1.14 kg)
<b>Material</b>	Fabric (shade), Metal (base)
<b>Shade Color</b>	White
<b>Light Source Type</b>	LED (recommended)
<b>Number of Light Sources</b>	1 (designed for multiple bulbs, typically 6 small E14 bulbs)
<b>Wattage</b>	7 watts (total, for included bulbs)
<b>Voltage</b>	220 Volts (AC)
<b>Control Method</b>	Touch
<b>Indoor/Outdoor Usage</b>	Indoor
<b>Assembly Required</b>	Yes
<b>UPC</b>	300846110094, 732773728620

## WARRANTY AND SUPPORT

For information regarding warranty coverage or technical support, please refer to the official IKEA website or contact IKEA customer service directly. Keep your proof of purchase for any warranty claims.

**IKEA Official Website:** [www.ikea.com](http://www.ikea.com)

