

[Manuals.plus](#) /

› [Good Vibes Only](#) /

› Good Vibes Only Rabbit Vibrator Bliss Instruction Manual

Good Vibes Only GVO002

Good Vibes Only Rabbit Vibrator Bliss Instruction Manual

Model: GVO002 | Brand: Good Vibes Only

INTRODUCTION

Thank you for choosing the Good Vibes Only Rabbit Vibrator Bliss. This manual provides essential information for the safe and effective use, maintenance, and care of your device. Please read it thoroughly before first use and retain it for future reference.

The Bliss Rabbit Vibrator is designed for dual stimulation, targeting the clitoris, vagina, and G-spot with its unique shape and 10 powerful vibration modes. It is made from body-safe silicone, is rechargeable, and fully waterproof for easy cleaning.

SETUP AND CHARGING

Initial Charge

Before first use, fully charge the vibrator. Connect the included USB charging cable to the charging port on the device and to a standard USB power source (e.g., computer, USB wall adapter). The indicator light will show charging status (specific light behavior may vary by production batch, refer to packaging if available).

The vibrator is rechargeable with the provided USB cable.

Preparation for Use

Clean the vibrator thoroughly before its first use. Refer to the 'Maintenance and Cleaning' section for detailed instructions.

BLIS

#GV002




Image: Infographic detailing the Blis Rabbit Vibrator's features, including its USB rechargeable capability.

OPERATING INSTRUCTIONS

Power On/Off

- To turn on: Press and hold the '+' button for a few seconds until the vibrations begin.
- To turn off: Press and hold the '-' button for a few seconds until the vibrations stop.

Adjusting Vibration Modes

- The Blis Rabbit Vibrator features 10 distinct vibration modes.
- To cycle through modes: Press the '+' button to increase intensity or change to the next mode. Press the '-' button to decrease intensity or cycle back through modes.

Usage Recommendations

- Apply a water-based lubricant to the vibrator and desired areas for comfortable use.
- The vibrator's design allows for simultaneous stimulation of the clitoris and vagina/G-spot. Experiment with different angles and pressures to find what is most pleasurable.

HOW TO USE?

#GV002



Use lube when you insert the Rabbit vibrator



Simultaneous stimulation of clitoris and vagina




Image: Visual guide on how to use the Bliss Rabbit Vibrator for dual stimulation.



Image: Close-up of the vibrator's control panel with '+' and '-' buttons.

MAINTENANCE AND CLEANING

Cleaning

- The Blis Rabbit Vibrator is fully waterproof, allowing for easy cleaning.
- After each use, clean the device thoroughly with warm water and a mild soap or a specialized sex toy cleaner.
- Rinse thoroughly to remove all soap residue.
- Dry completely with a lint-free cloth before storing.

WATERPROOF



Image: Infographic confirming the vibrator's waterproof design for easy cleaning.

Storage

- Store the vibrator in a clean, dry, and dust-free place.
- Avoid storing with other silicone products to prevent material degradation.
- Keep out of direct sunlight and extreme temperatures.

TROUBLESHOOTING

- **Device not turning on:** Ensure the device is fully charged. Connect it to the USB charger and allow sufficient time for charging.
- **Vibrations are weak:** The battery may be low. Recharge the device.
- **Buttons unresponsive:** Ensure the device is not locked (if applicable, though this model does not specify a lock function). Try fully charging the device.

If you experience persistent issues, please refer to the 'Warranty and Support' section for contact information.

SPECIFICATIONS

Feature	Detail
Product Name	Good Vibes Only Rabbit Vibrator Bliss
Model Number	GVO002
Brand	Good Vibes Only
Material	Acrylonitrile Butadiene Styrene (ABS), Silicone
Color	Blue
Dimensions (L x W x H)	22 x 10 x 4 cm (8.7 x 3.9 x 1.6 inches)
Weight	0.12 kg (0.26 lbs)
Vibration Modes	10
Power Source	Rechargeable Lithium-ion Battery
Charging	USB Cable (included)
Water Resistance	Waterproof

WARRANTY AND SUPPORT

For warranty information, product support, or to inquire about replacement parts, please refer to the documentation included with your purchase or contact the manufacturer directly.
Manufacturer: Good Vibes Only

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question