

[Manuals.plus](#) /

› [Smoby](#) /

› Smoby Garage First Age (Model 12422) Instruction Manual

Smoby 12422

Smoby Garage First Age (Model 12422) Instruction Manual

For ages 18 months to 5 years

INTRODUCTION

Thank you for choosing the Smoby Garage First Age. This manual provides essential information for the safe assembly, operation, and maintenance of your toy. Please read it carefully before use and retain it for future reference.

This toy garage is designed to immerse young children in the world of cars, featuring an elevator, ramp, and garage door. It includes one free-wheel vehicle adapted for small hands.



Image: The Smoby Garage First Age playset, showcasing its multi-level design with a ramp, a garage tower, and two toy cars.

SAFETY INFORMATION

- **Age Recommendation:** Suitable for children aged 18 months to 5 years. Not suitable for children under 18 months due to small parts that could pose a choking hazard.
- **Adult Supervision:** Adult supervision is recommended during play.
- **Assembly:** Adult assembly is required. Ensure all parts are securely fastened before allowing children to play.
- **Placement:** Use on a flat, stable surface to prevent tipping.
- **Cleaning:** Clean with a damp cloth. Do not use abrasive cleaners.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly.

- Garage structure components
- 1 x Free-wheel toy car
- Assembly instructions (this manual)

Note: The included car is specifically designed for this playset.

SETUP AND ASSEMBLY

Adult assembly is required. Please follow these steps carefully.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, flat surface.
2. **Base Assembly:** Connect the base pieces together according to the molded guides. Ensure they click securely into place.
3. **Ramp Attachment:** Attach the main ramp section to the base. Look for corresponding slots and tabs.
4. **Tower Construction:** Assemble the garage tower sections. These typically snap together.
5. **Elevator Installation:** Insert the elevator mechanism into the tower. Test its movement to ensure it slides smoothly.
6. **Connecting Tower to Base:** Secure the assembled tower to the main base structure.
7. **Adding Accessories:** Attach any smaller decorative elements or movable parts like the garage door or signs.
8. **Final Check:** Before play, ensure all connections are firm and there are no loose parts.



* incluye 1 coche

Image: A child's hand interacting with the ramp feature, demonstrating how cars move up and down.

OPERATING INSTRUCTIONS

The Smoby Garage First Age offers several interactive features for imaginative play.

- **Using the Ramp:** Place the included toy car at the top of the ramp and release it to watch it slide down. The ramp is designed for smooth, free-wheel action.
- **Operating the Elevator:** Position a car on the elevator platform. Use the manual crank or lever (depending on model variation) to raise or lower the car between levels of the garage tower.



Image: Demonstrates how to use the elevator, showing a hand moving the lever to lift a car.

- **Garage Door:** The garage door can be manually opened and closed to allow cars to enter and exit the ground level of the garage.
- **Interactive Elements:** Explore other interactive elements like the "Towing Salvage" sign and "Wheel Well Motor Court" details for enhanced play scenarios.

MAINTENANCE AND CARE

To ensure the longevity and hygiene of your Smoby Garage First Age, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the toy regularly with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used, followed by wiping with a clean, damp cloth.
- **Drying:** Ensure all parts are thoroughly dry before storing or allowing children to play again.
- **Storage:** Store the toy in a clean, dry place away from direct sunlight and extreme temperatures to prevent material degradation.
- **Inspection:** Periodically inspect all parts for wear and tear, especially moving components like the elevator and ramp. Discontinue use if any part is broken or damaged.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or strong detergents, as these can damage the plastic.

TROUBLESHOOTING

If you encounter any issues with your Smoby Garage First Age, refer to the following common solutions:

Problem	Possible Cause	Solution
Car does not slide smoothly down the ramp.	Obstruction on the ramp; ramp not properly assembled; car wheels are dirty.	Check for any debris on the ramp and remove it. Ensure the ramp sections are securely connected. Clean the car wheels.
Elevator is stuck or difficult to move.	Obstruction in the elevator shaft; elevator mechanism not properly installed.	Inspect the elevator shaft for any foreign objects. Re-check the assembly instructions for correct elevator installation.
Parts feel loose after assembly.	Components not fully clicked into place.	Press firmly on all connection points until you hear a click or feel them secure. Refer to the assembly section.

SPECIFICATIONS

- **Model Number:** 12422
- **Brand:** Smoby
- **Product Dimensions (Assembled):** 16.54 x 8.27 x 12.99 inches (42 x 21 x 33 cm)
- **Item Weight:** 2.85 pounds (1.29 kg)
- **Recommended Age:** 18 months - 5 years
- **Material:** Durable Plastic
- **Contents:** Garage playset, 1 x toy car

WARRANTY AND SUPPORT

Smoby products are manufactured to high-quality standards. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official Smoby website. For further assistance, missing parts, or specific product inquiries, please contact Smoby customer support. Contact details can typically be found on the product packaging or the official Smoby website: www.smoby.com

