

[Manuals.plus](#) /

› [Kooduu](#) /

› Kooduu Synergy 65 Pro - User Manual

Kooduu Pro65

Kooduu Synergy 65 Pro User Manual

Model: Pro65

INTRODUCTION

The Kooduu Synergy 65 Pro is an innovative product that combines a warm LED lamp, a high-quality Bluetooth speaker, and a functional ice bucket. Designed for both indoor and outdoor use, it provides ambient lighting, rich audio, and a convenient way to chill beverages. This manual provides detailed instructions for the setup, operation, and maintenance of your Synergy 65 Pro.



Image: The Kooduu Synergy 65 Pro, showcasing its design as a lamp, speaker, and ice bucket.

SAFETY INFORMATION

Please read all safety instructions carefully before using the Kooduu Synergy 65 Pro. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Do not immerse the unit in water. The product is not waterproof.
- Keep away from open flames or extreme heat sources.
- Do not attempt to disassemble or repair the unit yourself. Refer all servicing to qualified personnel.
- Use only the provided charging cable and adapter.
- Ensure the charging port is dry before connecting the charger.

- Keep out of reach of children and pets.
- Avoid placing heavy objects on top of the unit.

PACKAGE CONTENTS

Verify that all items are present in the package:

- Kooduu Synergy 65 Pro Unit
- Charging Cable (USB)
- Power Adapter
- User Manual (this document)

PRODUCT OVERVIEW

Familiarize yourself with the different parts of your Synergy 65 Pro.



Image: Underside of the Synergy 65 Pro, highlighting the power controls and speaker.

1. **LED Lamp:** Provides warm ambient lighting.
2. **Bluetooth Speaker:** Integrated speaker for audio playback.
3. **Ice Bucket:** Central compartment for chilling beverages.
4. **Leather Handle:** For easy portability.
5. **Control Panel (bottom):** Includes power button and charging port.

6. **Feet:** Stable base for the unit.

SETUP

1. Charging the Unit

Before first use, fully charge your Synergy 65 Pro. A full charge takes approximately 6 hours and provides up to 12 hours of combined light and music playback.

- Connect the charging cable to the USB port on the bottom of the unit.
- Plug the power adapter into a wall outlet.
- The LED indicator will show charging status (e.g., red for charging, green for fully charged).

2. Initial Placement

Place the Synergy 65 Pro on a stable, flat surface, ensuring proper ventilation around the speaker area at the bottom.

OPERATING INSTRUCTIONS

1. Power On/Off

- To power on, press and hold the power button on the bottom of the unit for 3 seconds. You will hear an audible confirmation.
- To power off, press and hold the power button for 3 seconds.

2. Bluetooth Pairing

Connect your mobile device to the Synergy 65 Pro to play music.

1. Ensure the Synergy 65 Pro is powered on. It will automatically enter Bluetooth pairing mode (indicated by a flashing LED).
2. On your mobile device (smartphone, tablet), go to Bluetooth settings.
3. Select "Kooduu Synergy Pro" from the list of available devices.
4. Once connected, the LED indicator will become solid, and you will hear a confirmation sound.
5. You can now play audio from your device through the Synergy 65 Pro speaker.



Image: The Synergy Pro's key features: warm LED lamp, Bluetooth speaker, and wine cooler.

3. Light Control

The Synergy 65 Pro features an integrated LED lamp.

- To turn the light on/off, briefly press the light button (usually located near the power button on the bottom).
- Some models may have dimming capabilities by holding the light button. Refer to specific product details if applicable.

4. Multi-Connect Function (True Wireless Stereo - TWS)

You can connect multiple Synergy Pro units (Synergy 35 Pro, 50 Pro, 65 Pro, and Nordic Light Pro) for a synchronized audio experience.




Image: Multi-connect diagram, showing how one device can link to several others for expanded audio.

1. Ensure all Synergy Pro units you wish to connect are powered on and not currently paired with any other device.
2. Pair your mobile device with one Synergy Pro unit (this will be the primary unit).
3. On the primary unit, double-press the power button. It will enter TWS pairing mode.
4. On the secondary units, double-press the power button. They will search for the primary unit.
5. Once connected, all units will play synchronized audio.
6. To disconnect TWS, double-press the power button on any connected unit.

5. Ice Bucket Usage

The integrated ice bucket is designed to keep your beverages cool.

- Fill the central compartment with ice and your desired beverages.
- Ensure the ice bucket is clean before use.
- After use, empty any melted ice and clean the compartment thoroughly.



Image: The Synergy 65 Pro in use as an ice bucket during an outdoor gathering.

MAINTENANCE

Proper care will extend the life of your Synergy 65 Pro.

- **Cleaning:** Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Ice Bucket:** After each use, empty the ice bucket and rinse it with water. Dry thoroughly before storing.
- **Storage:** Store the unit in a cool, dry place when not in use. If storing for extended periods, charge the battery every 3 months to maintain its health.
- **Battery:** The integrated battery is not user-replaceable.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Unit does not power on.	Battery is depleted.	Charge the unit fully.
Cannot pair via Bluetooth.	Unit is not in pairing mode; previously paired device is connected; device Bluetooth is off.	Ensure unit is in pairing mode. Disconnect from other devices. Turn on Bluetooth on your device.
No sound from speaker.	Volume too low; device not connected; audio source issue.	Increase volume on both unit and connected device. Re-pair Bluetooth. Check audio source.
Light does not turn on.	Unit is off; light function is off.	Ensure unit is powered on. Press the light button to activate.
Multi-Connect (TWS) not working.	Units not in TWS pairing mode; too far apart; already paired individually.	Ensure all units are in TWS pairing mode. Keep units within range. Disconnect individual Bluetooth pairings before TWS.

SPECIFICATIONS

Feature	Detail
Model	Synergy 65 Pro (Pro65)
Dimensions (D x H)	41 cm x 71.5 cm (16.1 x 28.1 inches)
Weight	4.45 kg (9.8 lbs)
Battery Capacity	3000 mAh Lithium-ion
Battery Life	Up to 12 hours (combined light & music)
Bluetooth Version	4.2
Speaker Output Power	8 Watts (Max 24 Watts)
Ice Bucket Volume	4.8 Liters
Connectivity	Bluetooth, USB Port (for charging)
Material	Genuine leather, brushed aluminum, brushed and galvanized nylon, soft white PET, Glass
Waterproof	No



Image: Size comparison of Synergy Pro models, including the 65 Pro.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official Kooduu website or contact your local retailer. Keep your proof of purchase for warranty claims.

Manufacturer: Kooduu

Website: www.kooduu.com (Example link, actual link may vary)

© 2024 Kooduu. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question