

[Manuals.plus](#) /

› [Rabalux](#) /

› Rabalux Camille 7608 Suspension Lamp User Manual

Rabalux Camille 7608

Rabalux Camille 7608 Suspension Lamp User Manual

Model: Camille 7608

1. INTRODUCTION

Thank you for choosing the Rabalux Camille 7608 Suspension Lamp. This manual provides essential information for the safe installation, operation, and maintenance of your new lighting fixture. Please read these instructions carefully before installation and retain them for future reference.

The Camille 7608 is a stylish suspension lamp featuring a chrome metal body and opal plastic shades, designed to provide ambient lighting. It is dimmable and uses six E14 bulbs (not included).

2. SAFETY INSTRUCTIONS

- **Professional Installation Recommended:** Installation should be performed by a qualified electrician to ensure safety and compliance with local electrical codes.
- **Power Disconnection:** Always disconnect the main power supply at the circuit breaker or fuse box before beginning any installation, maintenance, or bulb replacement.
- **Voltage Compatibility:** Ensure the voltage supply matches the requirements of the fixture (typically 220-240V for European markets).
- **Bulb Specifications:** Use only E14 bulbs with a maximum wattage of 40W per bulb. Do not exceed the total maximum wattage of 240W for the fixture.
- **Dimmable Feature:** If using the dimmable feature, ensure that the bulbs and dimmer switch are compatible.
- **Handling:** Handle the lamp components with care to avoid damage.
- **Environment:** This fixture is rated IP20, meaning it is protected against solid objects larger than 12.5mm but has no protection against water. Do not install in bathrooms or other areas where it may be exposed to moisture.
- **Cleaning:** Use a soft, dry cloth for cleaning. Do not use abrasive cleaners or solvents.

3. PACKAGE CONTENTS

Please check that all components are present and undamaged before installation. If any parts are missing or damaged, contact your retailer.

- Suspension Lamp Fixture (Canopy, Cables, Lamp Holders, Shades)
- Mounting Hardware (Screws, Wall Plugs)

- Instruction Manual

Note: Light bulbs (E14) are not included and must be purchased separately.

4. SETUP AND INSTALLATION

Important: Ensure the main power supply is switched off at the circuit breaker before starting installation.

1. **Prepare the Mounting Surface:** Identify the desired location for the lamp. Ensure the ceiling can support the weight of the fixture (2.12 kg).
2. **Attach the Mounting Bracket:** Secure the mounting bracket to the ceiling using the provided screws and wall plugs. Ensure it is firmly attached.
3. **Adjust Cable Lengths:** The suspension cables can be adjusted to your desired height. Carefully push the cable into the canopy's cable grip to shorten, or pull gently from the top to lengthen. Ensure all six cables are adjusted to the desired length and are level.
4. **Electrical Connection:** Connect the electrical wires from the ceiling to the terminal block on the lamp's canopy. Follow standard wiring conventions: Live (L), Neutral (N), and Earth (E). If unsure, consult a qualified electrician.
5. **Secure the Canopy:** Carefully push the canopy up against the ceiling, aligning it with the mounting bracket. Secure it in place using the provided screws or fasteners.
6. **Install Bulbs:** Screw six E14 bulbs (max 40W each) into the lamp holders.
7. **Attach Shades:** Carefully attach the opal plastic shades to each lamp holder.
8. **Restore Power:** Once installation is complete and all connections are secure, restore power at the circuit breaker.



Image 1: The Rabalux Camille 7608 Suspension Lamp elegantly installed above a dining table, showcasing its chrome finish and opal shades.




Image 2: Technical drawing illustrating the dimensions of the Camille 7608 lamp, with a width of 360mm and a total height of 1100mm.

5. OPERATING INSTRUCTIONS

Once installed and powered, the Rabalux Camille 7608 Suspension Lamp operates via your standard wall switch. If a compatible dimmer switch is installed, you can adjust the light intensity.

- **Turning On/Off:** Use the wall switch connected to the lamp to turn the light on or off.
- **Dimming (Optional):** If you have installed a compatible dimmer switch and dimmable E14 bulbs, rotate or press the dimmer control to adjust the brightness level.

6. MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your lamp.

- **Cleaning:** Before cleaning, ensure the power supply is disconnected. Wipe the metal and plastic surfaces with a soft, dry, lint-free cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish.
- **Bulb Replacement:** Always disconnect power before replacing bulbs. Allow old bulbs to cool completely before removal. Replace with new E14 bulbs, ensuring they do not exceed 40W each.
- **Inspection:** Periodically check the fixture for any signs of wear or damage, especially the electrical cables. If any damage is observed, disconnect power and consult a qualified electrician.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not light up.	No power supply. Faulty bulb(s). Incorrect wiring.	Check the circuit breaker and wall switch. Replace bulb(s) with new ones. Verify wiring connections (consult an electrician if necessary).
Light flickers.	Loose bulb connection. Incompatible dimmer/bulb. Faulty bulb.	Tighten bulbs. Ensure dimmer and bulbs are compatible (if dimmable). Replace faulty bulb.
Dimmable feature not working.	Non-dimmable bulbs installed. Incompatible dimmer switch.	Install dimmable E14 bulbs. Ensure dimmer switch is compatible with LED/incandescent bulbs as required.

8. SPECIFICATIONS

Feature	Detail
Model	Camille 7608
Brand	Rabalux
Type	Suspension Lamp
Material	Metal (chrome), Plastic (opal)

Feature	Detail
Dimensions (Width x Height)	360 mm x 1100 mm (36 cm x 110 cm)
Weight	2.12 kg
Number of Light Sources	6
Bulb Type	E14 (bulbs not included)
Max Wattage per Bulb	40W
Total Max Wattage	240W
Dimmable	Yes (with compatible bulbs and dimmer)
Protection Rating	IP20
Assembly Required	Yes




Image 3: Energy efficiency label for the Rabalux 7608 luminaire, indicating its compatibility with bulbs across various energy classes from A++ to E.

9. WARRANTY AND SUPPORT

For warranty information, please refer to the terms and conditions provided by your retailer at the time of purchase.

Rabalux products are designed for quality and durability.

If you encounter any issues or require technical assistance, please contact your point of purchase or visit the official Rabalux website for support contact details. Always have your model number (Camille 7608) and purchase details ready when seeking support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07SGYQYBM>

More documents and user manuals: <https://manuals.plus/>