

[Manuals.plus](#) /

› [Robo Alive](#) /

› Robo Alive Robotic Lizard Toy Pet Series 2 Instruction Manual

Robo Alive 10845218019331

Robo Alive Robotic Lizard Toy Pet Series 2 Instruction Manual

Model: 10845218019331 | Brand: Robo Alive

1. PRODUCT OVERVIEW

The Robo Alive Robotic Lizard is an interactive toy designed to mimic the movements and appearance of a real lizard. It features robotic technology that enables it to scurry at speed, realistic glaring eyes, a soft rubber tail and head, and a unique head-tilt sensor that allows it to stop and search for prey when its neck is tilted. This toy provides an engaging and realistic play experience.



Image: Robo Alive Robotic Lizard Toy Pet, showcasing its green and blue design with realistic features.

2. SETUP

2.1 Battery Installation

The Robo Alive Robotic Lizard requires **two (2) AA batteries** (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment on the underside of the lizard, typically in the stomach area.
2. Using a small Phillips head screwdriver, carefully unscrew the battery compartment cover.
3. Insert two (2) AA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Replace the battery compartment cover and secure it with the screw.

2.2 Power On/Off

After installing the batteries, locate the ON/OFF switch near the battery compartment. Slide the switch to the "ON" position to activate the lizard. Slide it to "OFF" when not in use to conserve battery life.

3. OPERATING INSTRUCTIONS

The Robo Alive Robotic Lizard is designed for intuitive play. Once powered on, place the lizard on a flat surface to observe its movements.

- **Movement:** The lizard will scurry forward using its legs, mimicking realistic lizard motion. It moves at a fast pace.
- **Head-Tilt Sensor:** To make the lizard stop its movement, gently tilt its head upwards. This activates a sensor that pauses its motion, allowing it to "search for prey."
- **Realistic Features:** Observe its glaring eyes and the way its mouth lights up during movement, adding to the realistic experience. The soft rubber tail and head provide a tactile and lifelike feel.

Your browser does not support the video tag.

Video: Official product video demonstrating the Robo Alive Lizard and Snake Series 2 in action, highlighting their realistic movements and features.

4. FEATURES

- **Robotic Technology:** Enables fast, scurrying movement.
- **Realistic Design:** Features glaring eyes, a soft rubber tail, and a flexible frilled neck.
- **Interactive Head-Tilt Sensor:** Stops movement when the head is tilted upwards.
- **Light-Up Mouth:** Adds to the lifelike appearance during operation.
- **Durable Construction:** Made with a combination of hard and soft rubber materials for longevity.

5. MAINTENANCE

To ensure the longevity and optimal performance of your Robo Alive Robotic Lizard, please follow these maintenance guidelines:

- **Cleaning:** Wipe the toy with a dry, soft cloth to remove dust and dirt. Do not immerse in water or use harsh cleaning agents.
- **Storage:** Store the lizard in a cool, dry place away from direct sunlight and extreme temperatures. Remove batteries if the toy will not be used for an extended period to prevent leakage.
- **Battery Care:** Always use fresh, high-quality AA batteries. Do not mix old and new batteries or different types of batteries.

6. TROUBLESHOOTING

If your Robo Alive Robotic Lizard is not functioning as expected, please refer to the following common issues and

solutions:

- **Lizard does not move:**
 - Ensure the ON/OFF switch is in the "ON" position.
 - Check if the batteries are correctly installed with the proper polarity.
 - Replace old or depleted batteries with new AA batteries.
- **Movement is slow or erratic:**
 - This usually indicates low battery power. Replace the batteries.
 - Ensure the lizard is on a smooth, flat surface. Rough or uneven surfaces may impede movement.
- **Mouth does not light up:**
 - Verify that the batteries are fresh and correctly installed.
 - If the lizard moves but the mouth light does not work, contact customer support.

7. SPECIFICATIONS

Feature	Detail
Product Dimensions	4.72 x 5.91 x 3.54 inches
Item Weight	11.2 ounces
Model Number	10845218019331
ASIN	B07SHGS855
Manufacturer	ZURU
Battery Requirement	2 x AA batteries (not included)

8. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the packaging or contact ZURU customer service directly. Keep your purchase receipt as proof of purchase.

Manufacturer: ZURU

For further assistance, visit the official [Robo Alive Store](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question