



[Manuals.plus](#) /

› [Alfawise](#) /

› Alfawise EX17S Sports Smart Watch User Manual

Alfawise EX17S

Alfawise EX17S Sports Smart Watch User Manual

Model: EX17S

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your Alfawise EX17S Sports Smart Watch. Please read this manual thoroughly before using the device to ensure proper function and longevity.



Image 1.1: Front view of the Alfawise EX17S Sports Smart Watch, displaying the digital interface and physical buttons.

2. PACKAGE CONTENTS

Upon opening the package, please verify that all items are present and in good condition:

- 1 x Alfawise EX17S Smart Watch
- 1 x English User Manual (this document)
- 1 x Screwdriver (for battery compartment)

3. GETTING STARTED (SETUP)

3.1. Battery Installation/Activation

The Alfawise EX17S uses a 610mAh CR2450 button battery. This battery is designed for long standby times (up to 540 days, approximately 18 months) and does not require frequent charging. If the watch is not powering on or displays a low battery reminder, the battery may need to be installed or replaced.

1. Locate the battery compartment on the back of the watch.

2. Use the provided screwdriver to carefully open the battery compartment cover.
3. Insert the CR2450 button battery with the positive (+) side facing up.
4. Securely close the battery compartment cover using the screwdriver.



Image 3.1: Rear view of the Alfawise EX17S Smart Watch, highlighting the battery compartment and water resistance markings.

3.2. App Download and Installation

To unlock the full smart features of your watch, download and install the companion application named **"Sports +"** on your smartphone. The app is compatible with Android 4.4 / iOS 8.0 and above systems.

1. Scan the QR code provided in the watch packaging or search for "Sports +" in your smartphone's app store (Google Play Store for Android, Apple App Store for iOS).
2. Download and install the application.
3. Follow the on-screen instructions to create an account and set up your profile.

3.3. Bluetooth Pairing

The Alfawise EX17S uses Bluetooth 4.0 for stable and low-power consumption connection with your mobile device. Ensure Bluetooth is enabled on your smartphone before proceeding.

1. Open the "Sports +" application on your smartphone.
2. Navigate to the device pairing section within the app.
3. On the watch, ensure Bluetooth is active. The watch features a one-button control for easy Bluetooth on/off. Refer to the *Basic Operation* section for button functions.
4. Select "Alfawise EX17S" from the list of available devices in the app to initiate pairing.
5. Confirm the pairing request on both your watch and smartphone if prompted.



Image 3.2: The Alfawise EX17S Smart Watch displaying its Bluetooth connection status alongside a smartphone running the companion application.

4. BASIC OPERATION

4.1. Button Functions

The Alfawise EX17S features multiple physical buttons for navigation and control:

- **LIGHT:** Activates the luminous dial for visibility in dark conditions.
- **MODE:** Cycles through different display modes and functions.
- **ST (Start/Stop):** Used to start and stop functions like the stopwatch or to confirm selections.
- **RESET:** Resets certain functions or returns to a previous menu.

4.2. Luminous Dial

The watch features an FSTN full-angle display with an electro-luminescent green backlight. Press the **LIGHT** button to illuminate the dial, making it convenient to see the time and other information in dark environments.



Image 4.1: A close-up view of the Alfawise EX17S Smart Watch's luminous dial, showing the green backlight for enhanced visibility.

4.3. Time and Date Display

The watch automatically synchronizes time and date information when connected to your smartphone via the "Sports +" app. Ensure your watch is paired for accurate timekeeping.

5. SMART FUNCTIONS

5.1. Pedometer (Health Tracker)

The built-in pedometer tracks your steps, distance (Km), and estimated calorie burn (Kcal). This data is synchronized with the "Sports +" app, allowing you to monitor your daily activity and progress.

5.2. Call and Message Reminders

When connected to your smartphone, the watch provides timely bell vibration reminders for incoming calls and messages. This feature supports notifications from various applications including Facebook, G-mail, Skype, Twitter, WeChat, and WhatsApp, ensuring you don't miss important communications.

CAL AND MESSAGE REMINDER

Timely bell vibration reminder don't miss an important call



Image 5.1: The Alfawise EX17S Smart Watch showing icons for calendar date, incoming calls, information reminders, and alarm clock functions.

5.3. Remote Camera Control

The watch extends the shutter function to allow remote photography on your mobile phone within a 10-meter range. This is useful for taking group photos or selfies without needing to hold your phone.

ONE TOUCH REMOTE PHOTOGRAPHY

The shutter function has been extended to smart watches for taking photos on mobile phones within 10 meters



Image 5.2: The Alfawise EX17S Smart Watch demonstrating its remote photography feature, allowing users to trigger their phone's camera from the watch.

5.4. Alarm and Stopwatch

Utilize the watch's built-in alarm function for reminders and the stopwatch for timing activities. These functions are accessible via the MODE button.

5.5. Social Share

Through the "Sports +" app, you can share your sports activity data with friends. This feature allows you to connect and share your progress at any time, regardless of your location.

6. CARE AND MAINTENANCE

6.1. Water Resistance

The Alfawise EX17S Smart Watch has an IP67 rating, meaning it is waterproof up to 50 meters. This allows for use during swimming and in rainy conditions. However, it is not suitable for hot water activities like showering or sauna, as steam can penetrate the seals.

6.2. Battery Replacement

When the watch displays a low battery reminder, it is time to replace the CR2450 button battery. Refer to section 3.1 for detailed instructions on battery installation.

6.3. Cleaning

To maintain the watch's appearance and functionality, regularly clean the watch case and band with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials that could damage the finish.

7. TROUBLESHOOTING

- **Watch not powering on:** Ensure the CR2450 battery is correctly installed and has sufficient charge. Replace the battery if necessary.
- **Bluetooth connectivity issues:**
 - Ensure Bluetooth is enabled on both the watch and your smartphone.
 - Make sure the watch is within the 10-meter Bluetooth range of your phone.
 - Restart both the watch and your smartphone, then attempt to re-pair.
 - Check the "Sports +" app for any specific connection instructions or troubleshooting tips.
- **Notifications not appearing:**
 - Verify that the watch is successfully paired with your smartphone.
 - Check notification settings within the "Sports +" app to ensure desired app notifications are enabled.
 - Ensure your smartphone's notification permissions allow the "Sports +" app to access and forward notifications.
- **Inaccurate Pedometer readings:** Ensure the watch is worn securely on your wrist. Calibrate the pedometer within the "Sports +" app if available.

8. SPECIFICATIONS

Feature	Detail
Brand	Alfawise
Model Number	EX17S
Bluetooth Version	Bluetooth 4.0
Built-in Chip Type	SI - BW03
IP Rating	IP67 (50M Waterproof)
Alert Type	Beeping, Vibration
Health Tracker	Pedometer
Notification Types	Facebook, G-mail, Skype, Twitter, WeChat, WhatsApp, Phone Call Reminder, Message Reminder

Feature	Detail
Remote Control Function	Remote Camera
Operating Mode	Press button
Battery Type	CR2450 button battery (610mAh)
Standby Time	Up to 540 days (approx. 18 months)
Band Material	TPU (Thermoplastic Polyurethane)
Case Material	Diamond Carbon Coating
Dial Shape	Round
Display Type	Digital (FSTN full angle display)
Compatibility	Android 4.4 / iOS 8.0 and above systems
Product Weight	0.0650 kg
Product Dimensions (L x W x H)	5.50 x 27.00 x 1.40 cm / 2.17 x 10.63 x 0.55 inches

9. WARRANTY AND SUPPORT

Information regarding product warranty and customer support is not available in the provided product data. Please refer to the official Alfawise website or your point of purchase for warranty details and support contacts.