

SLuB C0303

SLuB 4000mAh Ultra-Thin Mobile Battery Charger User Manual

Model: C0303

1. INTRODUCTION

Thank you for purchasing the SLuB 4000mAh Ultra-Thin Mobile Battery Charger. This portable power bank is designed to provide convenient and reliable charging for your electronic devices on the go. Its compact size, lightweight design, and multiple charging ports make it an ideal companion for daily use, travel, and business trips.

Package Contents:

- SLuB 4000mAh Mobile Battery Unit (Model C0303)
- USB Charging Cable
- Instruction Manual

Note: Product specifications are subject to updates. Newer versions of this product may not include a Micro-B input port. Please refer to the latest product information.

2. SAFETY INFORMATION

For safe and optimal use of your mobile battery charger, please read and follow these safety guidelines:

- This product is **PSE Certified**, ensuring compliance with safety standards for electrical appliances.
- The device incorporates multiple protection features, including **overcharge protection, overvoltage protection, and temperature management**, to prevent overheating and damage to your devices during charging.
- Avoid exposing the battery to extreme temperatures, direct sunlight, or high humidity.
- Do not disassemble, puncture, or modify the battery.
- Keep out of reach of children.
- It is safe to carry this device on airplanes.

3. PRODUCT FEATURES



High Capacity & Compact Design: 4000mAh capacity in an ultra-thin, mini-sized form factor.



Intelligent Fast Charging: Supports up to 2.4A output for quick charging of your devices.



Ultra-Thin & Lightweight: Weighs only 60g with a thickness of 8.5mm, making it highly portable.

低温充電

スマートチップを採用し、低温度のままスマホへ充電します。



Low Temperature Charging: Smart chip ensures charging at low temperatures to prevent overheating.

Ports and Indicators:

- **USB-A Output Port:** For charging various devices.
- **Type-C Input/Output Port:** Functions as both an input for charging the power bank and an output for charging devices.
- **LED Battery Level Indicator:** Four LED lights indicate the remaining battery charge.

拔群な互換性

様々なUSB充電式設備と互換性があります。



Names of Each Part: Power button, LED indicator lights, Micro USB input (*Note: May not be present in new versions*), Type-C input/output, USB-A output.

4. SETUP: INITIAL CHARGING

Before first use, fully charge your SLuB mobile battery.

1. Connect the provided USB charging cable to the Type-C input port on the mobile battery.
2. Connect the other end of the USB cable to a compatible USB wall adapter (not included) or a computer's USB port.
3. The LED indicator lights will illuminate to show the charging progress. All four LEDs will be solid when the battery is fully charged.

It is recommended to fully charge the power bank every three months if not in regular use to maintain battery health.

5. OPERATING INSTRUCTIONS

Charging Your Devices:

1. Connect your device's charging cable to either the USB-A output port or the Type-C output port on the mobile battery.
2. Connect the other end of the cable to your electronic device (e.g., smartphone, tablet).
3. The mobile battery will automatically begin charging your device. The LED indicators will show the remaining battery level.
4. To stop charging, simply disconnect your device from the power bank.

PORTABLE SOURCE

×

外出の必須アイテム

超便利

厚さ僅か
8.5mm



残電量表示

POWER DISPLAY



2つの入力

TWO INPUT PORTS



急速充電

QUICK CHARGE

Wide Compatibility: Charges a variety of devices including iPhones, iPads, Android phones, and more.

Checking Battery Level:

Press the power button once to activate the LED indicator lights. The number of illuminated LEDs indicates the remaining charge:

- **4 LEDs:** 76% - 100% charge
- **3 LEDs:** 51% - 75% charge
- **2 LEDs:** 26% - 50% charge
- **1 LED:** 0% - 25% charge

小型で大容量

4000mAhの大容量、スマホの充電ニーズに対応します！



LED Display: Clearly shows remaining battery at a glance.

6. MAINTENANCE

- Clean the exterior of the power bank with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- Avoid dropping or subjecting the power bank to strong impacts.
- Do not block the charging ports or vents during use.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Device not charging	Low battery on power bank; Loose cable connection; Incompatible cable/device.	Recharge the power bank; Ensure cables are securely connected; Try a different cable or device.
Power bank not charging	Loose cable connection; Faulty wall adapter; Cable damage.	Ensure cable is securely connected to Type-C input; Try a different wall adapter; Use a different charging cable.
Slow charging	Cable quality; Device input limit; High ambient temperature.	Use a high-quality charging cable; Ensure device supports fast charging; Charge in a cooler environment.
LEDs not lighting up	Battery completely drained; Power button not pressed.	Charge the power bank; Press the power button once to check the status.

8. SPECIFICATIONS

製品仕様



製品名	モバイルバッテリー	型番	C0303
カラー	ブラック、ホワイト	容量	4000mAh
電量表示	あり	質量	60g
入力	5V/2.4A	出力	5V/2.4A
外形寸法	53×85×8.5mm	タイプ	リチウム電池

Product Specifications: Model C0303, 4000mAh capacity, 60g weight, 8.5 x 5.3 x 0.8 cm dimensions.

Feature	Detail
Model Number	C0303
Battery Capacity	4000mAh
Battery Type	Lithium Polymer
Input (Type-C)	5V / 2.4A
Output (USB-A)	5V / 2.4A
Output (Type-C)	5V / 2.4A
Dimensions (L x W x H)	8.5 x 5.3 x 0.8 cm
Weight	60g
Color	Black (also available in White)
Safety Certification	PSE Certified

9. WARRANTY AND SUPPORT

Warranty Information:

This product comes with a **3-month warranty** from the date of purchase. Your order number serves as your warranty certificate. Please retain your purchase record for warranty claims.

The warranty covers manufacturing defects. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

Customer Support:

If you encounter any issues or have questions regarding your SLuB mobile battery charger, please contact the retailer or manufacturer's customer support. For the fastest service, please have your order number and product model (C0303) ready.