



[Manuals.plus](#) /

› [ANYOO](#) /

› ANYOO Cotton Hammock Instruction Manual

ANYOO AY-C-H-270150

ANYOO Cotton Hammock Instruction Manual

Model: AY-C-H-270150

PRODUCT OVERVIEW

The ANYOO Cotton Hammock is designed for comfortable and relaxing use in various outdoor and indoor settings. It features a tightly-woven fabric for support and comfort, an anti-rollover design for stability, and a complete suspension system for easy setup.



Image: The ANYOO Cotton Hammock in Blue/White/Red Stripe, shown with its included travel bag, two carabiners, and two tree-friendly suspension straps.

Key Features:

- **Comfortable Material:** Tightly-woven cotton fabric conforms to body shape, reducing pressure points. Colorfast and resistant to wear and tear.
- **High Weight Capacity:** Supports up to 660 pounds.
- **Anti-rollover Design:** Features a longer side (bottom) and shorter side (top) for a flatter sleeping surface and enhanced stability.
- **Complete Suspension System:** Includes tree-friendly high-density nylon straps and 2 carabiners for easy setup and takedown without tree damage.
- **Compact & Portable:** Easy to carry and store in the breathable storage bag, ideal for travel, hiking, and various outdoor/indoor locations.

SAFETY INFORMATION

WARNING: Maximum weight capacity 660 lbs. Ensure proper and secure installation using provided tree straps

and carabiners. Do not exceed weight limit. Adult supervision recommended.

Always inspect the hammock, straps, and carabiners for any signs of wear or damage before each use. Do not use if any components are compromised. Ensure the hanging points are stable and capable of supporting the maximum weight capacity.

SETUP INSTRUCTIONS

Components Included:

- 1 x ANYOO Cotton Hammock
- 1 x Storage Bag
- 2 x Hanging Straps (Tree-Friendly Nylon)
- 2 x Carabiners




Image: Visual representation of the hammock's dimensions (9ft/270cm length, 5ft/150cm width) and the included items: storage bag, hammock, two hanging straps, and two carabiners.

Method 1: Hanging Between Two Trees

1. **Select Suitable Trees:** Choose two sturdy trees that are approximately 10-15 feet apart. Ensure the trees are healthy and strong enough to bear the weight.
2. **Attach Tree Straps:** Wrap one hanging strap around each tree at a height that allows the hammock to hang comfortably (typically 4-6 feet from the ground). Pass one end of the strap through the loop on the other end, pulling it tight against the tree.
3. **Connect Carabiners:** Attach one carabiner to the loop at the end of each tree strap.
4. **Hook Hammock:** Connect the knotted ends of the hammock to the carabiners. Ensure both ends are securely fastened.
5. **Test Stability:** Before fully entering, gently test the hammock's stability and ensure all connections are secure. The lowest point of the hammock should be about 18 inches off the ground when in use.




Image: A detailed view of the hammock's knotted end connected to a carabiner, which is then attached to a suspension point. This illustrates the secure attachment mechanism.

WHY CHOOSE US?

ANYOO



100% No-Stretch Polyester



Tree-Friendly



No Need to Tie Knots



No Sag to Ground



OTHERS




Ropes



Damage Tree



Tie Knots



Will Sag After Bearing Weight



Image: A visual comparison highlighting the benefits of ANYOO's 100% no-stretch polyester tree-friendly straps (left) which prevent tree damage and do not require knots, versus traditional ropes (right) that can damage trees and require complex knots.

Method 2: Using a Hammock Stand (Stand Not Included)

1. **Assemble Stand:** Follow the manufacturer's instructions to assemble your hammock stand.
2. **Attach Hammock:** Hook the knotted ends of the hammock directly onto the hooks or attachment points of your hammock stand.
3. **Verify Security:** Ensure the hammock is securely attached to both ends of the stand before use.



Image: A person comfortably lounging in an ANYOO hammock set up on a metal stand in an outdoor patio setting, demonstrating typical use with a stand.

OPERATING INSTRUCTIONS

Once your ANYOO Cotton Hammock is securely set up, it's ready for use. Follow these guidelines for optimal comfort and safety:

- **Entering the Hammock:** Approach the hammock from the center. Gently sit down in the middle, allowing the fabric to cradle your body.
- **Positioning:** For maximum comfort and to utilize the anti-rollover design, lie diagonally across the hammock. This creates a flatter, more stable surface.
- **Exiting the Hammock:** Carefully swing your legs out and place your feet on the ground before standing up.
- **Usage Environment:** The hammock is suitable for various environments including backyard, patio, porch, garden, and indoor use. It can also be used for camping trips.

SUPPORTING RING IS SUPERFLUOUS

✓ Consistent & Even weaving

✓ Secure knots or stitching



Image: A close-up of a person's legs resting in the hammock, emphasizing the comfortable and versatile lounging experience it offers in various settings like home, garden, poolside, beach, campsite, or patio.

MAINTENANCE AND CARE

Proper care and maintenance will extend the life of your ANYOO Cotton Hammock. Follow these instructions to keep your hammock in excellent condition:

- **Cleaning:** The hammock can be cleaned by hand washing or machine washing. Use a mild detergent and cold water.
- **Drying:** Air dry the hammock completely before storing to prevent mildew. Do not tumble dry.
- **Storage:** When not in use, especially during rain or prolonged direct sunlight, store your hammock in the breathable storage bag provided. This prevents deterioration of the fabric and color fading.
- **Inspection:** Regularly inspect the hammock fabric, ropes, straps, and carabiners for any signs of wear, fraying, or damage. Replace any damaged components immediately.



Image: A close-up showing the high-quality fabric of the hammock, emphasizing its high density, durability, and breathability, which contribute to its comfort and longevity.

TROUBLESHOOTING

If you encounter any issues with your ANYOO Cotton Hammock, refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
Hammock sags too much or touches the ground.	Hanging points are too low or too far apart.	Raise the hanging points or move them closer together. The ideal sag allows the hammock to be about 18 inches off the ground when occupied.
Hammock feels unstable or rolls easily.	Incorrect entry/exit or improper lying position.	Ensure you enter from the center and lie diagonally across the hammock to engage the anti-rollover design.

Problem	Possible Cause	Solution
Fabric appears faded or discolored.	Prolonged exposure to direct sunlight or harsh weather.	Always store the hammock in its bag when not in use, especially during adverse weather conditions or intense sun.
Difficulty attaching carabiners to straps/stand.	Carabiner gate is stiff or misaligned.	Ensure the carabiner gate opens and closes smoothly. Apply a small amount of lubricant if necessary. Do not force.

SPECIFICATIONS

- **Brand:** ANYOO
- **Model Number:** AY-C-H-270150
- **Product Dimensions:** 106.3"L x 59.06"W (270cm x 150cm)
- **Item Weight:** 1.43 pounds
- **Material:** Cotton Fabric, High-density Nylon Straps
- **Maximum Weight Capacity:** 660 lbs
- **Color:** Blue/White/Red Stripe (as per current product variant)
- **UPC:** 709016377334

OFFICIAL PRODUCT VIDEOS

Watch these official videos for additional guidance on setting up and using your ANYOO Cotton Hammock.

No official seller videos are available for this product at this time.

WARRANTY AND SUPPORT

For warranty information or product support, please contact ANYOO customer service through the retailer where you purchased the product or visit the official ANYOO brand store on Amazon:

[Visit the ANYOO Store on Amazon](#)

Please retain your proof of purchase for any warranty claims.