Pure Enrichment PESPAPOR

Pure Enrichment PureSpa Go Portable Car Diffuser Instruction Manual

Product Overview

The Pure Enrichment PureSpa Go is a portable ultrasonic aroma diffuser designed to freshen small spaces such as cars, offices, or homes. It utilizes ultrasonic technology to create a fine mist, dispersing essential oil and water microparticles into the air. This compact diffuser features an optional color-changing light and an automatic shut-off function for safety and convenience.



Image: The PureSpa Go diffuser positioned in a car's cup holder, actively releasing a fine mist.



Image: The PureSpa Go diffuser on an office desk, demonstrating its versatility for various environments.

Safety Information

Please read and understand all safety instructions before using the PureSpa Go diffuser.

- Avoid direct skin contact with undiluted essential oils.
- Keep out of reach of children and pets.
- Ensure proper ventilation during use.
- Do not exceed the maximum water fill line.
- Use only clean tap water or distilled water.
- Do not operate the diffuser if it is damaged.
- Unplug the diffuser when not in use or before cleaning.

Package Contents

Verify that all items are present in the package:

- Ultrasonic aroma diffuser (PureSpa Go)
- USB power cable
- Cleaning brush
- Instruction Manual



Image: The PureSpa Go diffuser along with its included USB power cable and cleaning brush.

Setup

Follow these steps to set up your PureSpa Go diffuser:

1. **Unpack the Diffuser:** Carefully remove the diffuser and all accessories from its packaging.
2. **Remove the Cover:** Gently twist and lift the top cover of the diffuser to access the water tank.
3. **Fill the Water Tank:** Using a measuring cup, fill the 50mL water tank with clean tap water or distilled water up to the indicated MAX line. Do not overfill.
4. **Add Essential Oil:** Add 3-5 drops of your preferred essential oil directly into the water tank. Adjust the number of drops based on desired aroma intensity.
5. **Replace the Cover:** Securely place the top cover back onto the diffuser, ensuring it is properly aligned.
6. **Connect Power:** Plug the USB power cable into the diffuser's power port and connect the other end to a compatible USB power source (e.g., car USB port, wall adapter, power bank).
7. **Position the Diffuser:** Place the diffuser in a stable location, such as a car cup holder, office desk, or bedside table.



Image: A detailed view of the diffuser's top, showing the mist outlet and the power button.

Operating Instructions

Once set up, operate your PureSpa Go diffuser as follows:

- **Power On/Off:** Press the power button once to turn on the diffuser. Press it again to turn off the diffuser.
- **Mist Output:** The diffuser will immediately begin producing a continuous mist.
- **Color-Changing Light:** The diffuser features an optional color-changing light that rotates through a spectrum of

colors. This light activates automatically when the diffuser is turned on. To turn off the light while the diffuser is still misting, press and hold the power button for 2 seconds. To turn the light back on, press and hold the power button for 2 seconds again.

- **Automatic Shut-Off:** The diffuser will automatically shut off when the 50mL water tank is nearly empty. This feature helps prevent damage to the unit and ensures safety. The diffuser can operate for up to 4 hours on a full tank.



Image: The PureSpa Go diffuser displaying its optional color-changing light feature.

Maintenance

Regular cleaning ensures optimal performance and extends the lifespan of your diffuser.

1. **Daily Cleaning:** After each use, empty any remaining water from the tank. Wipe the inside of the water tank with a clean, soft cloth.
2. **Weekly Cleaning:**
    - Unplug the diffuser from the power source.
    - Remove the top cover.
    - Add a small amount of warm water (not hot) and a few drops of white vinegar to the water tank.
    - Let it sit for 10-15 minutes to loosen any mineral buildup or essential oil residue.
    - Use the provided cleaning brush or a cotton swab to gently clean the ultrasonic plate (the small disc at the bottom of the tank). Avoid scrubbing aggressively.
    - Pour out the water and vinegar mixture.
    - Rinse the tank thoroughly with clean water, being careful not to get water into the air outlet.
    - Wipe the tank dry with a soft cloth.
    - Wipe the exterior of the diffuser with a soft, damp cloth.
3. **Storage:** If storing the diffuser for an extended period, ensure it is clean and completely dry. Store it in a cool, dry place.

Important: Do not immerse the diffuser in water. Do not use harsh detergents or abrasive cleaners.

Troubleshooting

If you encounter issues with your PureSpa Go diffuser, refer to the following common solutions:

Problem	Possible Cause	Solution
No mist is being produced.	Low water level; Diffuser not plugged in; Ultrasonic plate dirty.	Ensure water is above the minimum level; Check USB connection; Clean the ultrasonic plate as per maintenance instructions.
Weak mist output.	Insufficient water; Mineral buildup on ultrasonic plate; Diffuser placed on an uneven surface.	Refill water to the MAX line; Clean the ultrasonic plate; Place diffuser on a flat, stable surface.
Diffuser leaks water.	Overfilled water tank; Cover not properly secured; Diffuser tilted or knocked over.	Do not exceed the MAX fill line; Ensure the cover is tightly closed; Keep the diffuser upright and stable.
Light not working.	Light function turned off; Power issue.	Press and hold the power button for 2 seconds to toggle the light; Check power connection.
No power.	USB cable not connected; Faulty power source.	Ensure USB cable is securely connected to both the diffuser and the power source; Try a different USB port or adapter.

If the problem persists after attempting these solutions, please contact customer support.

Specifications

- **Model Name:** PureSpa Go
- **Model Number:** PESPAPOR
- **Dimensions (L x W x H):** 2.8" x 2.8" x 4.6" (7.1 cm x 7.1 cm x 12 cm)
- **Water Tank Capacity:** 50 ml
- **Runtime:** Up to 4 hours
- **Coverage Area:** Up to 107 sq ft (10 square meters)
- **Power Source:** USB (Corded Electric)
- **Wattage:** 5 watts
- **Special Features:** Automatic Shut-Off, Portable, Optional Color-Changing LED Light
- **Material:** Plastic
- **Color:** White

Warranty and Support

The Pure Enrichment PureSpa Go Portable Car Diffuser comes with a**5-Year Warranty**, ensuring quality and peace of mind. Our dedicated customer support team is available to assist you with any questions or concerns.
For warranty claims, technical assistance, or general inquiries, please visit the official Pure Enrichment website or contact their customer service directly.
You can find more information and support resources by visiting thePure Enrichment Store on Amazon.

© 2024 Pure Enrichment. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question