



Manuals.plus /

- › AIMOS /
- › AIMOS USB Volume Controller Knob User Manual

AIMOS TIMEUSBTY-QHEI

AIMOS USB Volume Controller Knob User Manual

Model: TIMEUSBTY-QHEI

INTRODUCTION

Thank you for choosing the AIMOS USB Volume Controller Knob. This device provides a convenient and precise way to adjust the audio volume of your computer or compatible Android phone. Designed for ease of use, it features a durable aluminum shell and a responsive rotary knob for seamless control. This manual will guide you through the setup, operation, and maintenance of your new volume controller.



Image: The AIMOS USB Volume Controller Knob, showcasing its compact design and included USB cable.

PACKAGE CONTENTS

Please verify that all items listed below are included in your package:

- 1 x AIMOS USB Volume Controller Knob
- 1 x USB Cable (2 meters)
- 1 x User Manual (English)



Image: Contents of the product package, showing the volume controller, USB cable, and user manual.

SPECIFICATIONS

Feature	Detail
Brand	AIMOS
Model Number	TIMEUSBTY-QHEI
Material	Aluminum Shell
Color	Black
Dimensions (L x W x H)	65 x 49 x 39 mm
USB Cable Length	2 meters
Connectivity	USB
Power Source	Electric Cable (USB Powered)
Control Type	Rotary Knob with Push Button



Image: Detailed dimensions of the AIMOS USB Volume Controller Knob (Length: 65mm, Width: 49mm, Height: 39mm) and its 2-meter USB cable.

SETUP

The AIMOS USB Volume Controller Knob is designed for plug-and-play functionality. No drivers or additional software are required for most operating systems.

1. **Connect to PC:** Insert the USB cable from the volume controller into an available USB port on your computer.
2. **Audio Output (Optional):** If your audio output device (e.g., speakers, headphones) is connected to your computer's 3.5mm earphone jack, ensure it is properly connected. The volume controller will adjust the system volume.
3. **For Android Phones (with OTG):** If using with an Android phone, connect the volume controller via an OTG (On-The-Go) cable (not included).

USB Volume Regulator

Use this product in full screen mode
Turn the button to adjust the volume.

You can not adjust the volume by
the mouse when in the full screen mode



Image: The USB volume controller connected to a laptop, demonstrating its use for adjusting system volume, even in full-screen applications.

OPERATING INSTRUCTIONS

The volume controller offers intuitive operation for managing your audio levels.

Basic Operation

- **Adjust Volume:** Rotate the knob clockwise to increase the volume and counter-clockwise to decrease the volume. The ALPS rotary shaft supports 30 anchor points per turn for precise adjustment.
- **Mute/Unmute:** Press the knob once to instantly mute the audio. Press it again to unmute and resume playback.
- **Quick Adjustment:** Press and hold the knob while rotating to quickly adjust the volume.

Usage mode

360 Degree Rotation
To Adjust The Volume

Press the button to
mute/cancel the mute




Image: Visual guide demonstrating the rotation of the knob for volume adjustment and pressing the knob for mute/unmute functionality.

LED Indicator

- The blue LED light under the knob will illuminate when the device is in use or being rotated.
- If the knob is not rotated for 15 seconds, the LED light will automatically turn off to conserve power and reduce distraction.

COMPATIBILITY

The AIMOS USB Volume Controller Knob is compatible with a wide range of operating systems:

- Windows 10

- Windows 8
- Windows 7
- Windows Vista
- Windows XP
- macOS (Mac)
- Android (with OTG cable)

Ours



A USB cable can be connected, 360 degrees arbitrary rotation to adjust the volume, blue breathing lamp, easy to use, plug and play

Other



360 degree rotation is not supported, the connection line is not easy to arrange, many interface, and the plastic material is not durable

Compatible system

Android Mac OS

Windows XP Win 7/8/9 Windows 10

Image: Overview of compatible operating systems, including Android, macOS, and various Windows versions.

MAINTENANCE AND CARE

To ensure the longevity and optimal performance of your volume controller, follow these simple care guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the device. Avoid using abrasive cleaners or solvents.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Avoid dropping the device or subjecting it to strong impacts, as this may damage internal components.

TROUBLESHOOTING

If you encounter any issues with your AIMOS USB Volume Controller Knob, please refer to the following common solutions:

Problem	Possible Solution
Device not recognized / Not working	<ul style="list-style-type: none">◦ Ensure the USB cable is securely connected to both the controller and the computer.◦ Try connecting the controller to a different USB port on your computer.◦ Restart your computer.◦ Verify that your operating system is supported (Windows XP/Vista/7/8/10, macOS, Android with OTG).
Volume adjustment is erratic or jumps	<ul style="list-style-type: none">◦ Avoid rotating the knob too quickly. The device is designed for smooth, precise adjustments.◦ Ensure no other software or hardware is interfering with system volume control.
LED light does not illuminate	<ul style="list-style-type: none">◦ The LED light turns off after 15 seconds of inactivity. Rotate the knob or press it to reactivate the light.◦ Check USB connection.

WARRANTY AND SUPPORT

Information regarding product warranty and specific support contacts is typically provided by your retailer or included with your purchase documentation. Please refer to those resources for details on warranty coverage and how to obtain technical support.