

## VicTsing Wood Grain Essential Oil Diffuser

# VicTsing Wood Grain Essential Oil Diffuser User Manual

Model: Wood Grain Essential Oil Diffuser

## 1. INTRODUCTION

---

Thank you for choosing the VicTsing Wood Grain Essential Oil Diffuser. This manual provides important information regarding the safe operation, setup, maintenance, and troubleshooting of your new aromatherapy diffuser. Please read this manual thoroughly before using the product and retain it for future reference.

## 2. SAFETY INSTRUCTIONS

---

To ensure safe operation and prevent damage to the product or injury to yourself, please observe the following safety precautions:

- Always place the diffuser on a stable, flat, and water-resistant surface.
- Do not place the diffuser near heat sources, direct sunlight, or on electronic devices.
- Use only clean tap water or distilled water. Do not use purified water or mineral water.
- Do not exceed the maximum water level indicated inside the water tank.
- Only use 100% pure, natural essential oils. Avoid corrosive or chemical-based oils.
- Keep out of reach of children and pets.
- Unplug the diffuser from the power outlet before cleaning or when not in use for extended periods.
- Do not touch the ultrasonic vibrating plate directly with your fingers or sharp objects.
- If the diffuser emits an unusual smell or sound, or if smoke appears, unplug it immediately.
- Do not block the mist outlet.

## 3. PACKAGE CONTENTS

---

Please check the package contents upon unboxing:

- 1 x VicTsing Wood Grain Essential Oil Diffuser

- 1 x AC Adapter
- 1 x Measuring Cup
- 1 x User Manual

## 4. PRODUCT OVERVIEW

---

Familiarize yourself with the components of your diffuser:



*Image 1: Components of the VicTsing Wood Grain Essential Oil Diffuser. This diagram illustrates the top cover, water tank, mist outlet, light button, mist button, and power input.*

- **Top Cover:** Removable cover for accessing the water tank.
- **Water Tank:** Reservoir for water and essential oils.
- **Mist Outlet:** Where the aromatherapy mist is released.
- **Light Button:** Controls the LED light functions.
- **Mist Button:** Controls the mist output and timer settings.
- **Air Outlet:** Ensures proper airflow.
- **Power Input:** Connects to the AC adapter.
- **Ultrasonic Plate:** Located at the bottom of the water tank, responsible for mist generation.

## 5. SETUP

---

Follow these steps for initial setup:

1. Place the diffuser on a flat, stable surface.
2. Remove the top cover by lifting it upwards.
3. Connect the AC adapter to the power input port at the bottom of the diffuser. Then, plug the adapter into a wall outlet.
4. Using the measuring cup, fill the water tank with clean tap water or distilled water up to the maximum water level line (150ml). Do not overfill.
5. Add 3-5 drops of 100% pure essential oil directly into the water tank. Adjust the amount based on personal preference and room size.
6. Replace the top cover, ensuring it is securely seated.



*Image 2: Setup process for the VicTsing Wood Grain Essential Oil Diffuser. This image shows the steps of removing the cover, adding water and essential oil, and replacing the cover.*

## 6. OPERATING INSTRUCTIONS

---

Once set up, operate your diffuser using the two buttons:

### Mist Button (Left Button)

- **1st Press:** Continuous mist mode. The diffuser will operate until the water runs out.
- **2nd Press:** 1-hour timer mode. The diffuser will operate for 1 hour and then automatically shut off.
- **3rd Press:** 3-hour timer mode. The diffuser will operate for 3 hours and then automatically shut off.

- **4th Press:** 6-hour timer mode. The diffuser will operate for 6 hours and then automatically shut off.
- **5th Press:** Turn off the mist function.
- The diffuser features an automatic shut-off function when water runs out, regardless of the timer setting.

### Light Button (Right Button)

- **1st Press:** Turn on the LED light, which will cycle through 8 colors automatically.
- **2nd Press:** Fix the light to its current color.
- **Subsequent Presses:** Cycle through the 8 available colors to select your desired fixed color.
- **Long Press (2 seconds):** Turn off the light function.

## 7. MAINTENANCE

Regular cleaning helps ensure optimal performance and extends the lifespan of your diffuser. Clean the diffuser after every 5-6 uses or every 3-5 days.

1. Unplug the diffuser from the power outlet.
2. Remove the top cover and drain any remaining water from the water tank. Ensure to drain from the side opposite the air outlet to prevent water from entering internal components.
3. Add a small amount of warm water (not hot) and 1-2 drops of neutral detergent to the water tank.
4. Gently wipe the inside of the water tank and the ultrasonic plate with a soft cloth or cotton swab. Do not scrub aggressively.
5. Rinse the water tank with clean water, again avoiding the air outlet side.
6. Wipe the exterior of the diffuser with a soft, dry cloth.
7. Allow all parts to air dry completely before reassembling or storing.

**Important:** Do not use corrosive cleaners, alcohol, or harsh chemicals. Do not immerse the diffuser base in water.

## 8. TROUBLESHOOTING

If you encounter issues with your diffuser, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No mist or low mist output.	<ul style="list-style-type: none"> <li>Insufficient water in the tank.</li> <li>Water level too high.</li> <li>Ultrasonic plate is dirty.</li> <li>Mist outlet blocked.</li> <li>Diffuser not plugged in.</li> </ul>	<ul style="list-style-type: none"> <li>Add water to the appropriate level.</li> <li>Drain excess water.</li> <li>Clean the ultrasonic plate as per maintenance instructions.</li> <li>Ensure the mist outlet is clear.</li> <li>Check power connection.</li> </ul>
Diffuser leaks water.	<ul style="list-style-type: none"> <li>Overfilled water tank.</li> <li>Top cover not properly seated.</li> <li>Diffuser placed on an uneven surface.</li> </ul>	<ul style="list-style-type: none"> <li>Do not exceed the MAX water line.</li> <li>Ensure the top cover is securely in place.</li> <li>Place the diffuser on a flat, stable surface.</li> </ul>

Problem	Possible Cause	Solution
Light not working.	Light function is off. Power issue.	Press the Light button to turn on. Check power connection.
Unusual noise.	Insufficient water. Diffuser not on a flat surface.	Add water. Ensure the diffuser is on a flat, stable surface.

## 9. SPECIFICATIONS

Feature	Detail
Brand Name	VicTsing
Model	Wood Grain Essential Oil Diffuser
Material Type	Wood (finish)
Power Source	Corded Electric
Automatic Shutoff	Yes (Waterless Auto Shut-off)
Light Source	LED (8 Color LED Lights)
Additional Features	Silent Operation
Recommended Uses	Home, Office

## 10. WARRANTY AND SUPPORT

VicTsing products are designed and manufactured to the highest quality standards. For warranty information, technical support, or customer service inquiries, please refer to the contact information provided on the product packaging or visit the official VicTsing website. Please have your product model name and purchase date available when contacting support.