

DALI Katch G2

DALI Katch G2 Portable Bluetooth Speaker User Manual

Model: Katch G2

INTRODUCTION

Thank you for choosing the DALI Katch G2 Portable Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker. Please read it thoroughly before use to ensure optimal performance and longevity of your device.



Image: Front view of the DALI Katch G2 Portable Bluetooth Speaker in Caramel White.

SAFETY INFORMATION

- Do not expose the speaker to water or excessive moisture. This product is not waterproof.
- Avoid placing the speaker near heat sources or in direct sunlight for extended periods.
- Use only the charger supplied with the product.
- Do not attempt to disassemble or modify the speaker. Refer all servicing to qualified personnel.
- Keep out of reach of children.

PACKAGE CONTENTS

Verify that all items are present in the packaging:

- DALI Katch G2 Portable Bluetooth Speaker
- Power Adapter/Charger
- Quick Start Guide (not included in this manual)
- Travel Pouch (may vary by region)

PRODUCT OVERVIEW

The DALI Katch G2 features a sleek design with intuitive controls and various connectivity options.

Controls and Indicators



Image: Top panel of the DALI Katch G2 showing power, Bluetooth, volume, and sound mode buttons.

- **Power Button:** Press to turn the speaker on or off.
- **Bluetooth Button:** Press to enter pairing mode.
- **Volume Buttons (+/-):** Adjust the playback volume.
- **Sound Mode Button:** Cycle through available sound profiles.
- **Battery Indicator Lights:** Display current battery level.

Ports and Connections



Image: Side panel of the DALI Katch G2 showing the charging port and auxiliary input.

- **Charging Port:** Connect the power adapter to the charging port on the speaker.
- **3.5mm Auxiliary Input:** Connect external audio sources via a stereo mini-jack cable.

Internal Components



Image: Exploded view illustrating the internal components of the DALI Katch G2 speaker, including drivers and circuit board.

SETUP

1. Charging the Battery

1. Connect the supplied power adapter to the charging port on the speaker.
2. Plug the power adapter into a wall outlet.
3. The battery indicator lights will illuminate to show charging status. A full charge takes approximately 2 hours.
4. A fully charged battery provides up to 30 hours of playback.

2. Powering On/Off

- To power on, press and hold the **Power Button** until the indicator lights activate.
- To power off, press and hold the **Power Button** again until the indicator lights turn off.

3. Bluetooth Pairing

1. Ensure the speaker is powered on.
2. Press the **Bluetooth Button**. The Bluetooth indicator light will flash, indicating pairing mode.
3. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.

4. Select "DALI Katch G2" from the list.
5. Once connected, the Bluetooth indicator light will glow solid.

4. Analog Connection

- Connect a 3.5mm stereo mini-jack cable from your audio source to the Auxiliary Input port on the speaker.
- The speaker will automatically switch to auxiliary input mode.

5. True Wireless Stereo (TWS) Pairing

Two DALI Katch G2 speakers can be paired together for a stereo sound experience.

1. Ensure both DALI Katch G2 speakers are powered on and not connected to any other Bluetooth device.
2. On one speaker (this will be the primary speaker), press and hold the **Bluetooth Button** until it enters pairing mode.
3. On the second speaker, press the **Bluetooth Button** once.
4. The speakers will automatically connect to each other. The primary speaker's Bluetooth indicator will glow solid, and the secondary speaker's indicator will also confirm connection.
5. Now, connect your audio source to the primary speaker via Bluetooth as described in step 3.



Image: Two DALI Katch G2 speakers set up for True Wireless Stereo pairing in a home environment.

OPERATING THE SPEAKER

1. Audio Playback

- Once connected via Bluetooth or auxiliary input, start playback from your audio source.
- Use the **Volume Buttons (+/-)** on the speaker or your connected device to adjust the volume.

2. Sound Modes

The DALI Katch G2 offers different sound profiles to suit your listening preference or environment.

- Press the **Sound Mode Button** to cycle through the available sound modes (e.g., "Clear" and "Warm").
- Each mode provides a distinct audio characteristic.

3. Checking Battery Level

- Briefly press the **Power Button** when the speaker is on to illuminate the battery indicator lights, showing the current charge level.

MAINTENANCE

1. Cleaning

- Wipe the speaker with a soft, dry cloth.
- Do not use abrasive cleaners, waxes, or solvents.

2. Storage

- When not in use for extended periods, store the speaker in a cool, dry place.
- Avoid extreme temperatures.

3. Battery Care

- To prolong battery life, avoid fully discharging the battery frequently.
- Charge the speaker regularly, even if not in frequent use.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Battery is depleted.	Connect the speaker to the power adapter and charge it.
No sound from speaker.	Volume is too low or muted. Incorrect input source selected. Device not paired correctly.	Increase volume on speaker and connected device. Ensure correct input (Bluetooth/Aux) is active. Re-pair the Bluetooth device.
Bluetooth pairing fails.	Speaker is not in pairing mode. Device is too far from speaker. Interference.	Press the Bluetooth button to enter pairing mode. Move device closer to the speaker. Move away from other wireless devices.
True Wireless Stereo (TWS) pairing fails.	Speakers not in TWS pairing mode. One speaker already connected to a device.	Ensure both speakers are disconnected from other devices and follow TWS pairing steps.

SPECIFICATIONS

Model Name	DALI Katch G2
Brand	DALI
Speaker Type	Portable Bluetooth Speaker
Connectivity Technology	Bluetooth 5.0 (apt-X, apt-X HD, AAC)
Audio Output Mode	Stereo
Speaker Maximum Output Power	25 Watts
Battery Capacity	3300 mAh
Battery Life	Up to 30 hours
Charging Time	Approximately 2 hours
Woofers Diameter	3.5 Inches
Tweeter Diameter	21 Millimeters
Product Dimensions (D x W x H)	1.8" x 10.5" x 5.4"
Item Weight	2.42 pounds (1.1 Kilograms)
Control Method	Touch
Waterproof	No

WARRANTY INFORMATION







The DALI Katch G2 Portable Bluetooth Speaker comes with a **Limited Warranty**. Specific terms and conditions of the warranty may vary by region and retailer. Please retain your proof of purchase for warranty claims. For detailed warranty information, refer to the documentation provided with your purchase or visit the official DALI website.

CUSTOMER SUPPORT

If you encounter any issues not covered in this manual or require further assistance, please contact DALI customer support.

- Visit the official DALI website for support resources, FAQs, and contact information.
- Refer to your product packaging or purchase documentation for specific regional support contacts.

Related Documents - Katch G2

	<p>DALI KATCH G2 Portable Bluetooth Speaker User Manual</p> <p>Comprehensive user manual for the DALI KATCH G2 portable Bluetooth speaker, covering setup, features like True Wireless Stereo and aptX HD, sound modes, connectivity, and technical specifications.</p>
	<p>DALI Touch Panels TD1-S to TD5-S: Features, Specifications, and Operation</p> <p>Comprehensive guide to DALI touch panels TD1-S, TD2-S, TD3-S, TD4-S, and TD5-S, covering features, technical specifications, wiring diagrams, key functions, and DALI address settings for lighting control systems.</p>
	<p>DALI WSR Wireless Subwoofer Receiver Manual - Setup and Operation Guide</p> <p>Comprehensive manual for the DALI WSR Wireless Subwoofer Receiver. Learn how to install, connect, and use the WSR with DALI SOUND HUB and SOUND HUB COMPACT for enhanced audio.</p>
	<p>DALI S25X Thermal Imaging Monocular Quick Start Guide</p> <p>Quick start guide for the DALI S25X series thermal imaging monocular, covering button functions, IR menu configuration, settings, and important usage notes.</p>
	<p>DALI Wall Mounted Touch Panels TD1-4S to TD5-4S User Manual and Technical Guide</p> <p>Comprehensive guide for DALI wall-mounted touch panels (TD1-4S, TD2-4S, TD3-4S, TD4-4S, TD5-4S). Covers features, technical specifications, wiring, operation, RF remote matching, and DALI address settings for single color, dual color, RGB, RGBW, and RGB+CCT lighting control.</p>
	<p>DA-4S 4 Push Button DALI Dimmer - User Manual</p> <p>Comprehensive user manual for the DA-4S 4 Push Button DALI Dimmer. Learn about its features, technical specifications, installation, wiring diagrams, and detailed DALI address setting procedures for unicast, group, scene, and broadcast modes.</p>