

[Manuals.plus](#) /

› [Sun Joe](#) /

› Sun Joe 24V-TB-LTE IONMAX Cordless Compact Turbine Jet Blower User Manual

Sun Joe 24V-TB-LTE

Sun Joe 24V-TB-LTE IONMAX Cordless Compact Turbine Jet Blower

Model: 24V-TB-LTE

Brand: Sun Joe

PRODUCT OVERVIEW

The Sun Joe 24V-TB-LTE IONMAX Cordless Compact Turbine Jet Blower is a portable, battery-powered electric blower designed for efficient yard cleanup. It offers powerful airflow and airspeed for clearing leaves, grass clippings, dirt, and debris from various outdoor surfaces.



Image: The Sun Joe 24V-TB-LTE Jet Blower, shown with its included 2.0-Amp battery and charger. The blower features a black body with green accents and a long nozzle.

Key Features:

- **Powerful 24V Turbine Blower:** 350W motor provides 280 CFM of airflow and 100 MPH airspeed for fast and effective yard cleanup.
- **Cordless Convenience:** Battery-powered operation eliminates the need for cords, offering unrestricted movement.
- **Rapid 30-Minute Charge:** The rechargeable 24V lithium-ion battery fully charges quickly for continuous use.
- **Lightweight & Portable:** Weighing just 5.5 lbs, this blower is easy to carry and maneuver.
- **Versatile Applications:** Ideal for clearing leaves, grass clippings, dirt, and debris from lawns, patios, driveways, and other outdoor areas.

MAKE CLEANUP A BREEZE!



24V Cordless
**Compact Turbine
JET BLOWER**

2.0 Ah Battery + Charger included

Ideal tool for handling various
outdoor chores with ease



**350-Watt
Motor**

Provides 100 mph airspeed
and 280 CFM airflow



**Turbine Airboost
Technology**

Aligns rotor 90°,
turbine-like airflow



**Lightweight
& Portable**

Weighs only 5.5 lbs for
easy handling



**Cordless
Convenience**

Ideal anywhere power
is at a premium



Image: An infographic highlighting the key features of the Sun Joe 24V Cordless Compact Turbine Jet Blower, including its 350-Watt motor, Turbine Airboost Technology, lightweight design, and cordless convenience.

SETUP AND ASSEMBLY

Before first use, ensure all components are present and the battery is fully charged. Assembly of the blower is straightforward and requires minimal effort.

Package Contents:

- Sun Joe 24V-TB-LTE Jet Blower Unit
- 2.0-Ah Lithium-Ion Battery
- Battery Charger
- Upper Blower Tube
- Lower Blower Tube

Assembly Steps:

1. **Attach Blower Tubes:** Align the upper blower tube with the main blower unit and twist to secure. Then, attach the lower blower tube to the upper tube, ensuring a firm connection.
2. **Charge Battery:** Connect the battery charger to a standard electrical outlet. Insert the 2.0-Ah lithium-ion battery into the charger. The battery typically charges in approximately 30 minutes. Refer to the charger's indicator lights for charging status.
3. **Insert Battery:** Once fully charged, slide the battery into the battery compartment on the blower unit until it clicks securely into place.



Image: A close-up view of hands inserting the 2.0-Ah IONMAX battery into the top compartment of the Sun Joe blower, demonstrating the easy battery installation process.

OPERATING INSTRUCTIONS

The Sun Joe Jet Blower is designed for ease of use. Follow these steps for optimal performance.

Starting the Blower:

1. Ensure the battery is fully charged and securely inserted into the blower.
2. Hold the blower firmly with one hand on the main handle.
3. Press and hold the trigger switch to start the blower. Release the trigger to stop.

Using the Blower:

- Direct the blower nozzle towards the debris you wish to clear.
- Use a sweeping motion to gather leaves, grass clippings, and other light debris into piles for easier collection.
- The blower is effective on hard surfaces like patios, driveways, and walkways, and can also be used for light snow removal.



Image: A person wearing gloves and safety glasses operating the Sun Joe blower to clear leaves from a grassy area, demonstrating its effectiveness in outdoor cleanup.

MAKE CLEANUP A BREEZE!


SUNJOE

Turbine Airboost Technology

Aligns rotor at 90°, propelling air powerfully like an airplane turbine

Image: A person holding the Sun Joe blower, highlighting the Turbine Airboost Technology which aligns the rotor at 90 degrees for powerful air propulsion, similar to an airplane turbine.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your Sun Joe Jet Blower.

Cleaning:

- Always remove the battery before cleaning or performing any maintenance.
- Wipe down the exterior of the blower with a damp cloth. Do not use harsh chemicals or abrasive cleaners.
- Ensure the air intake vents and blower nozzle are free from debris to maintain proper airflow.

Battery Care:

- Store the battery in a cool, dry place away from direct sunlight and extreme temperatures.
- For long-term storage, it is recommended to store the battery with a partial charge (around 50%).

- Do not expose the battery to water or moisture.

TROUBLESHOOTING

If you encounter issues with your Sun Joe Jet Blower, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Blower does not start	Battery not charged or not properly inserted.	Ensure battery is fully charged and securely clicked into place.
Reduced airflow	Blower tube or air intake blocked by debris.	Remove battery, then clear any obstructions from the nozzle or air intake vents.
Battery not charging	Charger not plugged in, faulty outlet, or damaged battery/charger.	Check power connection, try a different outlet. If problem persists, contact customer support.

For further assistance, please refer to the official user manual or contact Sun Joe customer support.

SPECIFICATIONS

Attribute	Value
Brand	Sun Joe
Model Name	24V-TB-LTE
Power Source	Battery Powered
Voltage	24 Volts
Air Flow Capacity	280 Cubic Feet Per Minute (CFM)
Speed	100 Miles per Hour (MPH)
Item Weight	4 Pounds (approx. 5.5 lbs with battery)
Product Dimensions	19"L x 6"W x 11"H
Noise Level	74 dB
Included Components	2.0-Ah Battery and Charger, Upper and Lower Blower Tube
UPC	842470112551

MAKE CLEANUP A BREEZE!


SUNJOE



LENGTH

19"

48.2 CM

WIDTH

6"

15.2 CM

HEIGHT

11"

27.9 CM

WEIGHT

5.4

POUNDS

Image: The Sun Joe blower with its key dimensions labeled: 19 inches length, 6 inches width, 11 inches height, and a weight of 5.4 pounds.

WARRANTY AND SUPPORT

For detailed warranty information, please refer to the official product documentation included with your purchase. Sun Joe stands behind the quality of its products.

Additional Resources:

- **Official User Manual (PDF):** [Download PDF Manual](#)
- **Sun Joe Brand Store:** Explore other Sun Joe products and resources at the [Official Sun Joe Store](#).

If you require technical assistance or have questions regarding your product, please contact Sun Joe customer support through their official website or the contact information provided in your product packaging.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07SQB1V52>

More documents and user manuals: <https://manuals.plus/>