

Itel A46

Itel A46 Smartphone User Manual

BRAND: ITEL

Model: A46

1. INTRODUCTION


Welcome to the Itel A46 smartphone user manual. This guide provides essential information on how to set up, operate, maintain, and troubleshoot your device. Please read this manual carefully to ensure optimal performance and longevity of your smartphone.

The Itel A46 is a feature-rich smartphone designed for everyday use, offering a blend of performance, camera capabilities, and security features.

2. DEVICE OVERVIEW



Front and back view of the Itel A46 smartphone, showcasing its design and camera module.



Rear view of the Itel A46, highlighting the dual camera setup and circular fingerprint sensor.

3. SETUP GUIDE

3.1 Inserting SIM Cards and Memory Card

The Itel A46 supports dual SIM cards (micro+nano) and expandable memory up to 128GB. Follow these steps to insert your cards:

1. Locate the SIM/memory card tray on the side of your device.
2. Use the provided SIM ejector tool to open the tray.
3. Carefully place your micro and nano SIM cards into their respective slots.
4. If using a memory card, insert it into the dedicated memory card slot.
5. Gently push the tray back into the device until it clicks into place.

3.2 Initial Power On

After inserting your cards, press and hold the power button until the Itel logo appears. Follow the on-screen instructions to complete the initial setup, including language selection, Wi-Fi connection, and Google account setup.

4. OPERATING INSTRUCTIONS

4.1 Display Features

The Itel A46 features a vibrant display for an immersive viewing experience:

- **Screen Size:** 5.45-inch (13.8 centimeters) TFT IPS multi-touch capacitive touchscreen.
- **Resolution:** 1440 x 720 pixels with 295 ppi pixel density.
- **Color Support:** 16.7 million colors.
- **Design:** Full screen with rounded corners and narrow bezels for a modern look.



The 5.45-inch HD+ IPS FullScreen display of the IteL A46.

4.2 Camera Features

Capture stunning photos and videos with the IteL A46's advanced camera system:

- **Rear Camera:** 8+0.3MP dual rear camera for detailed shots.
- **Front Camera:** 5MP front camera for clear selfies.
- **AI Beauty Mode:** Enhances your portraits for a flawless look.
- **AI Super Night:** Optimizes photos taken in low-light conditions.
- **AI Scenario Detection:** Automatically adjusts camera settings based on the scene (e.g., plant, sky, food).
- **Portrait Mode:** Creates professional-looking photos with bokeh effects, highlighting your subject against a blurred background.

Your browser does not support the video tag.

This video demonstrates the camera features of the IteL A46, including AI Beauty Mode, AI Super Night, and AI Scenario Detection, showcasing how the phone intelligently enhances your photos.

4.3 Performance

Experience smooth performance with the IteL A46:

- **Processor:** 1.6GHz Spadtrum octa core processor for efficient multitasking.
- **RAM:** 2GB RAM ensures smooth application usage.
- **Operating System:** Runs on Android v9 Pie operating system.

4.4 Connectivity

Stay connected with the IteL A46's comprehensive connectivity options:

- **SIM Support:** Dual SIM (micro+nano) with dual-standby (4G+4G).
- **Network:** Supports 4G VoLTE for high-speed data and clear calls.
- **Other Features:** Includes GPS, Wi-Fi, Bluetooth, GPRS, EDGE, HSPA+, LTE.

4.5 Security Features

Protect your data with advanced security options:

- **Multi-function Fingerprint Sensor:** Unlock your device quickly and securely with your fingerprint.
- **Speedy Face Unlock:** Conveniently unlock your phone using facial recognition.

Your browser does not support the video tag.

This video highlights the key features of the Itel A46, including its 2GB RAM, 16GB ROM, Octa Core processor, Dual 4G VoLTE support, and the 5.45-inch HD+ IPS FullScreen display, along with security features like fingerprint and face unlock.

5. MAINTENANCE

To ensure your Itel A46 remains in optimal condition, follow these maintenance guidelines:

- **Keep Clean:** Regularly wipe your phone with a soft, dry cloth to remove dust and smudges. Avoid harsh chemicals.
- **Protect Screen:** Use a screen protector and a protective case to prevent scratches and damage from drops.
- **Battery Care:** Avoid extreme temperatures. Do not overcharge or completely drain the battery frequently. Use only the original charger.
- **Software Updates:** Keep your device's software updated to benefit from the latest features and security patches.
- **Storage Management:** Periodically clear unnecessary files and apps to maintain performance.

6. TROUBLESHOOTING

If you encounter issues with your Itel A46, refer to the following common troubleshooting steps:

- **Phone Not Turning On:** Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on again. If it still doesn't turn on, try a forced restart (usually by holding the power button for 10-15 seconds).
- **Apps Crashing/Freezing:** Close the problematic app and reopen it. If the issue persists, clear the app's cache and data in Settings > Apps. As a last resort, uninstall and reinstall the app.
- **Poor Battery Life:** Reduce screen brightness, disable unused features like Wi-Fi, Bluetooth, and GPS when not needed. Close background apps. Check battery usage in Settings to identify power-hungry apps.
- **Connectivity Issues (Wi-Fi/Mobile Data):** Toggle Wi-Fi or mobile data off and on. Restart your phone. For Wi-Fi, forget the network and reconnect. For mobile data, check your SIM card and network settings.
- **Fingerprint/Face Unlock Not Working:** Ensure your fingers/face are clean and dry. Re-register your fingerprint/face in the security settings. Check for any physical obstructions on the sensor or front camera.
- **Slow Performance:** Clear cache, uninstall unused apps, and free up storage space. Restart your device regularly.

If these steps do not resolve your issue, please contact Itel customer support or visit an authorized service center.

7. SPECIFICATIONS

Detailed technical specifications for the Itel A46 smartphone:

Feature	Specification
Brand	Itel
Operating System	Android v9 Pie
Processor	1.6GHz Sptheadrum Octa Core
RAM	2 GB
Internal Storage	16 GB (Expandable up to 128GB)

Feature	Specification
Display Size	5.45 Inches (13.8 cm)
Display Resolution	1440 x 720 pixels (HD+)
Rear Camera	8 + 0.3 MP Dual Camera
Front Camera	5 MP
Battery Capacity	2400 mAh Lithium-Ion
SIM Type	Dual SIM (micro+nano)
Network Technology	4G VoLTE, 3G, 2G (GSM, GPRS, EDGE, HSPA+, LTE)
Security Features	Fingerprint Sensor, Face Recognition
Sensors	Accelerometer, Ambient Light Sensor, Proximity Sensor
Dimensions	15 x 0.9 x 7.2 Centimeters
Weight	155 Grams
Material	Plastic

8. WHAT'S IN THE BOX

The retail package for your Itel A46 smartphone includes the following items:

- Handset
- Battery
- Charger
- Handsfree (Earphones)
- User Manual
- Warranty Card

9. WARRANTY AND SUPPORT

Your Itel A46 smartphone comes with a comprehensive warranty:

- **Device Warranty:** 1 year manufacturer warranty from the date of purchase.
- **Accessory Warranty:** 6 months manufacturer warranty for in-box accessories, including batteries, from the date of purchase.
- **Replacement Policy:** 100 Days replacement policy (Terms & Conditions Apply).

For further assistance, technical support, or warranty claims, please refer to the contact information provided on your warranty card or visit the official Itel website.