

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [noot products](#) /
- › [noot products NP11 Wireless Bluetooth Earbuds User Manual](#)

## noot products NP11

# noot products NP11 Wireless Bluetooth Earbuds User Manual

Model: NP11

## INTRODUCTION

---

Welcome to your noot products NP11 Wireless Bluetooth Earbuds. This manual provides detailed instructions for setting up, operating, and maintaining your earbuds to ensure optimal performance and longevity. Please read this manual thoroughly before using your earbuds.

## WHAT'S IN THE BOX

---

- noot products NP11 Wireless Bluetooth Earbuds
- User Manual
- Micro USB Charging Cable
- Protective Case
- Multiple sizes of ear tips



Image: The package contents, showing the NP11 earbuds, a round protective case, a USB charging cable, and various sizes of ear tips.

## PRODUCT OVERVIEW

---

The noot products NP11 earbuds are designed for active lifestyles, featuring an in-ear design with ear hooks for a secure fit. They include integrated controls and a microphone for convenience during sports and daily activities.



Image: A close-up view of the NP11 earbuds, highlighting the ergonomic ear hook design and the control buttons on the side.




Image: A graphic detailing the main features: music control buttons, built-in microphone, and the secure ear-hook design.

## SETUP

---

### Charging the Earbuds

Before first use, fully charge your earbuds to ensure maximum battery life.

1. Connect the provided Micro USB charging cable to the charging port located on one of the earbuds.
2. Connect the other end of the cable to a USB power source (e.g., computer USB port, wall adapter).
3. The indicator light on the earbud will illuminate to show charging status. A full charge typically takes 1.5 to 2 hours.



250 hours stand-by time  
1.5~2 hours charging time



continuous music time



\* charging cable included \*

Image: The earbud connected to its charging cable, illustrating the charging process and indicating battery life and charging time.

### Pairing with a Bluetooth Device

1. Ensure the earbuds are charged and turned off.
2. Press and hold the multi-function power button on the earbuds until the indicator light flashes red and blue alternately, indicating pairing mode.
3. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
4. Select "NP11" from the list of found devices.
5. Once successfully paired, the indicator light on the earbuds will turn solid blue or flash slowly.

The earbuds utilize Bluetooth 5.0 for stable connections up to 10 meters (33 feet).




Image: The NP11 earbuds shown with multiple compatible devices (smartphones, tablets), emphasizing universal Bluetooth compatibility.

## OPERATING INSTRUCTIONS

---

### Power On/Off

- **To Power On:** Press and hold the multi-function button until the indicator light turns blue.
- **To Power Off:** Press and hold the multi-function button until the indicator light turns red and then off.

### Music Control

- **Play/Pause:** Press the multi-function button once.
- **Next Track:** Press and hold the Volume Up (+) button.
- **Previous Track:** Press and hold the Volume Down (-) button.
- **Volume Up:** Press the Volume Up (+) button briefly.
- **Volume Down:** Press the Volume Down (-) button briefly.

### Call Management

- **Answer/End Call:** Press the multi-function button once.

- **Reject Call:** Press and hold the multi-function button for approximately 2 seconds.
- **Redial Last Number:** Double-press the multi-function button.

The built-in microphone allows for clear, hands-free calling.

## MAINTENANCE

---

- Keep the earbuds clean by gently wiping them with a soft, dry cloth after each use.
- Avoid exposing the earbuds to extreme temperatures, high humidity, or direct sunlight for prolonged periods.
- Store the earbuds in their provided protective case when not in use to prevent physical damage.
- The IPX7 sweatproof rating protects against sweat and light splashes, but avoid submerging them in water or exposing them to heavy rain.

## TROUBLESHOOTING

---

### Earbuds not pairing

- Ensure the earbuds are in pairing mode (indicator light flashing red and blue).
- Make sure Bluetooth is enabled on your device.
- Move the earbuds closer to your device to ensure they are within range.
- Turn off and then restart both the earbuds and your device, then attempt pairing again.

### No sound or low volume

- Check the volume levels on both the earbuds and your connected device.
- Ensure the earbuds are properly paired and connected to your device.
- Recharge the earbuds if the battery is low.

### Intermittent connection

- Ensure your device is within the 10-meter Bluetooth range of the earbuds.
- Avoid physical obstructions (walls, large objects) between the earbuds and your device.
- Disconnect the earbuds from your device's Bluetooth settings and then re-pair them.

## SPECIFICATIONS

---

Feature	Detail
Model	NP11
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.0
Bluetooth Range	10 Meters
Battery Life (Music Time)	8 Hours

Feature	Detail
Stand-by Time	250 Hours
Charging Time	1.5 - 2 Hours
Water Resistance	IPX7 Sweatproof
Special Features	Microphone Included, Remote Control, Sweatproof, Sports-and-Exercise
Dimensions	24 x 1 x 2 inches
Item Weight	3.2 ounces

## OFFICIAL PRODUCT VIDEO

---

Your browser does not support the video tag.

Video: An official product video demonstrating the features and usage of the noot products NP11 Wireless Earbuds.

## WARRANTY AND SUPPORT

---

For detailed warranty information, technical support, or to inquire about replacement parts, please refer to the contact details provided with your original purchase documentation or visit the official noot products website for assistance.