Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

De'Longhi Essenza Mini EN85 Series

De'Longhi Nespresso Essenza Mini EN85 Series Drip Tray / Water Collection Tray User Manual

1. Introduction

This document provides essential information for the proper installation, use, and maintenance of your new De'Longhi Nespresso Essenza Mini EN85 Series Drip Tray / Water Collection Tray. This component is an original replacement part designed to ensure the continued optimal performance of your Nespresso Essenza Mini coffee machine.

2. Safety Information

Please read and understand all safety instructions before installing or using this product. Failure to do so may result in damage to the product or your coffee machine.

- **Compatibility Check:** Always verify that this drip tray is compatible with your specific Nespresso Essenza Mini EN85 model before attempting installation. Refer to the 'Compatibility' section for a list of supported models.
- **Careful Installation:** Install the drip tray with caution to prevent damage to the tray or the coffee machine. Do not force the tray into place.
- **Original Part:** This is an original De'Longhi replacement part. Use of non-original parts may void your machine's warranty or cause malfunction.

3. Compatibility

This De'Longhi Nespresso Drip Tray / Water Collection Tray is compatible with the following Nespresso Essenza Mini EN85 series models:

- EN85.B
- EN85.BAE
- EN85.L
- EN85.LAE
- EN85.R
- EN85.RAE
- EN85.W
- EN85.WAE
- EN85B
- EN85BAE

- EN85L
- EN85LAE
- EN85R
- EN85RAE

If your model is not listed, please contact De'Longhi customer support for assistance.

4. Installation

Follow these steps to install the new drip tray:

1. **Unplug the Machine:** Ensure your Nespresso Essenza Mini coffee machine is unplugged from the power outlet before proceeding.
2. **Remove Old Drip Tray (if applicable):** If replacing an existing tray, gently pull the old drip tray straight out from the front of the coffee machine.
3. **Insert New Drip Tray:** Align the new drip tray with the slot at the base of the coffee machine. Gently slide the tray into place until it clicks or sits securely. Do not use excessive force.
4. **Verify Placement:** Ensure the drip tray is fully inserted and stable before plugging the machine back in.



Image showing the black plastic drip tray, designed to collect excess water and used coffee capsules from the Nespresso Essenza Mini EN85 series coffee machines.

5. Usage

The drip tray serves two primary functions within your Nespresso Essenza Mini coffee machine:

- **Water Collection:** It collects any excess water or coffee drips that may occur during the brewing process, keeping your countertop clean.
- **Used Capsule Storage:** It also functions as a container for used Nespresso capsules, which are automatically ejected into the tray after brewing.

Regularly check the drip tray and empty it when it becomes full to prevent overflow.

6. Maintenance

To ensure hygiene and proper functioning, regular cleaning of the drip tray is recommended:

1. **Remove and Empty:** Gently pull the drip tray out from the coffee machine. Empty any collected water and used capsules.

2. **Wash:** Wash the drip tray with warm water and a mild dish soap. Use a soft sponge or cloth to clean all surfaces.
3. **Rinse:** Rinse thoroughly under running water to remove all soap residue.
4. **Dry:** Dry the drip tray completely with a clean cloth or allow it to air dry before reinserting it into the coffee machine.

Do not use abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the plastic surface.

7. Troubleshooting

- **Tray Does Not Fit:** Ensure you have the correct model of drip tray for your Nespresso Essenza Mini EN85 series machine. Do not force it.
- **Tray Overflows Quickly:** This indicates the tray needs to be emptied more frequently. Check it regularly, especially after multiple coffee preparations.
- **Water Leaking from Machine:** If water is leaking from areas other than the drip tray, this may indicate an issue with the coffee machine itself, not the drip tray. Consult your coffee machine's user manual or contact De'Longhi customer support.

8. Specifications

- **Brand:** De'Longhi
- **Product Type:** Drip Tray / Water Collection Tray
- **Compatible Models:** Nespresso Essenza Mini EN85 Series
- **Color:** Black
- **Dimensions (approximate):** 6.1 x 3.6 x 8.1 cm (2.4 x 1.4 x 3.2 inches)
- **Weight (approximate):** 20 grams (0.7 ounces)
- **Material:** Plastic
- **Recommended Use:** Nespresso drip accessory

9. Warranty and Support

For information regarding warranty coverage, technical support, or to purchase additional replacement parts, please refer to the documentation provided with your original Nespresso Essenza Mini coffee machine or visit the official De'Longhi website. Always ensure you have your coffee machine's model number and serial number ready when contacting support.

© 2023 De'Longhi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07SVNWPZ7

More documents and user manuals: **https://manuals.plus/**