



[Manuals.plus](#) /

› [Topeakmart](#) /

› Topeakmart 55-inch Multi-Level Cat Tree Instruction Manual

Topeakmart TP-00093389-57

Topeakmart 55-inch Multi-Level Cat Tree Instruction Manual

Model: TP-00093389-57

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Topeakmart 55-inch Multi-Level Cat Tree. Please read all instructions carefully before assembly and use to ensure the safety and longevity of the product.



Image: The Topeakmart 55-inch Multi-Level Cat Tree in beige, showcasing its various levels, condos, and scratching posts.

SAFETY INFORMATION

- Keep the cat tree dry. Avoid exposure to moisture or high humidity.
- Keep the cat tree away from fire and other heat sources to prevent damage or fire hazards.
- Regularly inspect the cat tree for any loose parts or damage. Tighten screws as needed.
- Use the included anti-tip kit to secure the cat tree to a wall for enhanced stability and safety, especially for active cats or multi-cat households.
- Ensure the cat tree is placed on a flat, stable surface.
- This product is designed for cats. Do not allow children to climb or play on the cat tree.

Stable Durable

Protect the safety of the cat



Image: Close-up view of the anti-tip kit being installed, showing how to secure the cat tree to a wall for increased stability.

PACKAGE CONTENTS

Before beginning assembly, please verify that all components listed below are present in your package:

- 1 x Topeakmart Multi-Level Cat Tree (all structural components)
- 1 x Assembly Instructions Manual
- 1 x Accessory Kit (includes all necessary screws, bolts, and tools for assembly, and the anti-tip kit)

ASSEMBLY INSTRUCTIONS

Assembly typically takes approximately 45 minutes. It is recommended to have a clear workspace. All parts are labeled to correspond with the assembly diagram.

1. **Identify Components:** Lay out all parts and match them with the provided diagram in the separate assembly instructions manual. Ensure all screws and tools from the accessory kit are present.
2. **Attach Base:** Begin by attaching the lowest posts to the baseboard using the provided screws.

Ensure they are tightened securely.

3. **Build Lower Levels:** Follow the numerical sequence in the assembly manual to attach platforms, condos, and additional posts layer by layer. Pay attention to the orientation of each piece.
4. **Install Condos:** Secure the cat condos to their designated platforms. These typically involve internal screw connections.
5. **Add Perches and Basket:** Attach the upper perches, including the cat-ear perch, and the hanging basket as indicated in the diagram.
6. **Attach Dangling Toys:** Secure any dangling balls or toys to the designated points on the cat tree.
7. **Final Tightening:** Once fully assembled, re-check all screws and connections to ensure they are tight and stable.
8. **Install Anti-Tip Kit:** Secure the cat tree to a nearby wall using the anti-tip strap and hardware provided in the accessory kit. This is a critical safety step.




Image: A detailed diagram illustrating the dimensions and structural layout of the cat tree, including various platforms, condos, and scratching posts.



Image: A close-up view of the cozy cat condos, highlighting their dimensions for cat comfort.

OPERATING INSTRUCTIONS

The Topeakmart Multi-Level Cat Tree is designed to provide a stimulating and comfortable environment for your feline companions. Here's how to maximize its use:

- **Placement:** Position the cat tree in a location where your cat frequently spends time, such as near a window for bird watching, or in a common living area.
- **Encourage Exploration:** Introduce your cat to the tree by placing treats or toys on different levels. Gently guide them to explore the condos and perches.
- **Scratching Posts:** Encourage your cat to use the sisal-wrapped scratching posts and board instead of furniture. You can use catnip spray on the sisal to attract them.
- **Play:** Utilize the dangling toys to engage your cat in play, promoting physical activity and mental stimulation.
- **Resting Areas:** The multiple perches, condos, and basket offer various spots for your cat to rest, observe, or nap.

Multi-Level Top Lookout



Image: Two cats comfortably resting on the multi-level top lookout perches of the cat tree.

Top perch with lovable

CAT-EAR



Image: A close-up view of the top perch, featuring a unique cat-ear design for added comfort and aesthetic appeal.



Natural Sisal Scratching Post / Board




Image: A cat utilizing the natural sisal scratching post and board, demonstrating the durable material designed for claw health.

MAINTENANCE

Regular maintenance will extend the life of your cat tree and ensure a safe environment for your pets.

- **Cleaning:** Use a lint roller or vacuum cleaner to remove loose fur and debris from the plush surfaces. For spot cleaning, use a damp cloth with mild soap and water, then air dry thoroughly. Do not machine wash.
- **Sisal Care:** The sisal scratching surfaces are durable but will show wear over time. Replace if severely frayed to maintain effectiveness.
- **Stability Check:** Periodically check all screws and connections for tightness. Re-tighten any loose fasteners to prevent wobbling.
- **Damage Inspection:** Inspect the entire structure for any signs of damage, such as cracked particleboard or torn fabric. Discontinue use if significant damage is found that could compromise safety.



Plush Fabric Covering



Durable Particleboard



Natural Sisal Post

Image: Detailed view of the materials used in the cat tree: soft plush fabric covering, durable particleboard core, and natural sisal rope on scratching posts.

TROUBLESHOOTING

Cat tree wobbles after assembly:

Ensure all screws are fully tightened. Verify that the base is on a flat, even surface. Install or re-check the anti-tip kit to secure the tree to a wall.

Cat is not using the tree:

Try placing catnip on the scratching posts or inside the condos. Place favorite toys or treats on different levels to encourage exploration. Ensure the tree is in a quiet, accessible location that your cat prefers.

Dangling toys are damaged:

Dangling toys are subject to wear and tear. If they become detached or damaged, they can be replaced with similar cat-safe toys. Ensure no small parts become choking hazards.

SPECIFICATIONS

| Feature | Detail |
|---|--|
| Brand | Topeakmart |
| Model Number | TP-00093389-57 |
| Assembled Dimensions (L x W x H) | 49.5L x 49.5W x 144.8H Centimetres (approx. 19.5" L x 19.5" W x 57" H) |
| Material | Engineered Wood (Particleboard), Plush Fabric, Natural Sisal Rope |
| Color | Beige |
| Item Weight | 14.45 kg (approx. 31.9 lbs) |
| Number of Levels | 5 |
| Special Feature | Anti-Toppling Strap Included |
| Recommended Uses | Indoor use for small to medium breed cats |
| Maximum Weight Capacity (Basket/Platform) | 5 kg / 11 lb per basket/platform |
| Maximum Weight Capacity (Total) | 45 kg / 99 lb |

WARRANTY AND SUPPORT

Specific warranty details for the Topeakmart 55-inch Multi-Level Cat Tree are not provided in this manual. For warranty information, technical support, or to inquire about replacement parts, please contact Topeakmart customer service directly through their official website or the retailer where the product was purchased.

Please retain your proof of purchase for any warranty claims.