

[Manuals.plus](#) /

› [YODOLLA](#) /

› YODOLLA 28.5" Electric Fireplace Insert User Manual

YODOLLA 4EA44B438

YODOLLA 28.5" Electric Fireplace Insert User Manual

Model: 4EA44B438

1. PRODUCT OVERVIEW

The YODOLLA 28.5" Electric Fireplace Insert is designed to provide warmth and ambiance to your living space. It can be installed as a wall-recessed, wall-mounted, or freestanding unit, offering versatile placement options. This electric fireplace features adjustable flame colors and brightness, two heat settings, a thermostat, and a timer, all controllable via a remote or the integrated control panel.

FAST HEAT

The fast 5120BTU heater is heated to a 400 square foot heating zone.

Heating speeds surpass most electric fireplaces.

[With two alternative heat settings: 750w(2559BTU) and 1500watt (5118BTU).]



Front view of the YODOLLA 28.5" Electric Fireplace Insert.

2. SAFETY INFORMATION

- Read all instructions before installing or using this heater.
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces.
- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the heater.
- Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- To disconnect heater, turn controls to off, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric

shock or fire, or damage the heater.

- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- This heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, propane, paint, or flammable liquids are used or stored.
- Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).

3. SETUP AND INSTALLATION

Unpacking

Carefully remove the fireplace from its packaging. Retain the packaging for future storage or transport. Ensure all components are present and undamaged. If any parts are missing or damaged, do not proceed with installation and contact customer support.

Placement Options

This electric fireplace offers flexible installation options:

- **Wall-Recessed Installation:** Designed to fit into an existing fireplace opening or a custom-built recess. Ensure the inner dimensions of your opening are compatible with the fireplace insert's dimensions (24.6" x 19" x 5.3").
- **Wall-Mounted Installation:** Can be mounted directly onto a wall surface.
- **Freestanding:** Can be used as a standalone unit without permanent installation.

Power Connection

Connect the power supply according to the installation instructions. The unit operates on 110-120 volts/60Hz. Always plug the unit directly into a wall outlet. Do not use extension cords or power strips.

Initial Operation

During the first use, it is recommended to ventilate the room or run the fireplace in an open area for a short period, as some fumes may be released. This is normal and will dissipate quickly.



Dimensions of the YODOLLA 28.5" Electric Fireplace Insert.

4. OPERATING INSTRUCTIONS

The YODOLLA Electric Fireplace can be operated using the included remote control or the control panel located on the unit.

Control Panel and Remote

The control panel is typically located behind a small access panel on the front of the unit. Both the remote and the control panel offer similar functionalities.

Your browser does not support the video tag. This video demonstrates the control panel of the YODOLLA Electric Fireplace, showing how to access and use the buttons for various settings.

Video: Demonstration of the control panel and its functions.



1 ON/OFF

2 Temp
Adjustable temperature 62°F - 82°F

3 Dimmer
Make flame effect dimmer and brightness effect gets changing.

4 Heater
Two heat settings: 750-1500W

5 Color
Orange&Blue&Mix

6 Time
Adjustable timer 1H - 8H

Illustration of the control panel and remote control buttons.

Power On/Off

Press the power button on the remote or control panel to turn the fireplace on or off.

Heat Settings

The fireplace offers two heat modes: 750W and 1500W. Use the heat button to toggle between these settings. The thermostat allows you to set the desired room temperature between 60°F and 82°F.

Flame Effects

Customize the visual ambiance with:

- **3 Flame Colors:** Choose from various flame colors to match your mood or decor.
- **5 Brightness Settings:** Adjust the intensity of the flame effect from subtle to vibrant.

The flame effect can be operated independently, with or without the heat function, providing year-round ambiance.

Your browser does not support the video tag. This video demonstrates the three flame color settings available on the YODOLLA Electric Fireplace.

Video: Demonstration of the 3 flame color settings.



3 Flame Color




Illustration of the 3 flame colors and 5 brightness settings.

Timer Function

Set the countdown timer to automatically turn off the fireplace. The timer can be adjusted from 1 hour to 8 hours.

Your browser does not support the video tag. This video shows the flame effect of the YODOLLA Electric Fireplace at night, highlighting its ease of use.

Video: The fireplace flame effect at night.

5. MAINTENANCE

To ensure optimal performance and longevity of your YODOLLA Electric Fireplace, regular maintenance is recommended. Always disconnect the power before performing any maintenance.

- **Cleaning:** Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Air Vents:** Periodically check and clean the air vents to ensure they are free from dust and debris, which can obstruct airflow.
- **Log Set:** The log set is decorative and does not require specific maintenance beyond occasional dusting.

6. TROUBLESHOOTING

If you encounter issues with your electric fireplace, refer to the following common troubleshooting steps:

- **Unit Not Turning On:** Ensure the power cord is securely plugged into a functional wall outlet. Check the on/off switch on the unit and the remote control.
- **Heater Shuts Off Unexpectedly:** The unit may have an overheat protection feature. Disconnect power, wait 10 minutes, and then reconnect. Ensure the power cord is not pulled or stuffed into the unit, which can cause overheating.
- **Circuit Breaker Trips:** Verify that the fireplace is connected to a dedicated circuit with the correct voltage and amperage. Avoid plugging other high-power appliances into the same circuit.
- **No Flame Effect:** Check the flame effect settings on the remote or control panel to ensure it is activated and brightness is adjusted.
- **Remote Control Not Working:** Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the fireplace's sensor.

If problems persist after attempting these steps, contact customer support.

7. SPECIFICATIONS

Feature	Specification
Brand	YODOLLA
Model Name	28.5 Electric Fireplace Insert
Item Model Number	4EA44B438
Product Dimensions	6"D x 28.5"W x 21"H
Inner Size (Recessed)	24.6" x 19" x 5.3"
Item Weight	28 Pounds
Power Source	Corded Electric
Voltage	110-120 Volts/60Hz
Power Consumption	750W / 1500W
Heat Output	5100 British Thermal Units
Material	Metal, Tempered Glass-Front
Installation Type	Wall Mount, Recessed, Freestanding

Special Features	Dimmer, Flame Effect, Timer, Remote Control, Thermostat
Flame Colors	3 Adjustable Colors
Flame Brightness	5 Settings
Thermostat Range	60°F to 82°F
Timer Range	1 to 8 Hours

8. WARRANTY AND SUPPORT

Warranty Information

This YODOLLA Electric Fireplace Insert comes with a Limited Warranty. Please refer to the warranty card included with your product for specific terms and conditions, including coverage details and duration.

Customer Support

For technical assistance, troubleshooting, or warranty claims, please contact YODOLLA customer support. Contact information can typically be found on the product packaging or the official YODOLLA website.