

Beyution BN59-01259E

Beyution BN59-01259E Replacement Remote Control User Manual

For Samsung Smart LED 4K Ultra HDTVs

INTRODUCTION

This manual provides comprehensive instructions for the Beyution BN59-01259E replacement remote control. It covers setup, operation, maintenance, and troubleshooting to ensure optimal performance with your compatible Samsung Smart LED 4K Ultra HDTV.

SETUP

1. Battery Installation

The remote control requires two AAA batteries (not included). Ensure correct polarity when inserting the batteries.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards to open the compartment.
3. Insert two new AAA alkaline batteries, matching the (+) and (-) terminals as indicated inside the compartment.
4. Slide the cover back into place until it clicks securely.

Important: Use only new alkaline batteries. Rechargeable batteries may not provide sufficient power for proper operation.





Figure 1: Back view of the remote control, illustrating the battery compartment location.

2. Initial Use

This is an infrared (IR) replacement remote control. No programming or pairing is required. Once batteries are installed, point the remote directly at your Samsung Smart LED 4K Ultra HDTV and it should function immediately.

Note: Ensure there are no obstructions between the remote control and the TV's IR receiver.

OPERATING INSTRUCTIONS

The Beyution BN59-01259E remote control provides standard functions for your Samsung Smart LED 4K Ultra HDTV. Familiarize yourself with the button layout for efficient use.





Figure 2: Front view of the remote control with key buttons labeled.

Button Functions:

- **Power ():** Turns the TV on or off.
- **123:** Accesses the virtual numeric keypad for channel input or other numeric functions.
- **EXTRA:** Provides access to additional TV functions or information.
- **Navigation Pad (Circular):** Used to navigate menus and select items. Press the center button to confirm selections.
- **Back (↶):** Returns to the previous screen or menu.
- **Home (△):** Opens the Smart Hub or main menu.
- **Play/Pause/Fast Forward/Rewind ():** Controls media playback.
- **Volume (VOL):** Adjusts the TV's volume. Press up for louder, down for quieter.
- **Channel (CH):** Changes TV channels. Press up for the next channel, down for the previous.

MAINTENANCE

Cleaning the Remote Control

To maintain the remote control's appearance and functionality, clean it regularly:

- Wipe the surface with a soft, dry cloth.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner.
- Avoid using harsh chemicals, solvents, or abrasive cleaning pads, as these can damage the remote's finish or internal components.

Battery Replacement

Replace batteries when the remote control becomes unresponsive or its range decreases. Always replace

both batteries simultaneously with new alkaline batteries of the same type (AAA).

Storage

When not in use for extended periods, remove the batteries to prevent leakage and potential damage to the remote control.

TROUBLESHOOTING

If you experience issues with your remote control, refer to the following common problems and solutions:

Problem	Possible Cause / Solution
Remote control is not working.	<ul style="list-style-type: none">• Batteries: Ensure batteries are inserted correctly with the correct polarity. Replace with new alkaline batteries.• Line of Sight: Make sure there are no obstructions between the remote control and the TV's infrared receiver.• Distance: Ensure you are within the effective operating range of the TV's IR receiver.
Certain buttons do not respond.	<ul style="list-style-type: none">• Compatibility: Verify your TV model is listed in the compatible models section. While this remote is a replacement, some advanced functions of original remotes (e.g., voice control, specific Smart Hub features) may not be supported by an infrared replacement.• Remote Damage: Inspect the remote for any physical damage.
Remote works intermittently.	<ul style="list-style-type: none">• Low Batteries: Replace batteries with new alkaline ones.• Interference: Ensure no strong light sources (like direct sunlight or bright fluorescent lights) are interfering with the IR signal.

Compatible TV Models:

This replacement remote control is compatible with the following Samsung Smart LED 4K Ultra HDTV models:

- BN59-01241A, BN59-01259B, BN59-01259E, BN59-01260A, TM1640A
- UN40KU6290, UN40KU6290F, UN40KU6290FXZA, UN40KU6290FXZC
- UN40KU7000, UN40KU7000FXZA, UN40KU700D
- UN43KU7000, UN43KU7000D, UN43KU7000FXZA
- UN49KU7000, UN49KU7000FXZA
- UN50KU6290, UN50KU6290F, UN50KU6290FXZA, UN50KU6290FXZC
- UN55KU6290, UN55KU6290F, UN55KU6290FXZA, UN55KU6290FXZC
- UN55KU7000, UN55KU7000F, UN55KU7000FXZA
- UN60KU6270, UN60KU6290, UN60KU6290F, UN60KU6290FXZC
- UN65KU6290, UN65KU6290F, UN65KU6290FXZA, UN65KU6290FXZC
- UN65KU7000FXZA
- UN70KU6290, UN70KU6290F, UN70KU6290FXZC

If your TV model is not listed, please contact customer support for assistance.

SPECIFICATIONS

- **Model:** BN59-01259E
- **Brand:** Beyution
- **Connectivity Technology:** Infrared (IR)
- **Compatible Devices:** Samsung Smart LED 4K Ultra HDTVs
- **Power Source:** 2 x AAA Batteries (Alkaline recommended)
- **Product Dimensions:** 7 x 2 x 0.65 inches (approximately)
- **Item Weight:** 1.76 ounces (approximately, without batteries)
- **Special Feature:** Ergonomic design
- **Max Number of Supported Devices:** 1 (Television)

SUPPORT

For further assistance or inquiries, please contact your retailer or the manufacturer's customer support. Please have your product model number (BN59-01259E) ready when contacting support.