Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ChooChoo EUR-ST19001-BR

ChooChoo Narrow Console Table Instruction Manual

Model: EUR-ST19001-BR

Introduction

Thank you for choosing the ChooChoo Narrow Console Table. This manual provides detailed instructions for the assembly, use, and maintenance of your new furniture. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Image: The ChooChoo Narrow Console Table in Espresso, showcasing its design and potential use with decorative items.

Safety Information

- Keep children away from climbing on the table to avoid injury.
- Ensure all screws and fasteners are securely tightened before use.
- Do not exceed the maximum weight recommendation of 45 pounds.
- Place the table on a flat, stable surface to prevent tipping.
- Avoid exposing the table to excessive moisture or direct sunlight to prevent damage.

Package Contents

Before assembly, please verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Tabletop (1)

- Curved Legs (2)
- Lower Shelf (1)
- Hardware Pack (Screws, bolts, etc.)
- Assembly Tool (Allen wrench)
- Instruction Manual (1)

Assembly Instructions

Assembly is designed to be straightforward and typically takes less than 30 minutes. Follow these steps carefully:

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a clean, soft surface to prevent scratches. Refer to the parts list to identify each component.
2. **Attach Legs to Tabletop:** Secure the curved legs to the underside of the tabletop using the provided screws and the assembly tool. Ensure the curved design faces outwards as intended.
3. **Install Lower Shelf:** Attach the lower shelf to the designated points on the curved legs. Make sure it is level and securely fastened with the appropriate hardware.
4. **Final Tightening:** Once all parts are assembled, gently tighten all screws to ensure stability. Do not overtighten.




Image: A diagram illustrating the dimensions and structural components of the console table, useful for assembly.

Your browser does not support the video tag.

Video: Official ChooChoo Furniture video demonstrating the assembly and features of the console table.

Usage

The ChooChoo Narrow Console Table is designed for versatile use in various indoor settings. Its transitional design with curved legs and a clean tabletop allows it to complement both modern and traditional decor.

- **Entryway Table:** Ideal for small entryways or hallways to hold keys, mail, or decorative items.
- **Sofa Table:** Position behind a couch to provide additional surface space for lamps, drinks, or books.
- **Accent Table:** Use in living rooms, bedrooms, or bathrooms as a decorative accent piece or for displaying plants and photos.
- **Storage:** The lower shelf offers convenient storage for baskets, books, or other items, helping to keep your space organized.



Image: The console table positioned behind a sofa, demonstrating its use as a sofa table with various items.



Image: The console table serving as an entryway table, adorned with a vase of flowers and storage boxes.

Maintenance

- **Cleaning:** Wipe the table surface with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or water damage.
- **Tighten Fasteners:** Periodically check and tighten all screws and fasteners to maintain stability.
- **Avoid Heat and Moisture:** Do not place hot items directly on the surface. Use coasters or protective pads. Keep the table away from direct heat sources and areas of high humidity.

Troubleshooting

If you encounter any issues with your ChooChoo Narrow Console Table, please refer to the following common solutions:

- **Wobbly Table:** Ensure all screws are fully tightened. Check that the table is placed on a level surface. Adjust leg levelers if

available.

- **Scratches/Dents:** For minor imperfections, touch-up pens or furniture markers matching the Espresso finish can be used.
- **Missing Parts:** If any parts were missing upon delivery, please contact ChooChoo customer support with your purchase details.

Specifications

Brand	ChooChoo
Model Number	EUR-ST19001-BR
Color	Espresso
Product Dimensions (D x W x H)	11.8"D x 39.3"W x 31.4"H
Item Weight	10.5 Kilograms
Maximum Weight Recommendation	45 Pounds
Frame Material	Wood
Top Material Type	Engineered Wood
Required Assembly	Yes
Indoor/Outdoor Usage	Indoor

Warranty and Support

ChooChoo is committed to providing high-quality products. If you encounter any problems or have questions regarding your console table, please contact our customer support team. We aim to respond and assist you within 24 hours.
For support, please visit the official ChooChoo store on Amazon or contact us directly through the platform where you made your purchase.
Online Store: ChooChoo Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07SYJ189D

More documents and user manuals: **https://manuals.plus/**