

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Mando Compatible](#) /

> [Mando Compatible Universal Remote Control for FERROLI Air Conditioners, Model 5051155189015](#)

Mando Compatible 5051155189015

Mando Compatible Universal Remote Control for FERROLI Air Conditioners

Model: 5051155189015

INTRODUCTION

This manual provides instructions for the Mando Compatible universal remote control, designed for use with FERROLI split-type air conditioning units. It covers setup, operation, maintenance, and troubleshooting to ensure proper functionality.

Important: This remote control is compatible with wall-mounted FERROLI split-type air conditioners that provide both cooling and heating functions. It is **not suitable** for portable FERROLI air conditioners or centralized ducted FERROLI systems.

100 % COMPATIBLE FERROLI



Figure 1: Mando Compatible Universal Remote Control

SETUP INSTRUCTIONS

1. Battery Installation

The remote control requires two AAA batteries (not included). Follow these steps to install them:

1. Open the battery compartment cover on the back of the remote control.
2. Insert two AAA batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment.
3. Close the battery compartment cover securely.

2. Automatic Code Search and Configuration

After installing batteries, the remote control needs to be configured to your specific FERROLI air conditioner model using the automatic search system.

1. Ensure your FERROLI air conditioner is powered on.
2. Point the remote control towards the air conditioner's receiver.
3. Press and hold the "SET" button (or equivalent button for code search, refer to the remote's specific button layout if different). The display will show a flashing code or start searching.
4. Release the button when the air conditioner responds (e.g., turns on/off, changes mode, or beeps). This

indicates that a compatible code has been found.

5. Test all basic functions (On/Off, Temperature, Mode) to confirm proper operation. If not all functions work, repeat the search process to find another compatible code.

A detailed manual for the automatic search function is included with the product for further clarification.

OPERATING INSTRUCTIONS

The remote control features a digital LCD display and various buttons for controlling your air conditioner. While button layouts may vary slightly, common functions include:



Figure 2: Remote Control with Function Icons (Cooling and Heating)

- **Power On/Off:** Press the **ON/OFF** button to turn the air conditioner on or off.
- **Mode Selection:** Use the **MODE** button to cycle through operating modes such as Cool, Heat, Dry, Fan, and Auto. The current mode will be displayed on the LCD.
- **Temperature Adjustment:** Use the **TEMP ▲** and **TEMP ▼** buttons to increase or decrease the desired temperature.
- **Fan Speed:** Press the **FAN SPEED** button to adjust the fan speed (e.g., Low, Medium, High, Auto).
- **Air Swing:** The **AIR SWING** button controls the louver movement for air distribution.

- **Timer:** Use the **TIMER** button to set a timer for the air conditioner to turn on or off automatically.

Refer to the specific button labels on your remote control and the air conditioner's user manual for detailed function descriptions.

MAINTENANCE

To ensure optimal performance and longevity of your remote control, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote control's range decreases or the display becomes dim. Always replace both batteries at the same time with new AAA batteries.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and damage. Store it in a cool, dry place.
- **Avoid Exposure:** Do not expose the remote control to direct sunlight, high temperatures, humidity, or strong impacts.

TROUBLESHOOTING

If you experience issues with your remote control, try the following solutions:

Problem	Possible Cause / Solution
Remote control not working.	<ul style="list-style-type: none"> • Check if batteries are correctly installed and have sufficient charge. Replace if necessary. • Ensure there are no obstructions between the remote control and the air conditioner. • Verify that the remote control is pointed directly at the air conditioner's receiver. • Re-perform the automatic code search and configuration process.
Air conditioner does not respond to all commands.	<ul style="list-style-type: none"> • The current code may not be fully compatible. Repeat the automatic code search to find a more suitable code. • Some advanced functions might not be supported by all FERROLI models or by this universal remote.
Display is dim or blank.	<ul style="list-style-type: none"> • Batteries are low. Replace with new AAA batteries.

If the problem persists after trying these steps, please contact customer support.

SPECIFICATIONS

Brand: Mando Compatible

Model Number: 5051155189015

Compatible Devices: FERROLI Split-type Air Conditioners

Connectivity Technology: Infrared

Maximum Range: 10 Meters

Battery Type: 2 x AAA (not included)

Additional Features: Digital LCD Display, Automatic Code Search

Number of Buttons: 18

Controller Type: Button Control

Color: Black

Item Weight: 130 grams

Package Dimensions: 25.3 x 8.6 x 3 cm

WARRANTY INFORMATION

Specific warranty details for this product are not provided in the available information. Please refer to your purchase documentation or contact the seller for warranty terms and conditions.

CUSTOMER SUPPORT

For any questions, clarifications, or technical assistance regarding your Mando Compatible remote control, please contact our customer support team.



The graphic features a light blue background with a blurred image of a hand holding a white remote control. The remote control has a digital display showing '18.0' and various buttons labeled 'MODE', 'TEMP', 'ON', 'TIMER', 'SET', and 'AIR SWING'. Overlaid on the image is the text 'ATENCION AL CLIENTE 24H' in large, bold, black letters. Below this, the text 'QUEREMOS AYUDARTE' is written in a smaller, black, serif font. To the left of the phone number is a green WhatsApp logo. The phone number '622822020' is displayed in large, bold, black digits.

ATENCION AL CLIENTE 24H

QUEREMOS AYUDARTE

 622822020

Figure 3: Customer Support Contact Information

Support is available via phone and WhatsApp.

WhatsApp: [+34 622 822 020](https://wa.me/34622822020)