

[Manuals.plus](#) /

> [Beyution](#) /

> User Manual for Beyution AKB75095307 Replacement Remote Control

Beyution BE-AKB75095307-CAD

Beyution AKB75095307 Replacement Remote Control User Manual

Model: BE-AKB75095307-CAD

1. INTRODUCTION

This manual provides comprehensive instructions for the Beyution AKB75095307 Replacement Remote Control. This remote is designed as a direct replacement for various LG Smart 4K Ultra HDTV models, offering immediate functionality without the need for complex programming. It operates using infrared technology.





Image 1.1: Front view of the Beyution AKB75095307 Replacement Remote Control. The remote is black with clearly labeled buttons for power, numbers, volume, channel, navigation, and streaming services like Netflix and Amazon.

2. SETUP: BATTERY INSTALLATION

The AKB75095307 remote control requires two AAA batteries for operation. For optimal performance and to ensure proper functionality, it is crucial to use **brand new alkaline batteries**. Rechargeable batteries are not recommended as they may not provide sufficient power for consistent operation.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.





Image 2.1: Rear view of the remote control with the battery cover removed, illustrating the correct orientation for inserting two AAA batteries

into the compartment.

3. OPERATING INSTRUCTIONS

This replacement remote control is designed to function immediately upon battery installation, without requiring any programming. It operates via infrared (IR) signals.

3.1 Basic Operation

- Point the remote control directly towards your LG Smart TV.
- Ensure there are no obstructions between the remote control and the TV's IR receiver.
- Press the desired function button (e.g., Power, Volume, Channel, Netflix) to control your television.

3.2 Compatible Models

This remote control is compatible with a wide range of LG Smart 4K Ultra HDTV models. A partial list of compatible models includes:

- 32LJ550B, 32LJ550M
- 43LJ5500, 43LJ550M, 43LJ5550
- 43UJ6050, 43UJ6200, 43UJ6300, 43UJ6350, 43UJ6500, 43UJ6560
- 49LJ5500, 49LJ550M, 49LJ5550
- 49UJ6050, 49UJ6200, 49UJ620M, 49UJ6300, 49UJ6350, 49UJ6500, 49UJ6560
- 55LJ5500, 55LJ550M, 55LJ5550
- 55UJ6050, 55UJ6200, 55UJ6300, 55UJ6350, 55UJ6520, 55UJ6540, 55UJ6580
- 60UJ6050, 60UJ6300, 60UJ6350, 60UJ6540
- 65UJ6050, 65UJ6200, 65UJ6300, 65UJ6350, 65UJ6520, 65UJ6540, 65UJ6580
- 70UJ6520, 70UJ6570, 70UJ657A
- 75UJ6450, 75UJ6470, 75UJ6520, 75UJ657A
- And corresponding regional variations (e.g., 32LJ550B-UA, 43UJ6300-UA, MFL69669303).

If your specific TV model is not listed, please refer to the product listing or contact the seller for compatibility verification.

4. MAINTENANCE

Proper maintenance ensures the longevity and reliable performance of your remote control.

- **Cleaning:** Use a soft, dry cloth to wipe the remote control. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid excessive moisture.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or inconsistent. Always replace both batteries simultaneously with new alkaline batteries.
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity. If the remote will not be used for an extended period, remove the batteries to prevent leakage.

5. TROUBLESHOOTING

If your remote control is not functioning as expected, consider the following troubleshooting steps:

- **Remote Not Responding:**
 - Ensure you have inserted **brand new alkaline batteries**. Rechargeable batteries may not provide adequate power.
 - Verify that the batteries are inserted with the correct polarity (+ and -).

- Check if anything is blocking the infrared sensor on the front of the remote control or the IR receiver on your television.
- Try pointing the remote directly at the TV from a closer distance.
- **Intermittent Functionality:**
 - This often indicates low battery power. Replace the batteries with new ones.
 - Ensure there are no strong light sources (like direct sunlight or certain types of lighting) interfering with the IR signal.

If the issue persists after following these steps, please contact the seller for further assistance.

6. SPECIFICATIONS

Product Dimensions	7 x 2 x 0.65 inches
Item Weight	2 ounces
Model Number	BE-AKB75095307-CAD
Batteries Required	2 AAA batteries (Alkaline recommended)
Connectivity Technology	Infrared (IR)
Compatible Devices	LG Smart 4K Ultra HDTVs (specific models listed in Section 3.2)
Max Number of Supported Devices	1

7. WARRANTY AND SUPPORT

As a replacement remote control, specific warranty details may vary. Please refer to the original purchase documentation or contact the seller directly for information regarding warranty coverage, returns, or technical support for your Beyution AKB75095307 Replacement Remote Control.

© 2024 Beyution. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07SYY7YD2>

More documents and user manuals: <https://manuals.plus/>