

[Manuals.plus](#) /

› [Y YOFUN](#) /

› YOFUN Smart Interactive Cat Toy Model 01 User Manual

Y YOFUN 01

YOFUN Smart Interactive Cat Toy Model 01

User Manual

INTRODUCTION

The YOFUN Smart Interactive Cat Toy Model 01 is a USB rechargeable, self-rotating ball designed to engage your cat's natural hunting instincts. It features 360-degree rotation, automatic direction changes, and a built-in LED light to provide stimulating play for your feline companion.

SAFETY INFORMATION

- Always supervise your pet during play to prevent accidental ingestion of parts.
- Inspect the toy regularly for any damage. Discontinue use if the toy becomes broken or damaged.
- Keep the toy away from infants and young children.
- This product is intended for pet use only.

SETUP

Charging the Toy

Before first use, fully charge the YOFUN Smart Interactive Cat Toy. The toy is USB rechargeable, eliminating the need for battery replacement.

1. Gently twist the upper shell of the small ball anti-clockwise to open it.
2. Locate the charging port inside the ball.
3. Plug in the provided USB charging cable. A flashing red light indicates the ball is charging.
4. Charge for approximately 1.5 hours. The red light will remain solid when fully charged. A full charge provides up to 4 hours of playtime.

Rechargeable

It takes only one & half hour for the battery to get recharged and provides up to four hours of fun



Image: Charging the YOFUN Smart Interactive Cat Toy.

How To Charge

Open The Small Ball

Follow the direction on the Small Ball's outer shell turn the upper shell anticlockwise until you can fully open it



Plug In The Charging Cable

Locate the charging port, plug in the cable, flashing red spot indicates the ball is under charging process, red light stays on when fully charged



Turn Smart Ball On

Screw the ball back, press the "ON" button to activate the ball, then place it on the floor, let your furry friend enjoys the fun of hunting



Image: Detailed steps for opening, charging, and turning on the toy.

Turning On the Toy

After charging, screw the ball back together. Press the 'ON' button to activate the ball. Place it on the floor to begin play.

OPERATING INSTRUCTIONS

The YOFUN Smart Interactive Cat Toy is designed for autonomous play, stimulating your cat's natural hunting instincts.

- **360-Degree Self-Rotation:** Once activated, the ball will begin to rotate 360 degrees, moving continuously around your home.
- **Built-in LED Light:** A red LED light will illuminate and spin simultaneously with the ball's movement, further attracting your cat's attention.
- **Automatic Direction Change:** The ball features a self-balancing system that automatically changes its direction upon colliding with obstacles such as walls, furniture, or doors. No manual intervention is required during play.

Raise hunting instinct for indoor cat

360 degree rotation, automatically change direction when colliding with a wall, chair or door



Image: Cat observing the interactive toy in motion.

Optimal Play Surface

For best performance, the YOFUN Smart Interactive Cat Toy operates most effectively on hard, smooth surfaces such as wood or tile floors. It may not roll optimally on thick carpets.

Caution: The ball rolls the best on hard floor, might not roll well on thick carpet



Image: Recommended floor types for optimal toy performance.

MAINTENANCE

- **Cleaning:** Wipe the exterior of the toy with a soft, damp cloth. Do not immerse the toy in water.
- **Charging:** Recharge the toy when the red light indicates low battery or when performance diminishes. Regular charging helps maintain battery life.
- **Storage:** Store the toy in a dry place away from direct sunlight when not in use.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Toy does not turn on or stops moving unexpectedly.	Low battery; Power button accidentally pressed; Internal obstruction.	Charge the toy fully. Ensure the power button is not being pressed by impacts. Check for any debris obstructing internal mechanisms.

Problem	Possible Cause	Solution
Toy is not attracting cat's attention.	Cat is not in a playful mood; Toy is on an unsuitable surface.	Ensure the toy is activated and the LED light is working. Try placing the toy on a hard, smooth floor. Introduce the toy during your cat's active periods.

SPECIFICATIONS

Brand: Y YOFUN

Model Number: 01

Material: Acrylonitrile Butadiene Styrene (ABS)

Color: White

Item Weight: 100 g

Item Dimensions (L x W x H): 6.4 x 6.4 x 6.4 cm

Power Source: USB Rechargeable

Charging Time: Approximately 1.5 hours

Playtime per Charge: Up to 4 hours

Features: 360-degree self-rotation, Automatic direction change, Built-in LED light

Recommended Use: Indoor

Target Species: Cat

UPC: 760960534242

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question