Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

NYEAR Wireless Scanner Holder/Stand/Bracket

Nyear Wireless Scanner Holder/Stand/Bracket Instruction Manual

Model Compatibility: NT800-H26, NT500-H26, NT100-H26

Introduction

Thank you for choosing the Nyear Wireless Scanner Holder/Stand/Bracket. This product is designed to provide stable and convenient support for your Nyear barcode scanner, enhancing usability and efficiency in various work environments. This manual will guide you through the setup, operation, and maintenance of your new scanner stand. This holder is specifically designed for compatibility with Nyear barcode scanner models:**NT800-H26**, **NT500-H26**, and **NT100-H26**.

Product Features

- **Stable and Huge Support:** Engineered for robust stability, ensuring your scanner remains securely in place during use.
- **Adjustable Angle Range:** Features an adjustable angle of up to 30 degrees, allowing for optimal positioning of your scanner for comfortable and efficient operation.
- **Dedicated Compatibility:** Perfectly suited for Nyear barcode scanner models NT800-H26, NT500-H26, and NT100-H26.

Setup Instructions

Follow these steps to set up your Nyear Wireless Scanner Holder/Stand/Bracket:

1. **Unpack the Stand:** Carefully remove all components from the packaging. Ensure the stand base and the scanner cradle are present.
2. **Place the Stand:** Position the stand on a flat, stable surface where you intend to use your barcode scanner. Ensure there is enough space for comfortable operation and scanner placement.
3. **Insert the Scanner:** Gently place your compatible Nyear barcode scanner (NT800-H26, NT500-H26, or NT100-H26) into the cradle of the stand. The cradle is designed to securely hold the scanner.
4. **Adjust Angle (Optional):** If needed, adjust the angle of the scanner cradle to your preferred scanning position. The stand allows for an adjustment range of up to 30 degrees.



Figure 1: Front view of the Nyear Wireless Scanner Holder/Stand/Bracket.



Figure 2: Nyear barcode scanner placed securely in the holder.

Operating Instructions

The Nyear Wireless Scanner Holder/Stand/Bracket is designed for straightforward operation:

1. **Scanner Placement:** Ensure your Nyear barcode scanner is properly seated in the cradle. The design provides a snug fit to prevent accidental dislodgement.

2. **Angle Adjustment:** To change the scanning angle, gently hold the base of the stand and adjust the scanner cradle to your desired position. The joint allows for smooth movement within its 30-degree range. Avoid forcing the adjustment beyond its natural range.
3. **Scanning:** Once the scanner is in place and adjusted, you can use it for hands-free scanning or easily pick it up for handheld operations.



Figure 3: Illustration of the adjustable angle feature of the scanner holder.

Maintenance

To ensure the longevity and optimal performance of your scanner holder, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the stand regularly with a soft, dry, or slightly damp cloth. Avoid using abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish.
- **Inspection:** Periodically check the stand for any signs of wear or damage, especially around the adjustable joint.
- **Storage:** When not in use for extended periods, store the stand in a clean, dry environment away from extreme temperatures.

Troubleshooting

If you encounter any issues with your Nyear Wireless Scanner Holder/Stand/Bracket, refer to the following common solutions:

- **Stand Instability:**
  - Ensure the stand is placed on a completely flat and level surface.
  - Verify that the scanner is properly seated in the cradle.
- **Difficulty Adjusting Angle:**
  - Apply gentle, even pressure when adjusting the angle. Do not force the mechanism.
  - Ensure no debris is obstructing the joint.
- **Scanner Not Fitting:**
  - Confirm that your scanner model is one of the compatible Nyear models: NT800-H26, NT500-H26, or NT100-H26. This stand is not universally compatible with all scanner models.

Specifications

Brand	NYEAR
Manufacturer	Nyear
Compatible Scanner Models	NT800-H26, NT500-H26, NT100-H26
Color	Black
Adjustable Angle Range	Up to 30 degrees
ASIN	B07T18BQYM
UPC	742377804293

Warranty Information

For specific warranty details regarding your Nyear Wireless Scanner Holder/Stand/Bracket, please refer to the warranty card included with your original product packaging or visit the official Nyear website. Warranty terms and conditions may vary by region and purchase date.

Support

If you require further assistance or have questions not covered in this manual, please contact Nyear customer support. You can typically find contact information on the official Nyear website or through your product retailer.

For the latest information and support resources, please visit:www.nyear.com (*Note: This is a placeholder URL. Please refer to your product documentation for the actual support website.*)

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07T18BQYM

More documents and user manuals: **https://manuals.plus/**