

Xiaomi MSX201

Xiaomi Mijia Electric Shaver 2 Floating Head Razor User Manual

Model: MSX201

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using the Xiaomi Mijia Electric Shaver 2. Retain this manual for future reference.

- Avoid submerging the shaver completely in water. While it is waterproof for rinsing, prolonged submersion is not recommended.
- Exercise caution when using the floating head to prevent cuts or skin irritation.
- Always clean and dry the shaver thoroughly after each use to prevent bacterial growth and maintain hygiene.
- Keep out of reach of children.
- Do not disassemble or attempt to repair the shaver yourself. Contact authorized service for assistance.
- Use only the provided charging cable or a compatible USB-C cable for charging.

2. PRODUCT OVERVIEW

The Xiaomi Mijia Electric Shaver 2 is a compact, portable, and waterproof electric razor designed for men. It features two floating rotary heads for a smooth and comfortable shave, a durable stainless steel blade system, and a rechargeable battery for cordless operation.



Figure 2.1: Overall view of the Xiaomi Mijia Electric Shaver 2, showcasing its compact, black design with two floating rotary heads and a power button on the front.

Key Features:

- **Dual Floating Heads:** Adapts to facial contours for a close shave.
- **Waterproof Design:** Suitable for both wet and dry shaving, and easy to clean under running water.
- **USB Rechargeable:** Convenient charging via USB-C.
- **Compact and Portable:** Lightweight design (85 grams) ideal for travel.
- **Travel Lock:** Prevents accidental activation during transport.

3. SETUP AND CHARGING

Initial Charge:

Before first use, fully charge the shaver. A full charge typically takes approximately 2 hours and provides up to 90 minutes of shaving time.

1. Locate the USB Type-C charging port at the bottom of the shaver.
2. Connect the provided USB-C charging cable to the shaver and the other end to a compatible USB power adapter (not included) or a computer USB port.
3. The battery indicator lights on the shaver will illuminate to show charging progress. They will typically turn off or change color when fully charged.



Figure 3.1: An angled view of the Xiaomi Mijia Electric Shaver 2, highlighting the power button, battery indicators, and the USB-C charging port located at the bottom.




Figure 3.2: A close-up view of the shaver's base, emphasizing the USB Type-C charging port and indicating long battery life with a 2-hour charge time for 90 minutes of use, alongside a diagram of the ECM Electrochemical Processing Technology for smooth blades.

4. OPERATING THE SHAVER

Turning On/Off:

- To turn on the shaver, press the power button once.
- To turn off the shaver, press the power button once again.

Shaving Technique:

- For best results, hold the shaver at a right angle to your skin.
- Move the shaver in small, circular motions against the direction of hair growth.
- Apply gentle pressure. The floating heads are designed to adapt to your facial contours.
- The shaver can be used for both dry shaving and wet shaving with foam or gel.

Travel Lock Function:

The shaver features a double security protection travel lock to prevent accidental activation.

- To activate the travel lock, press and hold the power button for approximately 3 seconds until the lock indicator light appears.
- To deactivate the travel lock, press and hold the power button again for approximately 3 seconds until the lock indicator light disappears.




Figure 4.1: A composite image illustrating key features: a hand holding the shaver, demonstrating its portability; icons for double security protection (travel lock); a storage bag; and the battery indicator lights.

5. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and hygiene of your shaver.

Daily Cleaning:

1. Turn off the shaver.
2. Gently twist and pull off the shaver head assembly.
3. Rinse the shaver head and the main body (where the hair collects) under running water to remove hair clippings and residue.
4. Shake off excess water and allow both parts to air dry completely before reattaching the head.

Deep Cleaning (Periodically):

For a more thorough clean, you may use a small brush (if provided) to remove stubborn hair particles from the blades and inner components of the shaver head.

Battery Care:

- Avoid completely draining the battery frequently to prolong its lifespan.
- If storing the shaver for an extended period, charge it to about 50% capacity.
- The battery indicator lights will show the remaining charge level. Recharge when the indicator shows low battery.

6. TROUBLESHOOTING

If you encounter issues with your Xiaomi Mijia Electric Shaver 2, refer to the following common problems and solutions:

- **Shaver does not turn on:**
 - Ensure the shaver is charged. Connect it to a power source and check the charging indicator.
 - Check if the travel lock is activated. Deactivate it by pressing and holding the power button for 3 seconds.
- **Poor shaving performance:**
 - Clean the shaver head thoroughly to remove any accumulated hair or debris.
 - Ensure the shaver is fully charged. Low battery can affect motor speed.
 - For optimal performance, consider replacing the shaver heads if they are worn out (replacement parts sold separately, if available).
- **Shaver makes unusual noise:**
 - Clean the shaver head. Hair or debris caught in the blades can cause unusual sounds.
 - Ensure the shaver head is properly reattached after cleaning.

If the problem persists after trying these steps, please contact customer support.

7. SPECIFICATIONS

Feature	Detail
Model Name	MSX201
Brand	Xiaomi
Power Source	Battery Powered (USB Rechargeable)
Special Feature	Rechargeable, Floating Head, Waterproof
Included Components	Shaver, Battery (internal)
Package Dimensions	6.81 x 4.33 x 1.77 inches
Item Weight	3 ounces (approx. 85 grams)
Manufacturer	xiaomi



8. WARRANTY AND SUPPORT


For information regarding product warranty, returns, or technical support, please refer to the warranty card included with your product packaging or visit the official Xiaomi website. Specific warranty terms and conditions may vary by region.

For further assistance, you may also contact the seller or retailer from whom you purchased the product.

© 2025 Xiaomi. All rights reserved.


Related Documents - MSX201

	<p>XIAOMI Mijia S500 Electric Shaver User Manual</p> <p>Official user manual for the XIAOMI Mijia S500 Electric Shaver, detailing features, operation, and maintenance for men's grooming needs. Includes information on dry and wet shaving.</p>
	<p>Xiaomi Mijia S700 Electric Shaver User Manual</p> <p>Comprehensive user manual for the Xiaomi Mijia S700 electric shaver, detailing safety precautions, operating instructions, device overview, cleaning, maintenance, and power indicator status.</p>



[Xiaomi Mijia Hair Clipper 2 User Manual and FAQ](#)

Comprehensive user manual and frequently asked questions for the Xiaomi Mijia Hair Clipper 2, covering features, usage, maintenance, and troubleshooting for this IPX7 waterproof hair trimmer.



[Xiaomi Mijia Hair Clipper 2 User Manual - MJGHHHC2LF | Guide & Specifications](#)

Comprehensive user manual for the Xiaomi Mijia Hair Clipper 2 (Model MJGHHHC2LF). Find instructions on usage, safety, maintenance, troubleshooting, and specifications for this professional hair cutting tool.



[Xiaomi Mi \(Mijia\) Electric Shaver S500/S500C User Manual | Instructions & Specifications](#)

Comprehensive user manual for the Xiaomi Mi (Mijia) Electric Shaver models S500 and S500C. Find detailed instructions on operation, cleaning, maintenance, safety precautions, and technical specifications. Published by Rumicom.



[Xiaomi Mijia S700 Электробритва: Руководство пользователя и инструкция по эксплуатации](#)

Полное руководство пользователя для электробритвы Xiaomi Mijia S700. Узнайте о мерах предосторожности, функциях прибора, порядке использования, индикаторах питания и правилах очистки.

