

COSIEST C1001002

COSIEST 3 Piece Bistro Set Instruction Manual

Model: C1001002 | Brand: COSIEST

PRODUCT OVERVIEW

The COSIEST 3 Piece Bistro Set is designed for outdoor use, featuring two rocking chairs and a glass-top side table. This set combines elegance with durability, constructed from dark gray powder-coated, rust-resistant steel frames and complemented by warm gray cushions made from color-fast, all-weather poly-fiber fabric. It is suitable for various outdoor settings such as gardens, poolsides, and backyards, providing a comfortable and stable seating solution.



Image: The complete COSIEST 3 Piece Bistro Set, showcasing two rocking chairs with cushions and a central glass-top table.

SETUP AND ASSEMBLY

The COSIEST Bistro Set is designed for straightforward assembly. All necessary tools and detailed instructions are included to facilitate the process. Assembly typically takes approximately 45 minutes to an hour for two people.

Assembly Steps:

- 1. Unpack all components and verify against the parts list provided in the instruction manual.

2. Assemble the chair frames according to the diagrams, ensuring all bolts are securely tightened.
3. Attach the rocking bases to the chair frames.
4. Assemble the glass-top side table.
5. Place the seat and back cushions onto the chairs.




Image: Detailed dimensions of the rocking chairs and the side table, useful for planning placement.

OPERATING INSTRUCTIONS

The COSIEST Bistro Set provides a comfortable and relaxing experience. The rocking chairs feature an ergonomically optimal design with extra-wide 2-inch armrests and X-frame reinforcements for stability and an effortless rock. The included tempered glass-top side table offers a steady surface for beverages or small items.



Image: A single rocking chair and the glass-top table positioned on a patio, demonstrating typical use.

MAINTENANCE AND CARE

Proper maintenance will extend the life and appearance of your COSIEST Bistro Set.

- **Frame Care:** Wipe the iron frame with a dry cloth to remove dust and debris. Avoid harsh chemicals that may damage the powder-coated finish.
- **Cushion Care:** The cushions are made from solution-dyed poly-fiber fabric, offering superior color fastness (2 to 3 years in direct sunlight) and resistance to weather extremes. The cushion covers can be folded up for easy cleaning or to protect them from pets or adverse weather conditions overnight or during extended periods of non-use.
- **Glass Tabletop:** Clean the tempered glass tabletop with a soft cloth and a mild glass cleaner.
- **General:** Always follow the care instructions to maintain the product's safety and longevity.



Image: A close-up view of the chair's frame, highlighting the durable X-frame reinforcement.

SAFETY INFORMATION

Please adhere to the following safety guidelines to ensure safe use of your bistro set:

- Always assemble the furniture according to the provided instructions.
- Keep the rocking chairs on a stable, level surface to prevent tipping.
- Do not leave children unattended while using the furniture.
- Ensure all connections are secure before each use.

TROUBLESHOOTING

Should you encounter any issues with your COSIEST Bistro Set, please review the assembly instructions to ensure all steps were followed correctly. For persistent problems or concerns, refer to the "Support and Contact" section for assistance.

SPECIFICATIONS

Feature	Detail
Brand	COSIEST
Model Number	C1001002
Material (Frame)	Iron (Rust Proof)
Material (Cushion)	Poly-fiber Fabric
Color (Frame)	Black
Color (Cushion)	Warm Gray
Product Dimensions (L x W x H)	28.35 x 23.62 x 15.94 inches
Item Weight	57.3 pounds
Chair Dimensions	31.7" (D) x 24.5" (W) x 32.6" (H)
Coffee Table Dimensions	19" (L) x 19" (W) x 19" (H)
Weight Capacity	350 lbs
UPC	712636975149

SUPPORT AND CONTACT

For any questions, concerns, or assistance with your COSIEST 3 Piece Bistro Set, please contact COSIEST customer support. You can find contact information on the official COSIEST website or through your purchase platform.
[Visit the COSIEST Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07T2YTKFK>

More documents and user manuals: <https://manuals.plus/>