

[Manuals.plus](#) /

> [Paw Patrol](#) /

> Paw Patrol Marshall RC Fire Truck Instruction Manual

Paw Patrol 6054624

Paw Patrol Marshall RC Fire Truck Instruction Manual

Model: 6054624

INTRODUCTION

Welcome to the world of PAW Patrol! This instruction manual provides essential information for the safe and proper operation of your new Paw Patrol Marshall RC Fire Truck. Please read this manual thoroughly before use and retain it for future reference.



Image: The Paw Patrol Marshall RC Fire Truck, shown in its retail packaging, featuring Marshall the firefighter pup in his red fire truck and the easy-to-use Pup Pad controller.

WHAT'S INCLUDED

Your package should contain the following items:

- 1 Marshall RC Fire Truck
- 1 Pup Pad Controller
- 1 Instruction Guide (this document)

SETUP

Battery Installation

The Marshall RC Fire Truck and Pup Pad Controller require batteries for operation. Batteries are not included.

1. Locate the battery compartments on the underside of the Marshall RC Fire Truck and the back of the Pup Pad Controller.
2. Using a screwdriver (not included), open the battery compartment covers.
3. Insert 3 AAA batteries into the vehicle, ensuring correct polarity (+/-).
4. Insert 2 AA batteries into the controller, ensuring correct polarity (+/-).
5. Replace the battery compartment covers and secure them with the screws.

Initial Pairing

To establish a connection between the truck and the controller:

1. Ensure fresh batteries are installed in both the Marshall RC Fire Truck and the Pup Pad Controller.
2. Turn on the power switch located on the vehicle.
3. Turn on the power switch on the Pup Pad Controller.
4. The controller and vehicle should automatically pair. A red indicator light on the controller will illuminate when connected.



Image: A close-up view of the blue and grey Pup Pad Controller, showing the two large, easy-to-press buttons for forward and reverse/turn controls.

OPERATING INSTRUCTIONS

The Pup Pad Controller features a simple two-button design for easy operation.

- **Forward Button:** Press the button with the upward arrow to drive the Marshall RC Fire Truck forward.
- **Reverse/Turn Button:** Press the button with the curved arrow to make the Marshall RC Fire Truck reverse and turn simultaneously.

The controller operates on a 2.4GHz frequency, allowing control from up to 250 feet away. For optimal performance, operate the toy on flat, clear surfaces.



Image: A child smiling while operating the Marshall RC Fire Truck with the Pup Pad controller on a playmat, demonstrating active use of the toy.

MAINTENANCE

To ensure the longevity and proper functioning of your Marshall RC Fire Truck:

- **Cleaning:** Wipe the truck and controller with a clean, damp cloth. Do not immerse in water.
- **Storage:** Store the toy in a cool, dry place away from direct sunlight when not in use. Remove batteries if storing for extended periods to prevent leakage.
- **Battery Care:** Always use new batteries of the recommended type. Do not mix old and new batteries, or different types of batteries. Dispose of used batteries responsibly.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Truck does not respond to controller.	Low or dead batteries; Not paired; Out of range.	Replace batteries in both truck and controller; Ensure both are turned on and within 250 feet of each other.
Truck moves slowly or erratically.	Low batteries.	Replace batteries in both truck and controller.

Problem	Possible Cause	Solution
Interference with other RC toys.	Multiple 2.4GHz devices nearby.	Move to an area with less interference or try operating one toy at a time.

SPECIFICATIONS

Feature	Detail
Brand	Paw Patrol
Model Number	6054624
Power Source	Battery Powered
Vehicle Batteries Required	3 x AAA (not included)
Controller Batteries Required	2 x AA (not included)
Operation Mode	Remote Control (2-way steering)
Material Type	Plastic
Item Dimensions	8.3 x 5 x 6.25 inches
Item Weight	0.56 Kilograms
Recommended Age	3 years and up



Image: A side view of the Marshall RC Fire Truck, showcasing its red body, grey accents, and Marshall character molded into the driver's seat.

SAFETY INFORMATION

- **Choking Hazard:** Small parts. Not for children under 3 years.
- **Battery Safety:** Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries. Do not mix old and new batteries. Non-rechargeable batteries are not to be recharged. Rechargeable batteries are only to be charged under adult supervision. Exhausted batteries are to be removed from the toy. The supply terminals are not to be short-circuited.
- **Supervision:** Adult supervision is recommended during play.
- **Environment:** Do not operate near water or in wet conditions. Avoid operating near electrical hazards.

WARRANTY AND SUPPORT

This product is sold without a manufacturer's warranty as per the product specifications. For any questions or concerns regarding the product, please contact the retailer or the manufacturer, Spin Master, directly.

