#### Manuals+

Q & A | Deep Search | Upload

#### manuals.plus /

- Amazon Basics /
- > Amazon Basics Bike Cable Lock (Model AB-BL105) Instruction Manual

#### **Amazon Basics AB-BL105**

# Amazon Basics Bike Cable Lock (Model AB-BL105) - Instruction Manual

Your guide to securing your bicycle and other valuables.

#### 1. Introduction

Thank you for choosing the Amazon Basics Bike Cable Lock. This 6-foot keyed cable lock is designed to provide reliable security for your bicycle, helmets, backpacks, and luggage. Constructed from durable steel with a weather-resistant plastic coating, it offers both strength and protection against the elements. This manual will guide you through the proper use and care of your new lock.



Figure 1: Amazon Basics 6-foot Bike Cable Lock, coiled with two keys.

## 2. PACKAGE CONTENTS

- 1 x Amazon Basics Bike Cable Lock (Model AB-BL105)
- 2 x Keys

# 3. SETUP

Your Amazon Basics Bike Cable Lock comes ready to use. No assembly is required. Familiarize yourself with the lock mechanism and keys before first use.

# 3.1 Key Operation

- The lock features a protective key cover. Slide the blue cover to expose the keyhole.
- Insert one of the provided keys into the keyhole.
- Turn the key to unlock the cable.
- To lock, simply push the cable end into the lock mechanism until it clicks. The lock can be secured without the key.
- Remove the key and slide the key cover back into place to protect the mechanism from dirt and moisture.



Figure 2: Close-up of the lock mechanism with key cover.

# 4. OPERATING INSTRUCTIONS

Follow these steps to effectively secure your belongings:

- 1. **Choose a Secure Object:** Select a sturdy, immovable object to secure your bike or item to, such as a bike rack, lamppost, or fence.
- 2. **Position the Cable:** Loop the 70-inch (6-foot) cable through the frame of your bicycle (and ideally a wheel) and around the chosen secure object. Ensure the cable is not easily removable or cuttable.
- 3. **Engage the Lock:** Insert the free end of the cable into the locking mechanism. Push firmly until you hear a click, indicating it is securely locked. Remember, the lock can be engaged without the key.
- 4. **Verify Security:** Gently tug on the cable and the lock to ensure it is properly secured and cannot be easily dislodged.
- 5. **Unlock:** To unlock, insert the key into the keyhole (after sliding the cover) and turn it. The cable end will release from the mechanism.




Figure 3: Bike Cable Lock in use.

#### **Official Product Overview Video**

Your browser does not support the video tag.

Video 1: An official overview of the Amazon Basics Bike Cable Lock, demonstrating its features and basic operation.

#### **Demonstration of a Similar Cable Lock**

Your browser does not support the video tag.

Video 2: A demonstration of a similar keyed cable lock, showing how it can be mounted and used to secure a bicycle.

## 5. MAINTENANCE


- Keep Keys Safe: Store your spare key in a secure location. Avoid keeping both keys in the same place.
- Clean Keyhole: Periodically clean the keyhole to prevent dirt and debris from accumulating, which can affect the locking mechanism's performance. Use a small amount of graphite lubricant if the key becomes stiff
- **Inspect Cable:** Regularly check the steel cable and plastic coating for any signs of wear, cuts, or damage. Replace the lock if significant damage is observed.
- Weather Protection: Always ensure the key cover is closed when not in use to protect the internal

## 6. TROUBLESHOOTING

- Key is Stiff/Hard to Turn: Apply a small amount of graphite lubricant into the keyhole. Avoid using oil-based lubricants as they can attract dirt.
- Cable Not Locking: Ensure the cable end is fully inserted into the locking mechanism until a distinct click is heard. Check for any obstructions in the mechanism.
- Lost Keys: If both keys are lost, the lock will need to be replaced. Keep a spare key in a safe, separate location.

## 7. SPECIFICATIONS

Feature	Detail
Brand	Amazon Basics
Model Name	Bike Cable Lock
Model Number	AB-BL105
Lock Type	Cable, Keyed
Cable Length	70 inches (approx. 6 feet)
Cable Diameter	8mm
Material	Durable Steel, Plastic Coating
Color	Black
Included Components	1 x Cable Lock, 2 x Keys
Item Weight	0.28 Kilograms



#### 8. WARRANTY AND SUPPORT

The Amazon Basics Bike Cable Lock is backed by a 1-Year Limited Warranty. For warranty claims, product support, or further assistance, please refer to the contact information provided with your purchase or visit the official Amazon Basics support page.

© 2025 Amazon Basics. All rights reserved.

#### Related Documents - AB-BL105



#### Amazon Basics 5/8" Curtain Rod with Finials - 48" to 88" Installation and Safety Guide

This guide provides essential safety information, specifications, and installation instructions for the Amazon Basics 5/8" Curtain Rod with Finials, adjustable from 48" to 88" (122-224 cm). Learn how to safely install and maintain your curtain rod.



#### Amazon Basics Electronic Touchscreen Deadbolt Door Lock Installation Manual

Installation manual for the Amazon Basics Electronic Touchscreen Deadbolt Door Lock with Passage Lever. Provides product overview, parts list, and step-by-step installation guidance for various door types in multiple languages.



# Amazon Basics Cat6 Ethernet Cable (1000 Ft / 305m) - Product Information and Safety Guide

Comprehensive product information for the Amazon Basics Cat6 Ethernet Cable (1000 Ft / 305m). Covers intended use, critical safety precautions, environmental disposal guidelines, and feedback channels, presented in English with references to multilingual content.



#### Amazon Basics 5-Tier Ladder Bookshelf Organizer - User Manual and Safety Guide

Comprehensive user manual and safety guide for the Amazon Basics 5-Tier Ladder Bookshelf Organizer. Includes important safety warnings, assembly tips, cleaning instructions, maintenance advice, disposal guidelines, and product specifications.

