

[manuals.plus](#) /

› [VINCI](#) /

› [Vinci Hands Free Electric Citrus Juicer Instruction Manual](#)

**VINCI E19010**

## **Vinci Hands Free Electric Citrus Juicer Instruction Manual**

Model: E19010

Brand: VINCI

### **INTRODUCTION**

Thank you for choosing the Vinci Hands Free Electric Citrus Juicer. This innovative appliance is designed to make juicing citrus fruits effortless and efficient. With its 1-button automated press operation and hands-free design, you can enjoy fresh, healthy juice with minimal effort. Please read this manual thoroughly before first use to ensure safe and optimal operation of your juicer.



*The Vinci Hands Free Electric Citrus Juicer, ready to extract fresh juice, shown alongside a glass of freshly squeezed orange juice.*

#### **IMPORTANT SAFETY INFORMATION**

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire,

electric shock, and/or injury to persons, including the following:

- Read all instructions before using the juicer.
- Do not immerse the motor base in water or other liquids.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always ensure the lid is securely locked before operating.
- This appliance is for household use only.

## PRODUCT COMPONENTS

Familiarize yourself with the parts of your Vinci Hands Free Electric Citrus Juicer:

- A. Locking Latch:** Secures the lid during operation.
- B. Juicing Cone/Reamer:** Extracts juice from citrus halves.
- C. Pulp Filters (Low & High):** Interchangeable filters to control pulp level.
- D. 12 oz. Juice Bowl:** Collects the extracted juice.
- E. Locking Pour Spout:** Allows for controlled pouring of juice.
- F. One-Button Hands-Free Juicing Button:** Initiates the automatic juicing process.
- G. Motor Base:** Contains the motor and controls.

## FEATURING

Pressure Sensitive  
Juicing Technology



2 Interchangeable Filters  
1 Low & 1 High Pulp Filters



Locking Latch

Detachable  
Parts Top Rack  
Dishwasher Safe

12 oz. Juice Bowl

Locking Pour Spout



One Button  
Hands Free Juicing

*Detailed view of the Vinci Juicer highlighting its key components and features.*

# INTERCHANGEABLE PULP FILTERS

**LOW PULP**

**HIGH PULP**



*The two interchangeable pulp filters: Low Pulp (left) and High Pulp (right).*

## SETUP

- 1. Unpack:** Carefully remove all parts from the packaging.
- 2. Clean:** Before first use, wash all removable parts (juicing cone, pulp filters, juice bowl, lid) in warm, soapy water or place them on the top rack of your dishwasher. Rinse thoroughly and dry. Wipe the motor base with a damp cloth.
- 3. Assemble:**
  - Place the desired pulp filter (low or high) onto the juicing cone.
  - Place the assembled juicing cone and filter into the juice bowl.
  - Align the juice bowl assembly onto the motor base, ensuring it clicks into place.
  - Close the lid and ensure the locking latch is securely fastened.
- 4. Position:** Place the juicer on a stable, flat, and dry surface.

5. **Connect Power:** Plug the power cord into a standard 120V electrical outlet.

## OPERATING INSTRUCTIONS

The Vinci Hands Free Electric Citrus Juicer simplifies the juicing process into three easy steps:

1. **Slice Fruit:** Cut your citrus fruit (lemons, limes, oranges, grapefruits up to 4.5 inches in diameter) in half.
2. **Place Fruit:** Open the juicer lid. Place one half of the citrus fruit cut-side down onto the juicing cone.
3. **Press Button:** Close the lid and ensure the locking latch is engaged. Press the one-button hands-free juicing button. The juicer will automatically press and rotate the fruit to extract the maximum amount of juice.
4. **Dispense Juice:** Once juicing is complete, open the locking pour spout on the juice bowl to dispense fresh juice directly into a glass or container.

# Delicious JUICE in 3 EASY STEPS



**1 SLICE**



**2 PLACE**



**3 PRESS**



*The simple 3-step process: Slice the fruit, place it on the reamer, and press the button to extract juice.*



Vinci®

New Automatic  
**PRESSURE  
SENSITIVE**  
Juicing Technology

Juice  
**ANY SIZE CITRUS**  
from *Small Limes*  
to *Large Grapefruit*



The juicer utilizes new automatic pressure sensitive juicing technology and can juice any size citrus, from small limes to large grapefruits.

## CLEANING AND MAINTENANCE

Proper cleaning ensures the longevity and hygiene of your juicer. All removable parts are top-rack dishwasher safe.

- Unplug:** Always unplug the juicer from the power outlet before cleaning.
- Disassemble:** Open the lid, unlatch the juice bowl, and remove the juicing cone and pulp filter.
- Wash Removable Parts:** Wash the lid, juicing cone, pulp filter, and juice bowl in warm, soapy water or place them on the top rack of your dishwasher.
- Clean Motor Base:** Wipe the motor base with a damp cloth. Do not immerse the motor base in water or any other liquid.
- Dry:** Ensure all parts are completely dry before reassembling or storing.
- Storage:** Store the juicer in a clean, dry place.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Juicer does not turn on.	Not plugged in; power switch off; lid not properly closed/latched.	Ensure the juicer is securely plugged into a working outlet. Check if the red power switch is on. Make sure the lid is fully closed and the locking latch is engaged.
Juicer stops during operation.	Overload protection activated; lid opened during operation.	Unplug the juicer and let it cool down for 15-20 minutes. Reduce the pressure applied to the fruit. Ensure the lid remains closed and latched throughout the juicing cycle.
Poor juice extraction.	Fruit not properly centered; reamer/filter clogged; fruit too large/small.	Ensure the fruit half is centered on the reamer. Clean the reamer and filter if clogged with pulp. Use citrus fruits within the recommended 4.5-inch diameter.
Juice leaks from the spout.	Pour spout not closed; juice bowl not properly seated.	Ensure the locking pour spout is in the closed position when not dispensing. Verify the juice bowl is correctly aligned and seated on the motor base.

## SPECIFICATIONS

<b>Brand</b>	VINCI
<b>Model Number</b>	E19010
<b>Color</b>	Black/Stainless Steel
<b>Product Dimensions</b>	8.5"D x 7"W x 12.5"H
<b>Capacity</b>	12 Fluid Ounces (Juice Bowl)
<b>Maximum Power</b>	50 Watts
<b>Voltage</b>	120 Volts
<b>Power Source</b>	Corded Electric
<b>Blade Material</b>	Stainless Steel (Reamer)
<b>Special Features</b>	BPA-Free Tritan Plastic Juicer Bowl, Dishwasher-Safe (Top Rack) Removable Parts, Low & High Pulp Filters Included

## **WARRANTY AND SUPPORT**

For warranty information or technical support, please refer to the official VINCI website or contact their customer service directly. Keep your purchase receipt as proof of purchase for warranty claims.

You can also find additional support and product information by visiting the [VINCI Store on Amazon](#).

A digital version of the user manual is also available for download: [User Manual \(PDF\)](#).

© 2023 VINCI. All rights reserved.