

[Manuals.plus](#) /

> [Noma](#) /

> NOMA LED Flush Mount Light Fixture 13-inch User Manual (Model B07T3GDYPK)

Noma B07T3GDYPK (13-inch)

NOMA LED Flush Mount Light Fixture

Model: B07T3GDYPK (13-inch)

Brand: Noma

1. INTRODUCTION

This manual provides detailed instructions for the safe installation, operation, and maintenance of your NOMA 13-inch LED Flush Mount Light Fixture. This modern ceiling light is designed for indoor use in various rooms such as bathrooms, kitchens, and living rooms, featuring a dimmable LED light source and a durable metal base.

2. SAFETY INFORMATION

WARNING: To avoid electric shock, always turn off power at the main circuit breaker or fuse box before beginning installation or performing any maintenance. Do not attempt installation if you are not familiar with electrical wiring. Consult a qualified electrician.

- Read all instructions carefully before installation.
- Ensure the electrical supply to the fixture is disconnected before installation or servicing.
- This fixture is designed for indoor use only.
- Do not exceed the specified voltage (120 Volts).
- Handle the fixture with care to prevent damage.
- Keep packaging materials away from children.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation. If any parts are missing or damaged, do not proceed with installation and contact customer support.

- LED Flush Mount Light Fixture (1)
- Mounting Bracket (1)

- Mounting Screws (2)
- Wire Nuts (3)
- Instruction Manual (1)



Figure 1: NOMA 13-inch LED Flush Mount Light Fixture. This image shows the complete light fixture, a round, white unit with a metal base and a frosted diffuser.

4. SETUP AND INSTALLATION

Follow these steps carefully to install your NOMA LED Flush Mount Light Fixture. Professional installation is recommended if you are unsure about any steps.

1. **Turn Off Power:** Locate the circuit breaker or fuse box that controls the power to the light fixture location. Turn off the power completely to prevent electrical shock.
2. **Prepare Mounting Surface:** Ensure the ceiling junction box is securely mounted and capable of supporting the fixture's weight.
3. **Attach Mounting Bracket:** Secure the provided mounting bracket to the junction box using the mounting screws. Ensure it is firmly attached.
4. **Wire Connections:** Carefully connect the electrical wires. Match the black wire from the fixture to the black (live) wire from the junction box, the white wire from the fixture to the white (neutral) wire from the junction box, and the ground wire from the fixture to the ground wire from the junction box. Use the provided wire nuts to secure connections. Ensure all connections are tight and no bare wire is exposed.
5. **Secure Fixture:** Carefully align the light fixture with the mounting bracket and secure it in place. Refer to the internal view for component understanding.



Figure 2: Internal view of the NOMA LED Flush Mount Light Fixture. This image displays the internal LED array and wiring components, visible when the diffuser is removed, which is relevant for understanding the light source and potential wiring access.

5. OPERATING INSTRUCTIONS

Once installed, your NOMA LED Flush Mount Light Fixture is ready for use.

- **Turning On/Off:** Use your standard wall switch to turn the light fixture on or off.
- **Dimming Function:** This fixture is dimmable. To utilize the dimming feature, ensure you have a compatible dimmer switch installed on your wall. The control method is typically a push-button or touch-sensitive dimmer switch. Adjust the dimmer switch to achieve your desired light intensity.

6. MAINTENANCE

Regular cleaning will help maintain the appearance and performance of your light fixture.

- **Cleaning:** Ensure the power is turned off before cleaning. Use a soft, dry, or slightly damp cloth to wipe the exterior of the fixture. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish or electrical components.
- **LEDs:** The integrated LED light source is designed for long-term use and does not require replacement.

7. TROUBLESHOOTING

If you encounter issues with your light fixture, refer to the following common problems and solutions:

- **Light does not turn on:**
 - Check if the power is on at the circuit breaker.
 - Ensure all wire connections are secure and correct.
 - Verify the wall switch is in the 'ON' position.

- **Light flickers or dims improperly:**
 - Ensure you are using a compatible LED dimmer switch.
 - Check for loose wire connections.
- **Light is too dim or too bright:**
 - Adjust your dimmer switch to the desired brightness level.

If problems persist after attempting these solutions, contact customer support.

8. SPECIFICATIONS

Brand	Noma
Model Number	B07T3GDYPK
Size	13-inch (33 x 33 x 6.1 cm)
Material	Metal (Base), Frosted (Shade)
Colour	White
Light Source	Integrated LED
Wattage	24 watts
Voltage	120 Volts
Light Color	Warm White
Special Feature	Dimmable
Installation Type	Flush Mount
Indoor/Outdoor Usage	Indoor
Assembly Required	No

9. WARRANTY AND SUPPORT

This NOMA LED Flush Mount Light Fixture comes with a **1-year limited warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. For warranty claims, technical support, or any questions regarding your product, please contact NOMA customer service. Keep your proof of purchase for warranty validation.