Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ChooChoo Oxford (EUR-CT19004-BR)

ChooChoo Oxford Coffee Table User Manual

Model: Oxford (EUR-CT19004-BR)

Introduction

Thank you for purchasing the ChooChoo Oxford Coffee Table. This manual provides detailed instructions for assembly, usage, maintenance, and troubleshooting to ensure you get the most out of your new furniture. Please read this manual thoroughly before assembly and retain it for future reference.
The ChooChoo Oxford Coffee Table is a stylish and functional piece designed for living rooms, featuring a durable wood construction, a unique X-design, and a convenient 2-tier storage shelf. Its espresso finish complements both traditional and modern interior designs.

Important Safety Information

CAUTION:

- Avoid placing heavy objects on the table that may exceed the maximum weight recommendation of 40 pounds.
- Keep fingers and small objects away from the space between the floor and the bottom shelf to prevent pinch points.
- Always follow the assembly instructions carefully and avoid using power tools, as this may damage the furniture or cause injury.
- Ensure the table is properly anchored to prevent tipping or collapse, especially in households with children or pets.
- Do not stand or sit on the coffee table.

Parts List

Before beginning assembly, please ensure all parts are present and undamaged. Refer to the diagram below for identification. If any parts are missing or damaged, please contact customer service.



Figure 1: Exploded view of coffee table components and hardware.

Part	Description	Quantity
A	Table Top	1
B	Bottom Shelf	1
C	Legs (with X-design)	4
D	Side Support Beams	2
E	Hardware Pack (Screws, Dowels, Allen Wrench)	1

Setup and Assembly

Detailed instructions will guide the assembly step by step. All parts and accessories are numbered and easy to distinguish. It is recommended that two people assemble this product.

Tools Required:

- Phillips Head Screwdriver (not included, but recommended for some screws)
- Allen Wrench (included in hardware pack)

Assembly Steps:

1. **Step 1: Attach Side Support Beams to Legs.** Identify the four legs (C) and the two side support beams (D). Using the provided screws from the hardware pack (E), attach the side support beams to the top inner side of two legs each, forming two 'X' frames. Ensure the X-design faces outwards.
2. **Step 2: Connect the Leg Assemblies.** Take the two assembled leg frames from Step 1. Position them parallel to

each other. Attach the remaining two legs (C) to the other ends of the side support beams (D) using screws, completing the base frame.

3. **Step 3: Install the Bottom Shelf.** Carefully slide the bottom shelf (B) into the grooves or attach it to the designated supports on the inner side of the legs. Secure it with screws or dowels as indicated in the detailed diagram.
4. **Step 4: Attach the Table Top.** Place the table top (A) upside down on a soft, clean surface to prevent scratches. Carefully align the assembled base frame with the pre-drilled holes on the underside of the table top. Secure the table top to the base using the remaining screws.
5. **Step 5: Final Tightening and Placement.** Once all parts are assembled, gently turn the coffee table upright. Double-check that all screws are tightened securely. Place the coffee table in its desired location.



Figure 2: Fully assembled ChooChoo Oxford Coffee Table.

Operating and Usage

The ChooChoo Oxford Coffee Table is designed for residential use in living room settings. It features a spacious top surface and a lower shelf for storage and display.

Key Features:

- **Solid Construction:** Made from hardwood and manufactured wood (Natural Rubber Wood, Pine, MDF) with a high-quality paint finish for stability and durability.
- **Unique X Design:** Rustic X-design side trusses provide stability and a modern aesthetic.
- **2-Tier Storage:** Offers ample storage space on the top surface and the lower shelf for books, magazines, remote controls, or decorative items.



Figure 3: Coffee table in use, showcasing its design and functionality.



Figure 4: Close-up of the table's surface and storage shelf.

Maintenance and Care

Proper care will extend the life and maintain the appearance of your ChooChoo Oxford Coffee Table.

- **Cleaning:** Wipe with a dry cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Spills:** Immediately wipe up any spills with a soft, dry cloth to prevent staining or water damage.
- **Heat and Moisture:** Use coasters under hot or cold beverages to protect the surface from rings and marks. Avoid placing hot items directly on the table.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration of the wood finish.
- **Movement:** When moving the table, lift it rather than dragging it to prevent damage to the legs and floor.
- **Periodic Check:** Periodically check and tighten all screws to ensure the table remains stable and secure.

Troubleshooting

If you encounter any issues with your coffee table, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Table is wobbly.	Screws are loose; uneven floor.	Tighten all assembly screws. Move the table to a level surface or use furniture pads under the legs to stabilize.
Parts do not align during assembly.	Incorrect orientation of parts; screws not fully loosened.	Review the assembly diagrams carefully. Ensure parts are oriented correctly (e.g., X-design facing outwards). Loosen screws slightly, adjust alignment, then re-tighten.
Scratches or minor damage to finish.	Accidental impact; improper cleaning.	For minor scratches, use a wood repair marker or furniture polish matching the espresso finish. Always use soft cloths for cleaning.

Specifications

Feature	Detail
Brand	ChooChoo
Model Name	Oxford
Model Number	EUR-CT19004-BR
Product Dimensions (L x W x H)	39.3" x 21.6" x 17.7" (99.8 cm x 54.9 cm x 45 cm)
Color	Espresso
Material Type	Hardwood, Rubber Wood, Pine, MDF (Engineered Wood)
Maximum Weight Recommendation	40 Pounds (18.1 kg)
Number of Shelves	1 (bottom shelf)
Product Care Instructions	Wipe with Dry Cloth
Recommended Assembly Persons	2
Frame Joint Type	Screw or dowel joint



Figure 5: Detailed dimensions of the coffee table.

Warranty and Support

ChooChoo stands behind the quality of its products. For any questions, missing parts, or assistance with assembly, please contact our customer service. The email address for service is typically provided on the manual included in the product

packaging.
Please refer to your purchase documentation for specific warranty details. Keep your proof of purchase for any warranty claims.
For more information about ChooChoo products, you can visit the officialChooChoo Store on Amazon.

Product Videos

Watch these official videos for additional guidance and product overview.

Your browser does not support the video tag.

Video 1: A short preview video showcasing the ChooChoo Oxford Coffee Table in a living room setting, highlighting its design and espresso finish.

Your browser does not support the video tag.

Video 2: Another short preview video demonstrating the stability and general appearance of the coffee table.

© 2025 ChooChoo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07T49J71B

More documents and user manuals: **https://manuals.plus/**