

[Manuals.plus](#) /

› [ZEBRONICS](#) /

› Zeb-Bro In-Ear Wired Earphones User Manual

ZEBRONICS Zeb-Bro

Zeb-Bro In-Ear Wired Earphones User Manual

Model: Zeb-Bro

Brand: ZEBRONICS

INTRODUCTION

The Zeb-Bro in-ear wired earphones are designed to provide a comfortable and immersive audio experience. Featuring a 3.5mm audio jack for universal compatibility and 10mm drivers for clear sound, these earphones are suitable for various devices including mobile phones and tablets. The snug fit ensures comfort during extended use and contributes to passive noise cancellation, allowing for an enhanced listening experience. This manual provides essential information on setup, operation, maintenance, and troubleshooting.

IMPORTANT SAFETY INFORMATION

- Avoid listening at high volume levels for prolonged periods to prevent hearing damage.
- Do not use the earphones in situations where inability to hear ambient sounds could be dangerous (e.g., while driving, cycling, or walking in traffic).
- Keep the earphones dry. Do not expose them to water or moisture. The product is not water resistant.
- Handle the earphones with care. Avoid dropping or subjecting them to strong impacts.
- Keep out of reach of children. Small parts may pose a choking hazard.

PACKAGE CONTENTS

- 1 unit of Zeb-Bro Earphone

PRODUCT OVERVIEW

The Zeb-Bro earphones feature a classic in-ear design with a durable cable and a standard 3.5mm audio jack for broad compatibility.





Figure 1: Overall view of Zeb-Bro In-Ear Wired Earphones with 3.5mm jack and in-line controls.

The earphones are equipped with 10mm dynamic drivers designed to deliver clear audio across a frequency range of 20Hz to 20kHz.

10 mm Driver



Figure 2: Close-up of the earbud highlighting the 10mm driver.

An integrated microphone and in-line controls allow for convenient call management and media playback.



**Call function
with built-in Mic**

Figure 3: The in-line control unit with built-in microphone for call functions.

SETUP

Connecting your Zeb-Bro earphones is a simple process:

1. Locate the 3.5mm audio jack on your smartphone, tablet, or other compatible audio device.
2. Insert the 3.5mm plug of the Zeb-Bro earphones firmly into the audio jack of your device.
3. Wait a few seconds for the earphones to synchronize with your device.
4. Adjust the volume on your device to a comfortable listening level.



Figure 4: The 3.5mm audio jack for connecting to devices.

OPERATING INSTRUCTIONS

Audio Playback

Once connected, audio from your device will automatically play through the earphones. The snug-fit design provides passive noise cancellation for an enhanced listening experience.



Deep Bass

Figure 5: Illustration of the earphone's snug fit for optimal audio and passive noise cancellation.

Call Function

The built-in microphone allows you to make and receive calls hands-free. When a call comes in, the audio will switch from media playback to the call. Use the in-line controls to manage calls.

In-line Controls

The in-line control unit typically includes buttons for:

- **Play/Pause:** Press once to play or pause music.
- **Answer/End Call:** Press once to answer an incoming call or end an ongoing call.
- **Next Track:** Double-press to skip to the next song.
- **Previous Track:** Triple-press to go back to the previous song.
- **Volume Control:** The control unit may include dedicated volume up/down buttons or a slider. (Refer to the specific design of your unit for exact functionality).

CARE AND MAINTENANCE

- **Cleaning:** Gently wipe the earbuds and cable with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the earphones in a clean, dry place, preferably in a pouch or case to prevent tangling and damage.
- **Cable Management:** Avoid sharp bends or excessive pulling on the cable to prevent internal wire damage. The cable is designed to be tangle-free.
- **Temperature:** Do not expose the earphones to extreme temperatures (hot or cold) or high humidity.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound from earphones	3.5mm jack not fully inserted; Device volume too low; Incorrect audio output selected on device; Damaged cable/earphones.	Ensure the jack is fully inserted; Increase device volume; Check device audio settings; Test with another device; If still no sound, earphones may be faulty.
Sound is distorted or crackling	Loose connection; Volume too high; Audio source issue; Damaged cable.	Re-insert the jack; Lower device volume; Try a different audio source; Inspect cable for damage.
Microphone not working	Microphone port blocked; Device microphone settings; Incompatible device.	Ensure microphone is not covered; Check device's audio input settings; Test with another device.
In-line controls not responding	Incompatible device; Software glitch; Damaged control unit.	Ensure device supports in-line controls; Restart your device; If persistent, the control unit may be damaged.

TECHNICAL SPECIFICATIONS

Feature	Specification
Model Name	Zeb-Bro
Connectivity Technology	Wired

Feature	Specification
Headphones Jack	3.5 mm Jack
Ear Placement	In Ear
Driver Size	10mm (Dynamic Driver)
Impedance	16 Ohm
Frequency Response	20Hz - 20kHz
Cable Length	1.2 Meters
Control Type	Noise Control, Volume Control, Media Control (Touch)
Noise Control	Passive Noise Cancellation
Material	Rubber
Item Weight	41 Grams (1.45 ounces)
Water Resistance Level	Not Water Resistant
Compatible Devices	Mobile, Tablet

OFFICIAL PRODUCT VIDEOS

No official product videos are available for this model at this time.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or visit the official ZEBRONICS website. You may also contact the retailer where you purchased the product for assistance.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07T5DKR5D>

More documents and user manuals: <https://manuals.plus/>