



[Manuals.plus](#) /

> [Summer Infant](#) /

> Summer Infant Lookout 5-Inch Color Video Baby Monitor (Model 36134) Instruction Manual

## Summer Infant 36134

# Summer Infant Lookout 5-Inch Color Video Baby Monitor Instruction Manual

Model: 36134

## 1. INTRODUCTION

---

This manual provides instructions for the safe operation and maintenance of your Summer Infant Lookout 5-Inch Color Video Baby Monitor. Please read all instructions carefully before use and retain this manual for future reference. This monitor is designed to assist you in monitoring your baby, but it is not a substitute for direct adult supervision.

## 2. SAFETY INFORMATION

---

- **STRANGULATION HAZARD:** Children can become entangled in cords. Keep the camera unit and adapter cords out of reach of children (at least 3 feet / 1 meter away). Never place the camera or cords within the crib or playpen.
- **CHOKING HAZARD:** This product contains small parts. Keep out of reach of children.
- **HEAT HAZARD:** Do not place the monitor or camera near heat sources such as radiators, heat registers, stoves, or other appliances that produce heat.
- **WATER AND MOISTURE:** Do not use the product near water, such as a bathtub, sink, or swimming pool.
- **POWER ADAPTERS:** Use only the AC power adapters provided. Using other adapters may damage the unit.
- **BATTERY SAFETY:** The monitor unit contains a rechargeable battery. Do not attempt to replace the battery yourself. Contact customer support for battery replacement.

## 3. PACKAGE CONTENTS

---

Verify that all components are present in your package:

- Parent Unit (Monitor) with 5-inch color screen
- Baby Unit (Camera)

- Two AC Power Adapters
- PrestoMount (for camera wall mounting)

## 4. PRODUCT OVERVIEW

---

### 4.1 Parent Unit (Monitor)

The parent unit features a 5-inch color LCD screen for clear viewing of your baby. It includes controls for digital zoom, two-way talk, and menu navigation. A temperature display is also integrated.



Image: The Summer Infant Lookout 5-inch color video baby monitor parent unit, displaying a baby in a crib and showing the temperature and signal strength.

### 4.2 Baby Unit (Camera)

The baby unit includes a camera lens, infrared LEDs for night vision, a microphone for audio detection, and a speaker for two-way talk. It also has a sync button for pairing and a power input port.

## TRADITIONAL MOUNT

SCREW AND  
WALL ANCHOR



## NO-HOLE PRESTOMOUNT™

NO DRILLING REQUIRED!



Image: The Summer Infant Lookout baby monitor camera unit, shown placed on a flat surface.



digital zoom

Image: The Summer Infant Lookout baby monitor camera unit, highlighting its two-way talk capability with an icon.

## 5. SETUP

### 5.1 Camera Placement

Position the camera unit in a location that provides a clear view of your baby. Ensure the camera and its cord are at least 3 feet (1 meter) away from the crib or playpen to prevent strangulation hazards. The camera can be placed on a flat surface or mounted to a wall using the included PrestoMount.

#### Using the PrestoMount for Wall Installation:

1. Clean the wall surface with rubbing alcohol. Do not use household cleaners or water.
2. Remove the protective backing from the PrestoMount adhesive.
3. Press the PrestoMount firmly onto the desired wall location for 30 seconds.
4. Wait 24 hours before attaching the camera to the wall mount to ensure proper adhesion.

1000 foot range



Image: A graphic illustrating the four steps for wall mount installation using the PrestoMount adhesive.

## Tips for Wall Mount Installation

---

1. Wipe wall with  
rubbing alcohol

(do not use household cleaner or water)

2. Remove backing from  
wall mount

3. Press wall mount firmly  
on wall for 30 seconds

4. Wait 24 hours before  
adding camera to wall mount

Image: A comparison showing a traditional screw and wall anchor mount (crossed out) versus the no-hole PrestoMount, emphasizing no drilling is required.



Image: A hand attaching the baby monitor camera unit to the installed wall mount, indicated by a dashed arrow.

## 5.2 Powering On

1. Connect one AC power adapter to the camera unit and plug it into a standard electrical outlet.
2. Connect the second AC power adapter to the parent unit and plug it into a standard electrical outlet. The parent unit has a rechargeable battery for portable use, but it should be charged before first use.
3. Press and hold the Power button on the parent unit until the screen turns on.

## 5.3 Pairing (If Necessary)

The camera and parent unit are pre-paired at the factory. If you need to re-pair or add additional cameras (up to 4 total, sold separately), follow these steps:

1. Ensure both the parent unit and camera are powered on.
2. On the parent unit, navigate to the 'Add Camera' option in the menu.
3. Press the 'Sync' button located on the back of the camera unit. The parent unit should display the camera's video feed once successfully paired.

## 6. OPERATING INSTRUCTIONS

---

## 6.1 Viewing Your Baby

Once powered on and paired, the parent unit will automatically display the video feed from the camera. If multiple cameras are connected, you can switch between them using the camera selection button on the parent unit.

5.0" color screen



Image: A parent holding the Summer Infant Lookout baby monitor, which displays a clear image of a baby sleeping in a crib.



Image: A person holding the Summer Infant Lookout baby monitor, showing a baby in a crib on its screen, demonstrating typical use in a home environment.

## 6.2 Two-Way Talk

To speak to your baby, press and hold the Talk button on the parent unit. Release the button to hear your baby's sounds.

## 6.3 Digital Zoom

Use the zoom button on the parent unit to digitally zoom in on your baby for a closer view. Press the button again to zoom out.



Image: A split image demonstrating the digital zoom feature, showing a wide view of a baby in a crib on the left and a zoomed-in view of the baby on the right.

#### **6.4 Automatic Night Vision**

The camera is equipped with infrared LEDs that automatically activate in low-light conditions, providing a clear black and white image of your baby in the dark.

#### **6.5 Room Temperature Display**

The parent unit displays the current room temperature detected by the camera unit, helping you ensure a comfortable environment for your baby.

two-way talk  
back to baby



Image: A close-up of the Summer Infant Lookout baby monitor screen, clearly showing the room temperature display at 70°F.

## 6.6 Wireless Range

The monitor offers a wireless range of up to 1,000 feet (300 meters) in open areas. Environmental factors such as walls, floors, and other electronic devices may reduce the effective range.

## room temperature display



Image: A person holding the Summer Infant Lookout baby monitor, with text indicating its 1000-foot range capability.

### 6.7 Expandable System

The system supports up to 4 cameras. Additional cameras are sold separately. The parent unit can auto-scan video and audio between multiple cameras.

## 7. MAINTENANCE

### 7.1 Cleaning

Wipe the monitor and camera units with a dry, soft cloth. Do not use cleaning sprays or liquid cleaners. Ensure the units are unplugged before cleaning.

### 7.2 Battery Care

The parent unit contains a rechargeable battery. For optimal battery life, fully charge the unit before first use. Avoid completely draining the battery frequently. If the unit will not be used for an extended period, charge it periodically to maintain battery health.

## 8. TROUBLESHOOTING

- **No Picture/Sound:** Ensure both units are powered on and connected to their respective power adapters. Check that the camera and parent unit are within range. Re-pair the units if necessary (refer to Section 5.3).
- **Poor Picture Quality:** Adjust the camera's position for a clearer view. Ensure there are no obstructions between the camera and parent unit. Reduce interference from other electronic devices.
- **Short Battery Life:** Ensure the parent unit is fully charged. Battery performance may decrease over time. Keep the parent unit plugged in when not in portable use.
- **Feedback/Static Noise:** Move the parent unit further away from the camera unit. Ensure no other electronic devices are causing interference.
- **Camera Disconnects Randomly:** Check the wireless range. Ensure the camera's power adapter is securely connected. Try re-pairing the units.

## 9. SPECIFICATIONS

Feature	Specification
Model Number	36134
Screen Size	5-inch Color LCD
Connectivity Technology	Wireless (Wi-Fi Protocol)
Power Source	Battery Powered (Parent Unit), AC Adapter (Camera)
Batteries Required	4 AAA batteries (included for parent unit, rechargeable)
Night Vision	Automatic Infrared Night Color
Night Vision Range	Up to 1000 Feet
Digital Zoom	Yes
Two-Way Talk	Yes
Room Temperature Display	Yes
Expandable	Up to 4 cameras
Product Dimensions	29.85 x 20.32 x 13.34 cm
Item Weight	734.82 g (1.62 Pounds)

## 10. WARRANTY INFORMATION

This Summer Infant product is covered by a **1-year limited manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. For specific terms and conditions, please refer to the warranty card included with your product or contact customer support.

## 11. CUSTOMER SUPPORT

If you have any questions, require assistance, or need to claim warranty service, please contact Summer Infant customer support. Refer to the contact information provided in your product packaging or visit the

official Summer Infant website for support details.