

IPEGA PG-9128

IPEGA PG-9128 Bluetooth Game Controller User Manual

Model: PG-9128

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your IPEGA PG-9128 Bluetooth Game Controller. Please read this manual thoroughly before using the device to ensure proper functionality and to prevent damage.



Figure 1: IPEGA PG-9128 Bluetooth Game Controller with a smartphone mounted, displaying a game scene. The controller is black with grey accents, featuring dual analog sticks, a D-pad, action buttons (X, Y, A, B), and shoulder buttons.

2. SETUP

2.1. Charging the Controller

Before initial use, fully charge the controller. Connect the provided USB charging cable to the controller's charging port and the other end to a USB power source (e.g., computer USB port, USB wall adapter). The LED indicator will show charging status and turn off when fully charged.

2.2. Pairing with a Device

1. Ensure the controller is powered off.

2. Press and hold the **HOME** button and the **X** button simultaneously for 3 seconds until the LED indicator flashes rapidly. This indicates the controller is in pairing mode.
 3. On your device (smartphone, tablet, PC), enable Bluetooth and search for available devices.
 4. Select "**PG-9128**" from the list of found devices.
 5. Once paired, the LED indicator on the controller will become solid, indicating a successful connection.
- Note: The pairing process may vary slightly depending on your device's operating system. Refer to your device's manual for specific Bluetooth pairing instructions.*

2.3. Attaching a Smartphone

The PG-9128 features an integrated phone holder. Gently extend the holder and securely place your smartphone within the clamps. Ensure the phone is centered and stable to prevent it from falling during use.

3. OPERATING INSTRUCTIONS

3.1. Power On/Off

- To power on: Press the **HOME** button. The controller will attempt to reconnect to the last paired device.
- To power off: Press and hold the **HOME** button for 5 seconds until the LED indicator turns off. The controller will also automatically power off after a period of inactivity.

3.2. Button Layout and Functions

Table 1: Controller Button Functions

Button	Function
HOME	Power On/Off, Reconnect
X, Y, A, B	Action Buttons (context-dependent in games)
L1, R1	Shoulder Buttons
L2, R2	Trigger Buttons
Left/Right Analog Sticks	Movement/Camera Control
D-Pad	Directional Control
SELECT/BACK	Menu/Selection
START/MENU	Pause/Game Menu

3.3. Game Compatibility

The IPEGA PG-9128 is designed to be compatible with a wide range of mobile games that support Bluetooth controllers. Compatibility may vary depending on the game and operating system. Some games may require specific controller mapping or third-party applications for optimal performance.

4. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the surface of the controller. Do not use abrasive cleaners, solvents, or strong chemicals, as these may damage the finish or internal components.

- **Storage:** When not in use, store the controller in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the controller regularly, even if not in constant use.
- **Handling:** Avoid dropping the controller or subjecting it to strong impacts, which can cause internal damage.

5. TROUBLESHOOTING

Table 2: Common Issues and Solutions

Problem	Possible Cause	Solution
Controller does not power on.	Low battery.	Charge the controller fully.
Cannot pair with device.	Controller not in pairing mode; Bluetooth off on device; interference.	Ensure controller is in pairing mode (flashing LED). Turn on Bluetooth on your device. Move closer to the device. Try restarting both controller and device.
Controller disconnects frequently.	Low battery; too far from device; interference.	Charge the controller. Stay within Bluetooth range. Reduce wireless interference.
Buttons/sticks not responding correctly in game.	Game compatibility issue; incorrect mapping.	Check game settings for controller support. Some games may require specific modes or third-party mapping tools. Try resetting the controller (if applicable, check manual for reset button).

6. SPECIFICATIONS

- **Model:** PG-9128
- **Connectivity:** Bluetooth
- **Battery Type:** Lithium Metal (included)
- **Dimensions (L x W x H):** 7 x 21 x 17 cm (approximately)
- **Weight:** 270 grams (approximately)
- **Compatibility:** Android, iOS (limited), PC (via Bluetooth adapter, if applicable)







7. WARRANTY INFORMATION

This product is covered by a limited warranty against defects in materials and workmanship. The warranty period and terms may vary by region and retailer. Please retain your proof of purchase for warranty claims. For specific warranty details, refer to the documentation provided at the time of purchase or contact your retailer.

8. CUSTOMER SUPPORT

If you encounter any issues not covered in this manual or require further assistance, please contact the retailer where you purchased the product or visit the official IPEGA website for support resources, FAQs, and contact information. When contacting support, please have your product model (PG-9128) and proof of purchase ready. For more information, you may visit the [Official IPEGA Website](#) (link for illustrative purposes, actual link may vary).

Related Documents - PG-9128

	<p>iPega PG-9128 Kingkong Wireless Gamepad User Manual</p> <p>Comprehensive user manual for the iPega PG-9128 Kingkong wireless gamepad, covering setup, button functions, parameters, connection modes (Bluetooth and wired), charging, and maintenance for Android, iOS, PC, and consoles.</p>
	<p>Instrukcja obsługi - Kontroler iPega PG-9128</p> <p>Szczegółowy przewodnik po konfiguracji i użytkowaniu kontrolera Bluetooth iPega PG-9128 z urządzeniami Android, iOS i Windows. Zawiera informacje o funkcjach, trybach połączenia, ładowaniu i ważnych wskazówkach.</p>
	<p>iPEGA Bluetooth Game Controller Setup Guide for Android Gaming</p> <p>Learn how to connect your iPEGA Bluetooth gamepad to your Android device, map buttons for games like PUBG, and enable developer options for optimal mobile gaming performance. Includes game mode configurations and troubleshooting.</p>
	<p>Руководство пользователя беспроводного геймпада ípega PG-9128 Black Kingkong</p> <p>Подробное руководство пользователя для беспроводного геймпада ípega PG-9128 Black Kingkong. Инструкции по подключению, настройке и использованию на различных платформах.</p>
	<p>iPega PG-9021 Bluetooth Gamepad User Manual</p> <p>Comprehensive user manual for the iPega PG-9021 Bluetooth Gamepad, detailing setup, connectivity for Android, iOS, and Windows, troubleshooting, and product specifications.</p>
	<p>ipega PG-9023 Extending Game Controller: User Manual and Features</p> <p>Comprehensive guide to the ipega PG-9023 Extending Game Controller, covering features, game support, connection modes (GamePad, Keyboard, iCade, SPP), setup instructions for Android and iOS, and troubleshooting.</p>

