Gvirtue BN59-01259B

Gvirtue Universal Remote Control for Samsung TVs

Model: BN59-01259B

INTRODUCTION

This manual provides instructions for the Gvirtue Universal Remote Control, designed for use with a wide range of Samsung LED, LCD, QLED, HDTV, 3D, and Smart TV models. This remote serves as a replacement for many original Samsung remote controls, including the BN59-01259B model. It operates using infrared technology and does not require programming for most compatible Samsung TVs.

SETUP

1. Battery Installation

The remote control requires two (2) AA batteries for operation. To install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open.
3. Insert two AA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

Figure 1: Battery compartment for two AA batteries.

2. Initial Pairing (If Necessary)

For most compatible Samsung TVs, this remote control operates immediately after battery installation without additional programming. If the remote does not respond to your TV, a simple pairing step may be required:

- Ensure your TV is powered on.
- Point the remote control towards the TV.
- Simultaneously press and hold the **Back** button (curved arrow) and the **Play**/**Pause** button (triangle with two vertical lines) for approximately 3 seconds.
- Release the buttons. The remote should now be paired with your Samsung TV.

OPERATING INSTRUCTIONS

The Gvirtue Universal Remote Control features a streamlined design with essential functions for navigating your Samsung TV. Refer to the diagram below for button identification and their primary functions.

Figure 2: Remote Control Button Layout and Functions.

- **Power ( )**: Turns the TV on or off.

- **123 (Number Pad)**: Accesses the on-screen number pad for direct channel input or other numerical entries.

- **EXTRA (Color buttons)**: Activates additional functions, often context-sensitive, indicated by colored prompts on the TV screen.

- **Directional Pad (Up/Down/Left/Right)**: Navigates menus and selects items.

- **Select (Center Button)**: Confirms selections or enters menus.

- **Return ( )**: Goes back to the previous screen or menu.

- **Smart Hub ( )**: Opens the Samsung Smart Hub, providing access to apps, streaming services, and other smart features.

- **Play/Pause ( )**: Controls media playback (play, pause).

- **VOL (Volume)**: Move the button up or down to adjust the volume. Press the button to mute the sound. Press and hold for 1

second or more to access Accessibility Shortcuts.

- **CH (Channel)**: Move the button up or down to change the channel. Press the button to see the Guide screen.

COMPATIBILITY

This Gvirtue remote control is designed to be compatible with a wide range of Samsung televisions and can replace many original Samsung remote models. It supports Samsung 3D HDTV, 2K, 4K UHD Smart TVs, and various series including 4, 5, 6, 7, and 8 series.

Compatible TV Series and Models:

This remote is compatible with numerous Samsung TV models from 2016 and 2017, including but not limited to:

- **2016 Models:** KS8000, KS800D, KS8500, KS850D, KS9000, KS900D, KS9500, K625D, KU6290, KU6300, KU630D, KU6500, KU650D, KU6600, KU7000, KU700D, KU7500, KU750D series. Specific models include UN49KS8000F, UN55KS8000F, UN60KS8000F, UN65KS8000F, UN40KU6290, UN50KU6290, UN55KU6290, UN60KU6290, UN65KU6290, UN70KU6290, UN40KU6300, UN43KU6300, UN50KU6300, UN55KU6300, UN60KU6300, UN65KU6300, UN70KU6300, UN49KU6500F, UN55KU6500, UN65KU6500, UN55KU6600F, UN40KU7000, UN43KU7000, UN49KU7000, UN55KU7000F, UN65KU7000F, UN49KU7500FXZA, UN55KU7500F, UN65KU7500F, UN78KU7500F, UN65KS950DF, UN65KS9800F, UN78KS9800F, UN88KS9810F.
- **2017 Models:** MU6300, MU6500, MU7000, MU7500, MU8000, MU8500, MU9000 series. Specific models include UN40MU6300FXZA, UN43MU6300FXZA, UN50MU6300FXZA, UN55MU6300FXZA, UN65MU6300FXZA, UN75MU6300FXZA, UN49MU6500FXZA, UN55MU6500FXZA, UN65MU6500FXZA, UN40MU7000FXZA, UN49MU7000FXZA, UN55MU7000FXZA, UN65MU7000FXZA, UN49MU7500FXZA, UN55MU7500FXZA, UN65MU7500FXZA, UN49MU8000FXZA, UN55MU8000FXZA, UN65MU8000FXZA, UN75MU8000FXZA, UN82MU8000FXZA, UN65MU8500FXZA, UN55MU9000FXZA, UN65MU9000FXZA, UN75MU9000FXZA.

Replaced Remote Models:

This remote can replace many Samsung Bluetooth remotes, including but not limited to:

- BN59-01259B, BN59-01259E, BN59-01259D, BN59-01260A, BN59-01241A, BN59-01266A
- AA5900326, AA5900327, AA5900403E, BN5900687A, D5900350A, AA5900421A, BN5900701A, AA5900424A, AA5900316B, AA59-00781A, AA59-00772A, AA59-00758A, AA59-00772A, AA59-00776A, AA59-00778A, AA59-00784C, AA59-00817A, BN59-01259D, BN59-01182A, BN59-01181N, BN59-01185F, BN59-01185A, BN59-01181A, BN59-01184A, BN59-01179B, BN59-01220J, BN59-01220E, BN59-01006A, BN59-01042A, BN5900604A, BN5901015A, BN5900609A, BN5901012A, BN5900610A, BN5901014A.

Figure 3: Gvirtue remote compatible with various Samsung remote models.

Figure 4: Compatibility with various Samsung TV types.

FEATURES

- **No Programming Required:** This remote is designed to work immediately with most compatible Samsung TVs upon battery installation.
- **Infrared Technology:** Utilizes infrared signals for reliable communication with your television.
- **Ergonomic Design:** Shaped for comfortable handling and ease of use.
- **Durable Construction:** Manufactured with quality materials for longevity.

Figure 5: Key features of the Gvirtue remote control.

Figure 6: Long-distance precise control via infrared technology.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Avoid using liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's responsiveness decreases. Always replace both batteries at the same time with new AA batteries. Do not mix old and new batteries or different types of batteries.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures. If the remote will not be used for an extended period, remove the batteries to prevent leakage.

TROUBLESHOOTING

- **Remote not responding:**
  - Ensure batteries are correctly installed with proper polarity (+/-).
  - Replace old batteries with new AA batteries.
  - Point the remote directly at the TV's infrared receiver.
  - Try the pairing steps described in the "Setup" section.
- **Buttons are unresponsive or require hard pressing:**

- This can sometimes occur with prolonged use. Ensure the remote is clean and free of debris around the buttons.
- If the issue persists, consider replacing the remote.

- **Difficulty opening battery cover:**
    - The battery cover is designed to fit securely. Apply firm, even pressure when sliding the cover.
    - Avoid excessive force to prevent damage.

SPECIFICATIONS

Product Dimensions	5 x 1 x 0.5 inches
Item Weight	1.9 ounces
Model Number	BN59-01259B
Batteries Required	2 AA batteries
Brand	Gvirtue
Connectivity Technology	Infrared
Color	Black

Figure 7: Remote control dimensions.

WARRANTY AND SUPPORT

Specific warranty information for the Gvirtue Universal Remote Control is not provided within this manual. For details regarding warranty coverage, technical support, or further assistance, please refer to the product packaging or contact Gvirtue customer service directly.

You may also visit the Gvirtue Store on Amazon for additional product information.