

[Manuals.plus](#) /

> [ReadyWired](#) /

> ReadyWired USB Charging Cable for Blackweb Highwire Wireless Bluetooth Speaker BWA15AV110 User Manual

ReadyWired BWA15AV110

ReadyWired USB Charging Cable User Manual

For Blackweb Highwire Wireless Bluetooth Speaker Model BWA15AV110

1. PRODUCT OVERVIEW

The ReadyWired USB Charging Cable is designed to provide reliable power to your Blackweb Highwire Wireless Bluetooth Speaker, model BWA15AV110. This 3-foot cable ensures convenient charging and is built for durability and consistent performance.



Image 1.1: The ReadyWired USB Charging Cable, featuring a standard USB-A connector on one end and a Micro-USB connector on the other, both in black with the USB symbol. The cable itself is black and coiled.

2. SETUP INSTRUCTIONS

- 1. Identify Ports:** Locate the USB charging port on your Blackweb Highwire Wireless Bluetooth Speaker (BWA15AV110). This is typically a Micro-USB port.
- 2. Connect to Speaker:** Gently insert the Micro-USB end of the ReadyWired cable into the charging port of your Blackweb speaker. Ensure it is fully seated.
- 3. Connect to Power Source:** Insert the standard USB-A end of the cable into a compatible USB power source, such as a wall adapter (not included), a computer's USB port, or a power bank.
- 4. Verify Connection:** Confirm that the speaker's charging indicator light (if present) illuminates, indicating that charging has begun.

3. OPERATING INSTRUCTIONS

Once connected as described in the Setup section, the ReadyWired USB Charging Cable will automatically begin charging your Blackweb Highwire Wireless Bluetooth Speaker. No additional steps are required for operation.

- For optimal charging speed, use a USB wall adapter with appropriate power output (e.g., 5V/1A or 5V/2A) as recommended by your speaker's manufacturer.
- Avoid using damaged cables or power sources, as this can harm your device.
- The cable supports both charging and data transfer, though its primary function for this product is charging.

4. MAINTENANCE

Proper care and maintenance will extend the life of your ReadyWired USB Charging Cable.

- **Storage:** When not in use, store the cable in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling or bending the cable sharply.
- **Cleaning:** If the cable or connectors become dirty, gently wipe them with a dry, soft cloth. Do not use liquid cleaners or abrasive materials.
- **Handling:** Always grasp the connector head when plugging or unplugging the cable, rather than pulling on the cable itself, to prevent damage to the internal wires.
- **Inspection:** Periodically inspect the cable for any signs of wear, fraying, or damage to the connectors. Discontinue use if damage is observed.

5. TROUBLESHOOTING

If you encounter issues while using your ReadyWired USB Charging Cable, refer to the following common solutions:

Problem	Possible Cause	Solution
Speaker not charging.	Cable not properly connected.	Ensure both ends of the cable are securely plugged into the speaker and the power source.
Speaker not charging.	Faulty power source or adapter.	Try a different USB wall adapter or a different USB port on your computer.
Speaker not charging.	Damaged cable.	Inspect the cable for visible damage (frays, bends). If damaged, replace the cable.
Slow charging.	Low-power USB port or adapter.	Use a USB wall adapter with a higher current output (e.g., 5V/2A) if your speaker supports it.

6. SPECIFICATIONS

Brand: ReadyWired

Model Compatibility: Blackweb Highwire Wireless Bluetooth Speaker BWA15AV110

Cable Type: USB (USB-A to Micro-USB)

Connector Gender: Male-to-Male

Length: 3 Feet (approximately 0.91 meters)

Function: Charging, Data Transfer

Color: Black

Indoor/Outdoor Usage: Indoor, Outdoor

UPC: 305978365022

7. WARRANTY AND SUPPORT

ReadyWired products are manufactured to high-quality standards. For information regarding warranty coverage or technical support, please refer to the ReadyWired official website or contact their customer service directly.

For further assistance, please visit the [ReadyWired brand page on Amazon](#) or contact the seller, River City Electronics, through your Amazon order details.